

Party Lantern Instructions

K: 43564590



Please read this instruction manual carefully before use. Keep it in a safe place for future reference.

TECHNICAL SPECIFICATIONS:

Charging Input: DC5V1A

(only for Li-battery cell)

Output: DC5V1A

Li-battery: 3.7V 1200mAh

3 AA battery: 3x1.5V DC (Product does not contain 3AA batteries)

Power: 3W

PACKING LIST:

PRODUCT x1

USB DATA CABLE x1

MANUAL x1



Switch Function:

- full light
- half light
- 3 color lights rotates
- full light and 3 color lights rotates
- half light and 3 color lights rotates

Charging & discharge function:

When using a Li-battery cell, during charging, the indicator LED (near the charging port) will turn red and flash. When the battery is fully charged, the LED will stay solid red without flashing.

When using AAA batteries, the batteries cannot be charged. If you plug in the charging cable, the indicator LED will turn solid red without flashing.

If you use the product as a power supply, when the USB cable is plugged into the output port, the indicator LED will turn green.



WARNING: KEEP AWAY FROM FIRE. DO NOT DISMANTLE OR DISASSEMBLE.



Caution: when use LI-battery, please recharge the product for every 3 months.

HOW TO DISPOSE OF RECHARGEABLE BATTERIES

1. Be sure to turn off the power before disassembling the product and taking out the lithium battery.
2. The removed lithium battery should be disposed of safely and put into the battery recycling center designated by the government, which is conducive to environmental protection. Special Note: Take out the battery only when discarding this product. Before taking it out, please make sure that the battery has been exhausted. Non-professionals should not disassemble it.

CLEANING AND PRESERVATION

Please use a clean soft cloth to clean the product (please turn off the power when cleaning, do not use corrosive cleaning agents such as benzene or thinner, otherwise it will cause discoloration, surface aging, structural damage, etc.)

Please put the product in a well-ventilated and dry room.

MADE IN CHINA

CUSTOMER SERVICE

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567