



NETGEAR.com/support



community.NETGEAR.com

NETGEAR, Inc. 350 East Plumeria Drive San Jose, CA 95134, USA
NETGEAR INTERNATIONAL LTD Floor 6, Penrose Two, Penrose Dock,
Cork, T23 YY09, Ireland

© NETGEAR, Inc., NETGEAR, the NETGEAR Logo and the Nighthawk logo
are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used
for reference purposes only.



July 2024



For detailed instructions on alternative setup
methods like fixed installation and enterprise
deployment with NETGEAR Insight, scan the QR
code or visit NETGEAR.com/m7usermanual.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document
en français canadien à NETGEAR.com/support/download. (If this product
is sold in Canada, you can access this document in Canadian French at
NETGEAR.com/support/download.)

For regulatory compliance information including the EU Declaration of
Conformity, visit NETGEAR.com/about/regulatory. See the regulatory
compliance document before connecting the power supply. For
NETGEAR's Privacy Policy, visit NETGEAR.com/about/privacy-policy. By
using this device, you are agreeing to NETGEAR's Terms and Conditions at
NETGEAR.com/about/terms-and-conditions. If you do not agree, return the
device to your place of purchase within your return period.

Applicable to 6 GHz devices only: Only use the device indoors. The
operation of 6 GHz devices is prohibited on oil platforms, cars, trains, boats,
and aircraft, except that operation of this device is permitted in large aircraft
while flying above 10,000 feet. Operation of transmitters in the 5.925-7.125
GHz band is prohibited for control of or communications with unmanned
aircraft systems.


NETGEAR

QUICK START


NIGHTHAWK® | **M7 ULTRA**

5G MOBILE WIFI ROUTER


CONTENTS




Nighthawk M7 Ultra
5G Mobile WiFi Router



Power adapter
*Packages in some regions might
include additional plug adapters*




Battery




USB cable

REMOVE BATTERY COVER



1
Locate the small indent on the corner of the
back cover and gently pry it open

INSTALL THE SIM AND BATTERY




2
Slide the nano SIM
card into its slot

3
Insert the battery
into the device

4
Press to snap the
back cover into place

SET UP YOUR MOBILE WIFI ROUTER



Press and hold the **Power/home button** for two seconds to turn on your router, then follow the onscreen instructions to complete setup.

You can also connect to the router's default WiFi network with a WiFi device and visit <http://192.168.1.1> to complete setup from the web.