

LIVE TO PLAY LIVE®



JIMDUNLOP.COM

DUNLOP MANUFACTURING, INC. P.O. BOX 846 BENICIA, CA 94510 U.S.A. TEL: 1-707-745-2722 FAX: 1-707-745-2658



92503012781revB



SLASH

CRY BABY CLASSIC WAH

SC95 SLASH CRY BABY CLASSIC WAH OWNER'S MANUAL

SC95 SLASH CRY BABY® CLASSIC WAH

POWER

The Slash Cry Baby Classic Wah is powered by one 9-volt battery (accessed via bottom of pedal), a 9-volt AC adapter such as the Dunlop ECB003/ECB003EU, or a DC Brick™ power supply.

SETUP INSTRUCTIONS

- Run a shielded instrument cable from your guitar to the SC95's Instrument jack.
- Run another shielded instrument cable from the SC95's Amplifier jack into your amplifier input.
- Turn on the amplifier and begin playing.
- To turn the pedal on/off, push the toe of the pedal down until you feel a "click".
- By rocking your foot back and forth on the pedal, you can change the effect that the SC95 has on the tone of your instrument instantaneously.
- Blue LEDs on both side's of the pedal indicate ON/OFF status.

SPECIFICATIONS

Inductor	Custom wound low noise 560 millihenry high "Q" torroid
Input Impedance	.7 MEG
Output Impedance	<1 K
Sweep range	340 Hz - 1.7 KHz
Signal To Noise	>102 dB A weighted
Bypass	Hardwire DPDT bypass
Effect on LED's	Located on both sides of pedal
Power Requirements	+9 VDC @ <3 ma., 5.5mm x 2.1mm positive barrel & negative center or standard 9-volt battery.

