


PARTS LIST

REPLACEMENT PARTS - MODEL YM2BP 2-CYCLE GAS BACKPACK BLOWER




Item	Part No.	Description
1	753-05631	Muffler Assembly (includes 2)
2	753-05701	Muffler Gasket
3	753-05636	Shortblock Assembly (includes 4 & 11-17)
4	753-05784	Spark Plug
5	753-05702	Insulator Gasket
6	753-05632	Insulator Assembly (includes 5)
7	791-181709	Carburetor Gasket
8	753-05633	Carburetor Assembly (includes 7)
9	791-181757	Air Filter

Item	Part No.	Description
10	753-05725	Aircleaner Assembly (includes 9)
11	753-04324	Module Assembly
12	753-05703	Screw
13	753-05704	Cylinder Gasket
14	753-05705	Flywheel Adapter
15	753-05706	Washer
16	753-05707	Bushing
17	753-05708	Flywheel Assembly
18	753-05635	Pawl Assembly

PARTS LIST

REPLACEMENT PARTS - MODEL YM2BP 2-CYCLE GAS BACKPACK BLOWER



Item	Part No.	Description
1	753-05637	Nozzle
2	753-05638	Lower Blower Tube
3	753-05652	Throttle Grip Assembly
4	753-05639	Upper Blower Tube
5	753-05640	Clamp
6	753-05641	Flex Tube
7	753-05642	Elbow
8	753-05655	Harness Clip
9	753-05645	Harness (includes 8)
10	753-05643	Lead Wire
11	753-05644	Throttle Cable
12	753-05647	Nut
13	753-05646	Spacer

Item	Part No.	Description
14	753-05648	Insulator Mount
15	753-05649	Intake Cover
16	791-181345	Screw
17	791-180050	Nut
18	791-181862	Screw
19	753-05650	Impeller Housing Assembly (includes 14 & 16-18)
20	791-182414	Bolt
21	753-04482	Impeller Hardware (includes 20)
22	753-05651	Impeller (includes 20 & 21)
23	753-05654	Fuel Tank Assembly
24	791-182529	Fuel Cap
25	753-05728	Starter Housing Assembly (includes 16 & 18)