



For gold nugget prospecting in mineralised gold field locations.

GOLD*




For all salty conditions — dry sand, wet sand, surf and underwater.

BEACH



Ideal for detecting in historical fields for the widest range of target sizes.

FIELD



Great for high-trash recreational areas, including most general detecting.

PARK

SEARCH MODES * EQUINOX 900 Only



**GO
DETECTING**



**NOISE
CANCEL**



**SELECT
SEARCH MODE**



**TURN
ON**
QUICK START

This Getting Started Guide and the full length EQUINOX® User Manual are available to download online.

 Get these languages and more:

DE Deutsch **FR** français **KR** 한국어 **RU** русский
ES Español **JP** 日本語 **PT** Português **ZH** 中文


EQUINOX
700 | 900

GETTING STARTED GUIDE



4901-0417-1

ASSEMBLY



TIGHTEN CAMLOCKS


Tighten the Camlocks if they slip or become loose.




Open



Tighten gently in increments




Close



Check and repeat if needed

CHARGING

5-6 HOURS



⚠ Charge your detector with a good-quality USB charger that has a minimum charging capacity of 2 A @ 5V.

Risk of USB charger failure if a low quality charger is used.

Look for the following marks on USB chargers:



3 HOURS



CONTROLS & DISPLAY



* EQUINOX 900 Only