REMOTE SOLAR STRING LIGHTS INSTRUCTIONS

PRODUCT SPECIFICATION

SOLAR PANEL	4.5V 250MA
BATTERY	1200 capacity
WORKTIME	3-5 nights if power is full
FUNCTION	brightness control . 8 modes adjust . timing
COLOR	□white □warm white □multi-color □others
LED	□30LED □50LED □60LED □100LED □200LED
	□300LED □500LED □1000LED □others
MODE	1.Combination 2.In waves 3.Sequential
	4.Slo Glo 5.Chasing/Flash 6.Slow fade
	Twinkle/Flash 8.Steady on


DIRECTION FOR USING




Set light mode by pressing mode button

Press the Power switch(ON/OFF)

HOW TO USE REMOTE CONTROL



REMOTE CONTROL ATTENTIONS



INSTALLED ON THE GROUND



connect it



the controller





3.Install the product according to the picture

INSTALLED ON THE WALL





1.Punch holes in the wall according to the positioning holes







2. Tighten the screw and fix the bracket

3. The best installation angle as

ATTENTIONS





Charging during the day, please make sure nothing cover the solar panel, Whether or not it will affect the charging effect of solar energy, and affect the lighting time and brightness.





Make sure there is no strong light on the solar panel after dark, Whether or not it will enter charging mode, and the string lights will not work.