



NIRVANA ZENITH PRO

SMART GUIDE


PACKAGE CONTENTS




PRODUCT LABELLING




SMART POWER ON/OFF



BLUETOOTH PAIRING




MODES OF NOISE CONTROL



Long touch the CTC on the right earbud for 2 seconds to toggle between Normal (ANC Off), Ambient, and ANC (Active Noise Cancellation) audio modes.


Note:
1. By default, the Normal (ANC OFF) mode is active.
2. The operational cycle is Normal Mode (ANC OFF) → Ambient Mode → ANC Mode.
3. Use the boAt Hearables app to choose between Adaptive, Max, Moderate and Mild ANC sub-modes.
4. Adaptive ANC chooses the most optimized ANC level based on your background noise.
5. Your earbuds will remember the mode you last used & will enable the respective noise cancellation mode when they are powered on next time.
6. When you activate ANC or Ambient modes, the earbuds will consume more power which will reduce the playtime.

MULTIPOINT CONNECTION



Note: If the earbuds are not connected, try connecting the first device manually once again to activate multipoint connection.


Hi-RES AUDIO WITH LDAC



Note:
• Streaming audio in LDAC mode might reduce the playtime of your earbuds.
• Please refer to your phone's user manual for instructions on how to activate LDAC.


*LDAC and LDAC logo are trademarks of Sony Corporation.

FUNCTIONS (CALL/MUSIC)




Note: The earbuds may start at 100% volume when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.

FUNCTIONS (boAt Spatial Audio/ BEAST™ MODE VOICE ASSISTANT)



Note:
• boAt Spatial Audio is activated only when both earbuds are worn. This mode will be deactivated in Mono (single earbud) mode.
• The earbuds may start at high volume when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.

HEARABLES APP COMPATIBILITY



Discover the following features of your earbuds only on the Hearables App-

- ✓ Toggle Noise Cancellation Modes
- ✓ Toggle Adaptive ANC Modes
- ✓ Activate/Deactivate boAt 360 Spatial Audio
- ✓ boAt Adaptive EQ by Mimi
- ✓ Touch Control Customization
- ✓ Preset EQ Modes
- ✓ Connectivity and Battery Status
- ✓ Activate/Deactivate Multipoint Connectivity
- ✓ Activate/Deactivate In-Ear Detection
- ✓ Smart Diagnostics Function
- ✓ Over-the-Air Software Updates

RESET NIRVANA ZENITH PRO

Note: Red LED rapidly flashes 5 times on both earbuds and white LED rapidly flashes 5 times on the charging case after successful reset.

LED STATUS GUIDE

Note: (1) Before using the earbuds for the first time, it is recommended to fully charge them.
(2) Please note that the earbuds cannot be used / switched on while charging.

CHARGING GUIDELINES

Note: (1) Before using the earbuds for the first time, it is recommended to fully charge them.
(2) Please note that the earbuds cannot be used / switched on while charging.

LEARN MORE ABOUT YOUR PRODUCT

Scan this QR Code to Access Your Product's Manual, FAQs, and Warranty Information

PDF Adobe