

We're saving some paper. View your manual online.

dhlifelabs.com/help-support/

Need Help?

1-877-548-9722 9 AM-6 PM, CST, Monday-Friday









Aaira + HEPA

QUICK START GUIDE | AAHE-50WC04C



Your safety is important to us.

Read all safety instructions before you use the device.



WARNING! TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY PLEASE ADHERE TO THE FOLLOWING:

- ! Use only as described in the instruction manual. Do not carry out any maintenance other than that shown in this guide or as advised by customer support. Any other use not recommended by the manufacturer may cause fire, electric shock or injury.
- ! Ensure the machine is fully assembled in accordance with the instructions before use.
- ! Do not move the machine while it is plugged in or powered on. Make sure the machine is powered off and unplugged before moving.
- ! Remove the HOCl Generator before moving the machine to avoid spilling water inside the machine. If water is spilled while moving, wipe the machine dry with a clean cloth and allow it to dry before use.
- ! THIS MACHINE IS NOT INTENDED FOR USE BY CHILDREN. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children. This appliance can be used by children 8 years and above if supervised.

- ! DO NOT LOCATE DIRECTLY BELOW A MAIN ELECTRICITY SUPPLY SOCKET.
- ! This machine is not intended for use by persons with reduced physical, sensory or reasoning capabilities or lack of experience or knowledge unless they have been given supervision or instruction concerning the use of the machine by a person responsible for their safety.
- ! Do not use the machine on wet surfaces or outdoors. Do not use in bathrooms. Never operate the machine where it may fall in the bath or other water container. Do not use or store it where it may get wet or in the immediate surroundings of a bath, shower or swimming pool.
- ! Do not pour water into any openings except for the water tank. When refilling, only do so as described in this guide. DO NOT USE HOT WATER.
- ! Do not unplug by pulling the cord from the socket. To unplug, grasp the plug, not the cord

- ! This machine may have hot parts inside. Do not use in areas where fuel, paint or flammable liquids are present. Keep combustible materials away from the machine. DO NOT USE NEAR FURNACES, FIREPLACES, STOVES OR OTHER HIGH-TEMPERATURE HEAT SURFACES.
- ! To reduce the risk of electric shock, this machine has a polarized plug. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way. (Not applicable in UK).
- ! Always plug directly into a wall socket. Never use the machine with an extension cord as overloading may result in the cord overheating or catching fire.
- ! Do not handle any part of the plug with wet hands.
- ! Do not use the machine with a damaged cord or plug.
- ! Do not allow the area around the machine to become damp or wet. If dampness occurs, turn the output of the humidifier down or use intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
- ! If the machine is not working properly, has received a sharp blow, has been dropped or damaged, do not use the machine and contact customer support for repair.

- ! Do not use the machine on a soft or unstable surface. ALWAYS PLACE THE MACHINE ON A FIRM, FLAT, LEVEL SURFACE.
- ! DO NOT COVER THE MACHINE WHILE IN USE.
- ! Never leave water in the reservoir when not in use. Empty and clean before storage. Clean before next use.
- ! Turn off all controls before unplugging. Always unplug the machine if not in use and while filling or cleaning.
- ! For best performance, place the machine on the floor at least 3 feet from any wall or appliances.
- ! READ AND SAVE THESE INSTRUCTIONS.
- ! THIS MACHINE IS INTENDED FOR HOUSEHOLD AND INDOOR USE ONLY.
- ! Warning: Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.

Read all safety instructions in the quick start guide, instruction manual, and on device.



Product Overview



- 1. Main Body
- 2. 3-Stage H13 HEPA Filter
- 3. HOCl Generator
- 4. Cold Evaporation Filter (CEF)
- 5. Salt Bottle with 1 Gram Scoop

Quick Start



Take off bottom cover, remove H13 true HEPA filter from plastic bag, and install in device. Replace the bottom cover.



Fill the generator with water to the MAX. water level (800ml/27.05oz.).





Add 1 scoop total (1 gram) of non-iodized salt and stir evenly.





Replace the CEF and screw it into the bottom of the HOCl Generator.



3

Grasp the handle and turn the HOCI Generator to unlock it and remove it from the device.

Remove top cover to access the HOCl Generator.



8

Wipe the exterior dry and place it back in the base. Using the handle, turn the HOCl generator and lock it in place. Replace top cover.



4

Remove the CEF by unscrewing it from the generator.





Connect the AC adapter to the device, plug into an outlet, and press the power button to turn on.



Control Panel



Fan Speed

(1/2/3) Three fan speed



Sleep Mode

Lowest fan speed level that is ultra-quiet



On/Off

Powers the device on and off



Timer

(2H/4H/8H) Set the timer to have the machine turn off automatically



Disinfect

On and flashing when generating HOCI



CEF Replacement Indicator

Press for 3 seconds to reset the filter life countdown



HEPA Filter Replacement Indicator

Press for 3 seconds to reset the filter life countdown



Wi-Fi Indicator

Flashing amber: Attempting to connect Steady amber: Connection successful Steady red: Not connected Connect/disconnect: Short press

Alerts



(SOLID)

Low Salt Alert

Solid salt level indicator Sound alert

or



(SOLID)

Low Water Alert

Solid water level indicator Sound alert



(FLASHING)

or High Salt Alert

Flashing salt level indicator Sound alert

What to do:

- **1.** Power off device
- 2. Empty HOCl Generator
- 3. Rinse the CEF
- 4. Fill water to Max line
- **5.** Add 1 scoop total (1 gram) of non-iodized salt and stir evenly



(FLASHING)

HOCl Generator Alert

Flashing water level indicator

What to do:

- 1. Power off device
- 2. Remove HOCl Generator and reposition correctly in device

Real-Time Air Quality Indicator







Good

Moderate

Poor

Connectivity



DH Lifelabs App

download the DH Lifelabs App. Open the App and click '+' to connect your device. Follow the steps in the App. Works with Google Home or Amazon Alexa.

Download on the App Store



Aaira + HEPA can connect with your smart device when you

Cleaning Your Aaira + HEPA

The unit should be cleaned regularly. Clean the HOCl Generator with fresh water. Use a clean, dry cloth for the external surfaces of the machine. If water stays in the HOCl Generator for 7 days follow the alert process.

Maintenance Alert

Flashing water level indicator Flashing salt level indicator

What to do:

- 1. Power off device
- Empty HOCl Generato
- **3.** Rinse the CEF
- 4. Fill water to Max line
- **5.** Add 1 scoop total (1 gram) of non-iodized salt

Descaling

Lime scale builds up in the machine over time. To ensure the best performance, descale monthly.

What to do:

- 1. Power off device
- 2. Empty HOCl Generator
- 3. Take out the CEF
- Add 200ml (7 oz) of 5% white vinegar; leave for 1 hour (do not turn device power on)
- **5.** Empty and clean HOCl Generator with fresh water

5