



Original	Replacement
 Guia	 Gui de / EPG / - / - -
 Power	 Power
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 ←	 Back / Return
 O	 Info / Angle
 (>)	 Smart / List
 V+	 Vol +
 Voice	 Display / Media
 P+	 CH+ / Page+
 V-	 Vol -
 P-	 CH- / Page-
 Red	 Red / Netflix / Search
 Sky	 TV/ Radio /

Original	Replacement
 Green	 Green / APP / Repeat
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Mute	 Mute / Dimmer
 0	 0
 Yellow	 Yellow / YouTube / Repeat

