RainPoint® More Than Water Saving

Need Help?


Scan the QR code for more help.



or Email: support@rainpointonline.com

QUICK START GUIDE

Watch how-to videos on YouTube, search @Rainpoint






1 Check the water inlet filter

The filter prevents impurities from entering and blocking the valve, and its peripheral rubber ring seals the connection to prevent leaks. Please install the water inlet filter correctly as shown below.




2 Insert the batteries correctly


Prepare 4 new AA alkaline batteries and insert them into the battery compartment as shown below. Then, securely close the battery compartment cover to ensure it is waterproof.



Install the timer on the faucet



Wrap Teflon tape to the faucet's or hose's threads to avoid leakage.



Install the timer when the faucet is off and make sure the inlet is higher than outlets.


Try to ensure the display vertical to the ground.





Activate the timer valve before use

- Keep the faucet off and turn the dial to "ON".
- Press and hold the "OK/ MANUAL" button and at the same time insert the batteries to enter the self-inspection mode.
- Release "OK/Manual" button 3 secs later and all the valves will be opened and closed in turn to finish self-inspection, each valve costs 5
- After all of the zones finished the first self-inspection, turn on the faucet a little bit to start test with
- During test of each valve, please check whether the water flows out or shuts off as expected.



* Refer to the user manual for details.

TIPS:

- Please activate the device before first use or after a period of inactivity.
- When testing, please keep away from the water timer outlet to avoid being splashed and wet.



Congratulations!

You have completed the installation of the timer. Now please refer to the user manual to begin programming your watering schedule.



5 steps to quickly program your watering plan

Turn the dial clockwise, from OFF to SET CLOCK to finish setting using buttons, and then set the plan in the order of START TIME \rightarrow HOW LONG → HOW OFTEN → ON. Use "+" and "-" buttons to adjust and OK to switch between hours or minutes. Turn the dial clockwise after setting to save the changes and go to next STEP for each setting.



TIPS:

- ITV305&ITV405 has multi zones, please follow the steps below to set ZONE 1 and then set the other zones using the same methods (use "ZONE" button to switch zone).
- Single Zone Operation: The device can only run one zone's program at a time, running multiple zones simultaneously will split and reduce water pressure. If there are conflicting programs, only one zone will execute while others wait for completion. More information please refer to the user manual.



Troubleshooting

Problem	Possible Cause	Possible Solution
The water inlet leakage	No filter or not be placed horizontally. The faucet is not the standard 3/4".	Add a filter and make sure it's placed horizontally in the inlet. Make sure the faucet is a standard 3/4" faucet. Wrap teflon tape on the faucet to make the connection tight.
The water won't stop/ flow out	Long time in storage and transportation make the valve inactive. Valve blockage.	Keep the faucet turned off and turn the timer dial to ON. Run the manual watering for 5-7s and stop it. Repeat the Step 2 for 3 to 5 times. Try using it normally.
Low water pressure	Filter blockage. Inlet pressure not sufficient to support watering needs.	Check if the filter is clogged, if so, clean or replace the filter. Make sure the timer is properly installed and not cross-threaded. Install a booster pump or other pressure increasing device.



Warrantv

RainPoint provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship.



Join Us For More Offers

Here are some gardening tips and tricks, as well as a lot of inspiration to help us become better gardeners.



Facebook: @Rainpointglobal YouTube: RainPoint













