

BE62CP

USER'S MANUAL

BLUETOOTH® | MP3-COMPATIBLE DIGITAL MEDIA AM/FM RECEIVER
FEATURING 6.2" (157 mm) CAPACITIVE TOUCHSCREEN

ELITE





Thank you for Choosing Boss Audio Systems!

IMPORTANT! Fill Out And Keep For Your Records.



IMPORTANT

Record the serial number of the product:

Model:

Serial Number:

Date of Purchase:

The serial number is located on the top part of the chassis.

Contents.....	2
Notes.....	4
Cautions.....	5-7
About this Manual.....	7
California Prop. 65.....	7
Basic Product Operation	8
What comes in the box.....	8
Product Basics.....	9-14
Using/Caring for the Touchscreen.....	12
Product Setup.....	13
Navigating the Menus.....	14
Apple CarPlay	15
Warnings.....	15
Using CarPlay.....	15
Gestures & Control.....	15

CarPlay Display.....	16
Disable Apps.....	16
Bluetooth®	17
Cautions.....	17
Setup & Connections.....	17
Phonebook.....	17
Device Status.....	17
Calling.....	18
History.....	18
Private Mode.....	18
Audio.....	19
Track Control.....	19

Media Player Source Switching.....	19
Media	20
Warnings.....	20
USB Playback.....	20
Navigating Menu.....	20
Photos.....	20
Radio.....	21
Display Overview.....	21
Controls.....	21
Tuning.....	21
Bands.....	21
Presets.....	21
Favorites.....	21

AV IN	22
AUX IN	22
Playback.....	22
Camera.....	22
Warnings.....	22
Reverse View.....	22
General Settings.....	23
Cautions.....	23
System Language.....	23
Time Zone.....	23
Date & Time.....	23
Auto Adjust Daylight Saving.....	23
System Tone.....	23
Power Off Delay.....	23
Parental Disc Lock.....	23
Audio.....	24
EQ.....	24
Balance/Fader.....	24
Subwoofer.....	24
Loudness.....	24

Internal Amp.....	24
Volume.....	24
Source level.....	24
Display Settings.....	25
Illumination Control.....	25
Gamma.....	25
Bluetooth® Settings.....	26
Device Name.....	26
Camera.....	26
Rear Camera input.....	26
Front Camera input.....	26
Rear View pelay.....	26
Radio Settings.....	26
Region.....	26
RBDS	26
Alternative Frequency (AF).....	26
Traffic Announcement (TA).....	26

Connections.....	27
Cautions & Warnings.....	27-32
Power/SWC	27
Speaker.....	28
Audio Pre-amp/AV IN/ Radio.....	29
Camera/USB/MIC.....	30
Parking Brake.....	31
Hands-free Mic.....	32
Troubleshooting.....	33
Specifications.....	35

This symbol with “WARNING” is intended to alert the user to the presence of critical instructions/procedures. Failure to observe the instructions/procedures can result in injury, death, damage to the product and/or property.



This symbol with “CAUTION” is intended to alert the user to the presence of important instructions/procedures. Failure to observe the instructions/procedures can result in injury or damage to the product and/or property.



Use of the Apple CarPlay logo means that a vehicle user interface meets Apple performance standards.

Apple is not responsible for the operation of this vehicle or its compliance with safety and regulatory standards. Please note that the use of this product with iPhone or iPod may affect wireless performance.

iPhone is trademark of Apple Inc., registered in the U.S. and other countries.

Apple CarPlay is a trademark of Apple Inc.

The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BOSS AUDIO Systems is under license.

Other trademarks and trade names are those of their respective owners.

Precautions

BE SURE TO OBSERVE THE FOLLOWING GUIDELINES: Do not turn up the volume so high that you can't hear what's around you.

Use caution or temporarily discontinue use in potentially hazardous situations.

Do not operate mobile video equipment while driving a motorized vehicle – safe driving and safety consideration of others should always be your highest priority.

Set your volume control at a low setting, then slowly increase the sound until you can hear it comfortably without distortion, or ear discomfort.

In the event you should notice smoke, strange noises or odor from this product, or any other abnormal signs, immediately turn off the power and consult your dealer or the nearest authorized **BOSS AUDIO SYSTEMS** Service Center.

Using this product in this condition may result in permanent damage to the system.

Installation Precautions

Boss Audio Systems does not recommend to install the product yourself.

We recommend to have it professionally installed by a certified professional.

Always consult with a professional installer .


Do not attempt to install or service this product by yourself. Installation or servicing of this product by persons without professional training and experience in electronic equipment and motorized vehicle accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards

Refer any repairs to a qualified BOSS AUDIO SYSTEMS Service Center

Before Installing

To avoid potential shorts in the electrical system, be sure to disconnect the (–) battery cable before installation.

Use this unit with a 12-volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.



Product Safety

It is against Federal and Local laws for video to be viewed by the driver while the vehicle is in motion. This video product was intended to be used with the parking brake safety feature. Video cannot be seen without the proper parking brake powered connection. Tampering or disabling this feature will void any and all warranty. Please check with a professional installer to have your product installed properly.



Important Note

Due to ongoing enhancements, example images on screens may slightly differ from actual product.

Images and Video

Watching video while driving is against Federal, State, and Local laws.

Drive safely, know and obey traffic rules. Watching this screen and making selections while driving can lead to a serious accident.

Check surroundings for safety while camera images are displayed.

Do not use features of this product while driving if it cannot be operated safely and legally in your location. Before operation of smartphone Apps accessible from this device, read safety instructions in your Owner's Manual. When using navigation Apps stay alert to observe real world conditions.

About this manual

To entirely understand how to properly use your new Boss product, it is recommended to read this entire user's manual, and keep it in a safe place for future reference.

- Read the entire manual
- Keep the manual
- Follow all instructions
- Clean with a dry cloth only
- Do not use or operate near water
- Do not defeat any safety features


California Residents (Proposition 65)

This product may contain chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

What comes in the box




Hardware

- Qty 1 BE62CP
- Qty 1 Trim Ring
- Qty 1 Mounting Hardware Set
 - M5 x 6mm Bolts (8)
 - Brackets (2)




Connections

- Qty 1 Power/Harness
- Qty 1 Hands-free Microphone



Front Detail



1 BAND Button

2 MODE Button


3 MENU Button

4 Power/Volume Control Knob

5 Voice Assistant

6 AUX IN/USB/SD/Reset Cover

Rear Detail



Product Basics

BAND

For radio band conversion between FM/AM

MODE


Press to select system mode.

MENU

Press to return to the home menu, or previous source.


Voice Assistant

press to command



Power/Volume Control

1. Long press to turn the unit ON or OFF.
2. Short press to mute or restore volume.
3. Rotate to increase or decrease volume.




Display Off

-Long press to turn off the display


Display On

-Touch the display to reactivate




Standby/ Power On

1. long press to Standby
2. Short press to Power ON



Using and Caring for the Touchscreen



Use:

This head unit utilizes a Capacitive Touchscreen, the same type that is used on high-end mobile devices. It should be used for and cared for like that type of device. As with all capacitive type technology, if your fingers are wet or sweaty, it will not function properly.

Do not allow any sharp objects to come in contact with the screen glass.

Care and Cleaning:

To clean the screen, use a dry microfiber type cloth to clean. Do not use ammonia, window cleaner, or any other type of household chemicals to clean the screen. Abrasives should not be used at all.

Product Setup (Date & Time)


Setup Option A: CarPlay Method

Connect your Apple ® device using a Lightning® cable*. The CarPlay USB port must be used.


This will automatically setup the time and date.

User must set Time Zone manually.

Default is Pacific Time Zone



Setup Option B: Date and Time




Additional Setup

General > Language

Audio > EQ, Other Audio Settings

Display > Illumination, Brightness

Navigating the Menus



Using CarPlay

Note

Apple CarPlay usage is limited while driving.

Functions, contents, and usability is determined by the App provider(s).

Controls will vary with each App that is available for CarPlay.

For more details visit:

<http://www.apple.com/ios/carplay>

WARNING

Familiarize yourself with your Local and State laws regarding mobile devices.

Certain functions of an iPhone might be prohibited and or illegal while driving in your location.

When in doubt, park the vehicle and engage the parking brake first before performing the function(s).

Connecting to CarPlay USB Port

1. Connect the CarPlay compatible device via LIGHTNING® cable (not included).
2. The iPhone will load the CarPlay function.
3. On the display, the CarPlay will illuminate green, touch it to enter the CarPlay menu.
4. To return to the product **Home** menu,

Touch



NOTE

The product's Bluetooth will turn **OFF** automatically when CarPlay is in use. Hands-free phoning will function through the CarPlay feature.

When using CarPlay, there is no need to pair your iPhone, the USB cable connected through the rear USB port will enable this feature.

If other devices are connected via Bluetooth, they will be disconnected for the duration of CarPlay use.

Gestures & Control

Basic controls, but not limited to:

Touch



Swipe



Dragging



Other gestures and controls might differ on each App.

NOTE

Volume control is handled exclusively by the product.

Using CarPlay

CarPlay Display Setup

1. Using your iPhone:


Settings > General > CarPlay


2. **Touch and Hold** each App icon to move.


To remove an App, **Touch** 



NOTE

Only Apps with the  icon can be removed from CarPlay.


Only Apps with the  icon can be added in carplay.



How to Disable Apps

1. Using your iPhone:

Settings > Notifications > App to Disable



Setup & Connection

Hands-Free Menu

Touch



NOTE

CarPlay must not be active. If being used, disconnect the iPhone to start Bluetooth.

Compatibility with all mobile devices is not guaranteed. Please read through the user's guide of the mobile device.

CAUTION

For your safety, the setup process should be accomplished while the vehicle is parked and parking brake engaged.

First time Pairing

Using your phone, media or other Bluetooth device, try to connect to this headunit.

Mobile Device:
Search for **BOSS AUDIO BE62CP**
iOS Devices: **Settings > Bluetooth**
Android Devices: **Settings > Connections > Bluetooth**


A passcode is generated and will display on both the head unit and mobile device for secure pairing.

Touch  to confirm

Every time the product is powered ON, the mobile device will automatically connect if within range.

NOTE

Once paired and connected, the device list will display the available Bluetooth profiles.



Phonebook and History

To **Download Phonebook**:

1. Touch **Contact > Download**

To **Download History**

1. Touch **History > Download**

Device Status

Battery and Cellular Strength is displayed on the top right of the Home menu.

GATT Profile support is required on the mobile device.



Hands Free

Calling

Making & Receiving Calls

1. Dialing from the dial pad


Touch  to make call


2. Contacts

Touch the contact name

3. History

Choose the name, then

To End a call Touch 

To Mute a call Touch 

Dial pad

To use the dial pad while on a call




Touch 

Searching History

Swipe Up or Down to search





History

1. Outgoing Call 
2. Incoming Call 
3. Missed Call 

Private Mode


When a call needs to be transferred to the mobile device:

Touch  to switch the mobile device

Touch  to return to hands-free mode

Searching Contacts

Contacts must be downloaded to search.

1. Touch 

2. Enter the Contact Name, then

Connection: **ON**

Auto Connect: **ON**

Auto Answer: **OFF**

Device Name: **BOSS AUDIO BE62CP**

Clear Records

Audio

Audio Streaming

To play media through Bluetooth, the mobile device must be **Paired and Connected** to the BE62CP

1. Touch



The music will play automatically.

Track Control

1. Play/Pause



2. Track Fwd / Rev



3. Swipe to Fwd/Rev



Note

For best performance, your mobile device volume setting should be set to maximum.

All volume adjustments for the system should be controlled from the product.

The unit will recall the last volume setting on your mobile device every time it connects.

Formats

Playback is supported from the mobile device with any format it can play.

Audio will only be played by the product.

Video cannot be viewed on the unit.

Switching Media

Touch



Available sources will display
(Bluetooth and USB)



Note

USB source will only be displayed if a USB drive is inserted and has playable media.

Display

Track info will be displayed when available.

Track, Album and Artist.

Album art is not supported via Bluetooth playback.

USB/SD

USB/SD Playback



The music will play automatically.

Audio Control

1. Play/Pause 
2. Track Fwd / Rev 
3. Repeat ALL 
4. Repeat One 
5. Random 



Note

If there are other files in the USB, music files will play first.

Video Control











1. Play/Pause 
2. Track Forward/Backward 
3. Repeat All 
4. Repeat one 
5. SETUP 

Photo Control

1. Play/Pause 
2. Track Forward/Backward 
3. Repeat All 
4. Repeat One 
5. Rotate 

Navigating Menu



To browse contents **Swipe**



To return to the current file playing,



Watching videos or photos while driving is against Federal ,State, and Local laws.

Do not use features of this product if it cannot be operated safely and legally in your location.



Note

Review the connections of this product, to properly integrate the parking brake wire to the vehicle.

Video and or photos cannot be viewed while driving. The vehicle must be stationary and the parking brake applied to enable viewing.

AM/ FM


Controls





Tuning


To search for stations:

Search

Touch and Hold  

Manual Seek

Touch  

Auto Search & Store: Touch 

 **Note**

RBDS info (if available) and currently tuned station will display on the radio icon in the home screen

Not all stations will have or display RBDS info.



Band & Settings

Touch FM to switch bands


To change radio settings

Touch 


Favorites and Presets


Settings Favorites

Touch  Favorite Set 

To remove a favorite, Touch 

Browsing Favorites



To return the Tuner screen Touch 

Changing Presets


Touch  

To list all Stored Stations

Touch 


Stereo/Mono

To turn on/off stereo when receiving a stereo signal ,

Touch 

LOC/DX

To select Local or Distant broadcasting stations,

Touch 

External Source

Playback

Touch



Media must be controlled from the external device.

Track functions are not controlled from the product.

Note

To adjust the volume level properly, the carry-in device volume should be set between 50 % - 75%. The volume level should remain at that level for the remainder of the time it is connected to the product.

WARNING

Never rely solely on the rear view camera; always check your surroundings before proceeding.

Images may appear reversed

Do not use features of this product if it cannot be operated safely and legally in your location.

Rear View

The rear view camera can be displayed on demand.

Touch



If the user opens the SETTINGS interface and turn on both FRONT CAMERA and REAR CAMERA functions, you can choose REAR CAMERA and FRONT CAMERA casually.



To return to the Home screen

Touch



Reverse View

When the vehicle is put into reverse gear, the camera will display the image on the screen.

CHECK SURROUNDINGS BEFORE PROCEEDING



Rear View Delay

Due to varying vehicle configurations, the rear view trigger can be delayed to best suit the vehicle.

Default setting: **0 Sec** Delay

Note

The rear view camera will still function normally, if the product is in standby mode

General

System Language

Touch to change

English (Default), Spanish



Note

CarPlay is independent of the system language setting.

Time Zone

Adjust to correctly display time

Default Setting: **(GMT-08:00) Pacific Time (US&Canada)**

Date & Time

24H Mode

Touch



Auto Adjust Daylight Saving

Touch



Note

If using an CarPlay, the iPhone will automatically set date & time. Time Zone needs to be adjusted manually.

System Tone

Touch



Power Off Delay

Some vehicles during crank to start will interrupt the accessory power.

If the product re-boots during crank to start, Turn **ON** delay

The delay can select 1, 2 or 3 sec.

Default Setting: **OFF**



Note

Power Off Delay **ON** will also delay when the vehicle is turned OFF.

This might affect hands-free functionality during a call.

Factory Settings

To restore settings to default:



CAUTION

Will restore all settings to factory defaults.

All settings and presets will be lost.

Audio

EQ

To access the EQ menu

Touch



Note

The EQ can also be directly accessed while changing the volume. The volume display will show the EQ icon, you can touch to access the Audio Settings.



Preset EQ

Jazz, HipHop, Pop,Rock, R&B

Balance/Fader

Left/Right Balance, Touch



Swipe for quick adjustment



Front/Rear Fader, Touch



Swipe for quick adjustment



Subwoofer

The level and filter can be adjusted for the Sub pre-amp output.

Level, 1-14 dB

Swipe



Filter: 50Hz, 80 Hz, 120 Hz, 160 Hz

Touch +/- Subwoofer Frequency

Loudness

Enhances and gently boosts low and high freq.

Touch



Internal Amp

To reduce the possibility of noise entering the signal chain when utilizing the audio pre-amp outputs, the internal amp can be turned OFF

Touch



Volume

Settings are for default volumes for Main(Radio, Media), Hands-free(BT Ring, BT Talking), Apple CarPlay/Android Auto (Navi, Voice).

Source Level

The source mode(Radio, USB, SD, BT Audio, AV Input, Apple carplay,AUX) gain control.

Illumination Control

When the vehicle lights are on, the products illumination can be customized for night use.

Gamma

Gamma can be adjusted for both day and night settings.

Screen Brightness**UI settings****Wall paper**

Touch to change

User can change the background picture by inserting a USB with photos.

Background brightness

**Connection**

Power On/Off Bluetooth

Default Setting: ON

**Note**

Bluetooth will turn **OFF** automatically when CarPlay is in use. If other devices are connected via Bluetooth, they will be disconnected for the duration of CarPlay use.

Auto Connect






Auto connects to the device when the product is powered ON

Default Setting: ON

Auto Answer

Auto answers when there is an incoming call.

Default Setting: OFF

Bluetooth	Camera	Radio
<p>Device Name BOSS AUDIO BE62CP</p> <p>Rear Camera input Turn on if you have a rear view camera, turn off if you have not.</p> <p>Front Camera Input Turn on if you have a front view camera, turn off if you have not.</p> <p>Parking Assist guide Turn off if your rear view camera have parking assist guide, turn on if you have not.</p> <p>Parking Assist guide Adjust You can adjust parking assist guide</p> 	<p>Rear View Delay 0 Sec (Default), 0.1 Sec, 0.5 Sec, 1 Sec, 2 Sec When switching from Park to Drive, or vice versa, the camera should not trigger on the display. Sensitivity should be adjusted to trigger only on reverse gear selector.</p> <p>Region Touch </p> <p>Default Setting: USA 2 US Tuner Spacing: FM (200 KHz), AM (10 KHz) European Spacing: FM (50 KHz), AM (9 KHz)</p> <p>RBDS, Radio Broadcast Data System Touch </p> <p>Default Setting: ON Allows data from the radio station to be displayed on the product.</p>	<p>RBDS, Cont'd Not all stations will broadcast information to display.</p> <p>AF (Alternative Frequency) Touch </p> <p>When On, the tuner will automatically locate the same tuning program on other stations and select the strongest signal of those being broadcast. Default Setting: OFF</p> <p>TA (Traffic Announcement) Touch </p> <p>The radio will automatically tune in to traffic information broadcasts while receiving FM broadcasts playing media. Default Setting: OFF</p>

Power/SWC

CAUTION

It is recommended to have the product installed by a certified installation professional.


CAUTION

Before installation, or wiring connections, disconnect the negative (-) battery terminal to prevent damage to the product, and/or possible injury.




CAUTION

Remote Out is 500 mA max output rating. If several amplifiers are to be used, it is recommended to use a relay for the Remote Out trigger.



Note

Unused input/output wires need be insulated with tape, heat shrink, or crimp connectors. **Never use wire nuts.**



Location to plug in

Note

A separate interface might be needed for your vehicle application. It is recommended that you consult with a professional installer.

Note

When replacing the fuse, always do so with the same type and value (**15 A**).

Speakers

CAUTION

Do not chassis ground any speaker wire leads.

CAUTION

Only use 4-8 Ω Speakers

Do not use 1-3 Ω Speakers

CAUTION

Do not bridge any of the channels, they are only to be wired in stereo mode.

Note


Unused speaker wires need be insulated with tape, heat shrink, or crimp connectors.

Never use wire nuts.

If the speaker outputs are not used, turn **Off** the internal amp to reduce the possibility of noise entering the signal chain.

Note

Observe speaker polarity when making connections.




Audio Pre amp/AV IN/ Radio

Note

Subwoofer Pre-amp is a non-fading mono output.


Note

Always run signal wires away from power cables to reduce the possibility of noise.



Note

If pre-amp outputs are being used exclusively, turn **Off** the internal amp of the product, to reduce the possibility of noise entering the signal chain.



Location to plug in

Camera/USB/MIC





WARNING

Never rely solely on the rear view camera; always check your surroundings before proceeding.

Images may appear reversed

Do not use a feature of this product if it cannot be operated safely and legally in your location.



Parking Brake

WARNING

Improper connection or use of the parking brake status wire, (i.e. defeating the safety feature) violates Federal, State, and Local laws. This may lead to injury, property damage, and/or death.

WARNING

Watching videos or photos while driving is against Federal, State, and Local laws.

Note




For Android Auto setup, the parking brake status wire **MUST** be connected.



Note

Review the connections of this product, to properly integrate the parking brake wire to the vehicle.

Video and or photos cannot be viewed while driving. The vehicle must be stationary and the parking brake applied to enable viewing.



Power/Speaker/SWC Harness

Note

The parking brake input needs to be connected to the power side of the parking brake.

Note

Every vehicle has a different type of parking brake connection; consult a certified professional installer.

Hands free Mic

Placement

Every vehicle will perform differently due to layout, interior materials, etc...

The **Red** shaded areas are the recommended locations for best microphone performance.


Items to look for before placement:

1. Do not place in front of air vents.
2. If the vehicle has tweeters placed on sail panels, do **NOT** locate the mic on steering column area.
3. Front of mic must not be blocked.
4. Mic should be firmly attached to mounting location.
5. Do not cover the grille openings surrounding the mic.
6. To avoid excessive wind noise, do not place near the sunroof opening



WARNING

Run microphone wire where it will **NOT** impede the operation of any safety items, i.e. Airbags, Knee Airbags, etc...



Issues	Cause	Solution
No Sound	Internal amplifier is off Product is muted External amplifiers Audio source	Go to Settings > Audio > Internal Amp ON Touch the volume. Check the external amplifiers are on. Check the remote output wire has voltage Change the audio source
Media Not Supported	Media on the USB device/SD card	Change the media format on the USB device/SD card Change the USB device/SD card
Bad Radio Reception	Radio area Antenna	Change the station Turn OFF AF and TA Turn OFF RBDS Antenna output wire sn't connected Connect Antenna to product
Apple CarPlay	Bad Lightning®/USB cable Locked device Not charged CarPlay	Replace the cable Device needs to be unlocked Device needs to be powered ON for CarPlay/ Allow it to charge and power on. Unplug the device, close all Apps and plug it in again.
Bluetooth	Not connecting to device	Make sure the device is within range. Devices' Bluetooth connection needs to be turned ON

Issues	Cause	Solution
Bluetooth	Not connecting to device	Go to Setting >Connection >Power ON Pair and Connect the device like new.
Hands-free call quality	Mobile device Microphone	Check cellular strength on mobile device. End call and redial number. Microphone placement needs to be relocated. Microphone needs to be firmly attached to location it's mounted on. Check to see if microphone is properly plugged in.
Unit is unresponsive	Processor has frozen	Restore the factory settings. Use a small pin to press the reset button on the front panel.



If you have questions about this product:

Customer Service

805-751-4853

M-F 8:30a-5:00p (PST)

Tech Support: www.bossaudio.com/support/technical-support

© 2021 Boss Audio Systems

General

Power Input.....	8.5 V—18 V DC
Nominal.....	14.4 V DC
Current Consumption.....	15A
Fuse Type.....	15A
Dimensions (H x W x D).....	3.8"x6.71"x3.56"
Head Unit Weight.....	1.75 lbs.
Operational Temperature.....	-4—158°F

Display

Screen Size.....	6.2"
Aspect Ratio.....	16 x 9
Resolution.....	800*480
Screen Type.....	TFT-LED Active Matrix

Audio

Max Power.....	80 W x 4 Ch.
Acceptable Speaker Load.....	4-8 Ω
Preset EQ.....	5
JAZZ, HIPHOP, POP, ROCK, R&B	
EQ Bands, Adjustable.....	10
32, 63, 125, 250Hz, 500Hz	
1KHz, 2KHz, 4KHz, 8KHz, 16KHz	
EQ Boost/Cut.....	\pm 6 dB

Audio Cont'd

Pre-amp Output.....	3 Pairs
Front.....	4V, Full-Range
Rear.....	4V, Full-Range
Sub (Mono).....	4V, LPF
Sub LPF.....	50 Hz, 80 Hz, 120 Hz, 160 Hz
Sub Level.....	+1-14dB

Radio Tuner

Freq. Range.....	87.5 MHz-108 MHz (FM)
Freq. Range.....	522 kHz-1710 kHz (AM)
USA 1 Range (FM).....	100 kHz Spacing
USA 2 Range (FM).....	200 kHz Spacing
Europe Range (FM).....	50 kHz Spacing
RBDS.....	AF, TA

Apple CarPlay

iPhone Support.....	iPhone 5 or Newer
iOS.....	iOS 7.1 or Newer

USB/SD

USB Spec.....	USB 2.0 (High-Speed)
Rear USB port:	Carplay& 1.5A Charging
Current Output	1.5A
Front USB Port :	Media & 1.5A Charging.....
Current Output	1.5A
File System.....	FAT32
Audio Playback.....	WAV, MP3
Video Playback.....	AVI, MKV, WMV
Picture Playback.....	JPG, PNG, BMP

*Not all listed compressed files guaranteed to play due to different creation methods or file contents.

Bluetooth®

Version.....	v4.2+E.D.R.
Audio Codec.....	S.B.C.
Profiles.....	
HFP v1.6,A2DP v1.2,AVRCP v1.5,PBAP v1.1	

ELITE

BOSS Audio Systems
3451 Lunar Court • Oxnard, CA 93030
www.bossaudio.com
805-751-4853 Customer Service
Tech Support: www.bossaudio.com/support



0221

iPhone® is a trademark of Apple Inc., registered in the U.S. and other countries. Apple CarPlay is a trademark of Apple Inc. BOSS Audio Systems is not affiliated with Apple Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BOSS Audio Systems is under license. Other trademarks and trade names are those of their respective owners.

Use of the Apple CarPlay logo means that a vehicle user interface meets Apple performance standards. Apple is not responsible for the operation of this vehicle or its compliance with safety and regulatory standards. Please note that the use of this product with iPhone may affect wireless performance.

ELITE

ELPC40B USER MANUAL

**REAR VIEW LICENSE PLATE
MOUNT CAMERA**

FEATURING HIDDEN MOUNTING BRACKET



Introduction

This camera is designed for use as a front view or rear-facing backup camera, and mounted neatly behind your license plate. When installed with any of our camera-capable head units, the camera view can be automatically triggered when shifting into reverse or manually triggered by selecting the camera button from the head unit home screen.

Package Contents

- 1x Camera with power and video sockets
- 1x Power cable with power plug
- 1x Video cable with two yellow RCA plugs
- User manual

Important

Please read and understand all instructions before you use your product. Failure to follow the instructions could result in injury and/or damage that could potentially void the warranty.

Important safety precautions

- Use of the camera must not replace other safe driving habits. Precise control and looking around before backing up is necessary.
- Always remember that the area displayed by the camera is limited, and certain obstacles may not be detected or not reliably detected.

Installation precautions

- **WARNING:** Always consult a professional installer.
- Improper wiring and mounting of the camera can cause damage, injury or accident. Have installation performed by a professional only. Contact our technical support for any installation questions.
- Disconnect the negative terminal of the vehicle battery prior to wiring.
- When making modifications to your car due to the installation, make sure the safety and structural integrity of the car is not impaired.
- Hide wires under car floor mat or through car headliner. Make sure wires are not squeezed or damaged by sharp edges. Use rubber bushings for penetrations.

Wiring

- Follow two steps described below to install this product as a front camera or a rear camera.
- The rear camera view automatically turns on when reversing. Ensure you connect the **"Reverse Input"** wire on your head unit to the vehicle's reverse light for reverse trigger. Front camera view is not accessible when reversing.
- Both rear and front camera view can be selected via Home screen options on your head unit.

1. Connect the video cables.

- a** Connect one yellow RCA plug of the video cable to your head unit.

Front camera: to **"Front Camera Input"** RCA socket.

Rear camera: to **"Rear Camera Input"** RCA socket.

- b** Connect the other yellow RCA plug of the video cable to the yellow RCA socket on the camera.

2. Connect the power cables.

- c** Connect the red split wire of the video cable to your head unit.


Front camera: to **"Front Camera Power Output"** wire.

Rear camera: to **"Rear Camera Power Output"** wire.

- d** Connect the other red split wire of the video cable to the red wire of the power cable.

- e** Connect the black (ground) wire of the power cable to the car chassis.


- f** Connect the black plug of the power cable to the red socket on the camera.



Mounting

The camera is designed for mounting behind the license plate of your car through the screw holes on the license plate. No drilling hole is required.

1. Remove the license plate lamp. Through the opening of the license plate lamp, run the camera's cable from the outside into the inside of the car.
2. Remove the license plate screws. Align the camera frame with two top screw holes on the license plate, and secure the camera frame with two license plate screws. **Make sure the camera is correctly oriented to avoid reverse image.**



3. Verify the camera angle is properly positioned. If needed, loosen the screws and adjust the camera angle then re-tighten the screws.

Troubleshooting

Problem	Solution
No image	Ensure the camera's power cable is securely plugged. Ensure there is correct and secure wiring between the camera and your head unit. Ensure the reverse input wire on your head unit is connected to the vehicle's reverse light. Ensure correct camera settings on your head unit.
Image blurry	Check for water drops or dust on the camera lens. Clean it with a damp, fiber-free cloth.
Image shaking	Ensure the camera is tightly mounted.
Image slanted	Adjust the camera frame position.

Image Setting

- To remove the on-screen parking guidelines, cut open the white wire loop which splits from the camera's cable. Otherwise, keep the white wire loop uncut.
- If the camera image appears reverse, cut open the blue wire loop which splits from the camera's cable. Otherwise, keep the blue wire loop uncut.
- Make sure to unplug the power cable from the camera and plug it again to enable the new setting (after cutting off the white or blue wire loop).

Specifications

Power supply	12 VDC
Viewing angle	170°
TV system.....	NTSC
Video output	1.0 vp-p, 75 Ω
S/N ratio.....	≤45 dB
Ingress protection rating	IP67 (waterproof)
Operating conditions.....	-22 to +140°F (-30 to +60°C) max. 95% RH
White balance.....	Auto
Illumination	min. 0.1 lux
Automatic gain control (AGC).....	Auto
Resolution (TV lines)	480
Electronic shutter speed	1/60 (NTSC)
Effective pixels.....	648 x 488
Dimensions (L x W x H).....	7.756" x 0.88" x 0.88" 197 x 22 x 22 mm
Cable length	197"/5m (video cable); 39"/1m (power cable); 20"/0.5m (camera's cable)

Specifications are subject to change without notice.

ELITE

BOSS Audio Systems
3451 Lunar Court • Oxnard, CA 93030
www.bossaudio.com
805-751-4853 Customer Service
Tech Support: www.bossaudio.com/support



0523

Boss ELPC40B camera connected
to the Boss BE920WCPA-C radio

Connect the **Purple/White reverse wire** on the **BE920WCPA-C** harness to the vehicles reverse wire to switch the radio to the cameras picture automatically.

Line up the **Arrows and Grooves** on the connectors when connecting the **Video cable** to the **Camera cable**.

Connect the **ELPC40B** video cables **Red wire** to the **Red/White "Rear Cam Power Out"** from the **BE920WCPA-C** radio harness.

