

Getting Started With Wonderboom 3

POWER

To get started with your WONDERBOOM 3, press the power button located on the top of your speaker. When powered on, WONDERBOOM 3 automatically reconnects to the last mobile device it was connected to.

WONDERBOOM 3 will automatically turn itself off after 15 minutes of inactivity to save battery life.



To pair WONDERBOOM 3 with your mobile device, press and hold the Bluetooth button until you hear the tone.

Go to the Bluetooth settings on your mobile device and select WONDERBOOM 3 from the list.



PLAY MUSIC

Once WONDERBOOM 3 is on and connected to your mobile device, just hit play to begin streaming your music.

You can control the volume from your mobile device, or directly from your WONDERBOOM 3 by pressing the "+" or "-" button.



CONTROL MUSIC

You can control the music directly from your WONDERBOOM 3 without picking up your phone. To pause the stream, simply press the center button located on the top of the speaker. Press it again to resume playing. Double press the button will skip to the next track.





CHARGE

To charge your WONDERBOOM 3, plug the included USB cable into the micro-USB port located inside the weather door.

Warning:

A wet or contaminated micro-USB connector may cause excessive heat or melting and may lead to fire damage or personal injury. Always charge your speaker with a clean, dry micro-USB connector.



BATTERY LEVEL

You can check the battery level of your WONDERBOOM 3 by pressing both the volume + and volume – buttons simultaneously.



If you hear this tone, it means that your WONDERBOOM 3 is roughly half full (or half empty).

{audio clip}

If you hear this tone, your WONDERBOOM 3 is running low on power and needs a charge.

{Audio Clip}



DOUBLE UP

Connect two WONDERBOOM 3 together for a bigger sound. PRESS AND HOLD the center button on 1 speaker and wait for the sonification. While holding the center button on speaker 1, press the center button on speaker 2 until you hear a pairing tone.

{Sound clip}

You could easily switch between 'Party Louder' mode and 'Immersive Stereo' mode by pressing the center button.

Press the Bluetooth button of one of the two speakers to leave the DOUBLE UP mode.


If you hear this confirmation tone, it means that you are in double sound mode.

{sound clip}

If you hear this confirmation tone, it means that you are in stereo mode.

{sound clip}





MULTI-HOST

WONDERBOOM 3 can simultaneously connect with up to two Bluetooth mobile devices.

Simply pair and connect each mobile device to WONDERBOOM 3, then you can take turns playing music from each device.

Still Need help?

Our agents are here to help Monday -Friday from 7 AM - 5 PM PST. With two ways to contact us, communicate in the way that you like best!



CALL US



EMAIL US



Shop

HYPERBOOM

MEGABOOM 3

BOOM 3

myBOOM 3

WONDERBOOM 3

RETAILERS

Hours

Monday - Friday

7:00AM - 5:00PM PST

Learn

Press

Recycling

Heritage

Helpful Info



[Web Privacy Policy](#)

[Terms Of Use](#)

[Warranty](#)

