

PR[◀]AIM Low Ninja Baby 5/8" Double Riser Stand (TP-LNJB-01)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Low Ninja Baby Stand


All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Low Ninja Baby Stand Setup

- Loosen the knob of the Low Ninja baby stand and spread the legs of the stand equally.

NOTE: The stand collapses easily to an extremely small size, making it ideal for both storing and traveling.




- After spreading the legs, properly tighten the knob of the stand.

NOTE: The Baby Stand is equipped with leveling leg for balancing loads on an incline or uneven terrain & you can glide your stand comfortably as the feet have rounded plastic capping to them.



- Loosen the top knob of the Low Ninja stand and increase the height of the stand, as shown in the image.



- After increasing the height, properly tighten the knob.



- To increase the extra height of the stand, loosen the bottom knob and increase the height.



- Set the stand's height according to your requirement.

NOTE: The stand rises to a maximum height of 39.8" / 101.1 cm and can go as low as 22.2" / 56.5 cm with built-in solid locks to steady the stand's height.



NOTE: It is a 3-section, double-riser stand with a foot base, collapsible legs, and a middle-level spreader, which offers excellent steadiness for your lighting equipment indoors and outdoors



- Loosen the knob of the levelling leg to properly balance the stand and then again tighten the knob.

NOTE: The Baby Stand is equipped with leveling leg for balancing loads on an incline or uneven terrain & you can glide your stand comfortably as the feet have rounded plastic capping to them.




Light Setup

- Light ki knob ko loose krain or low ninja stand par mount krain.



- Light mount karne ke bad knob ko properly tight kar dain.

NOTE: The 5/8" baby pin on the top allows you to mount studio equipment like lights, reflectors, backgrounds, & even a Camera Stabilizer System & Gimbals with support accessories.



NOTE: 1. Low Ninja Baby Stand, offering the ultimate solution for supporting heavy fixtures or any grip equipment low to the ground.
2. This Baby Ninja stand is perfectly balanced to mount heavy fixtures, boom, or studio lights at incredibly low angles, offering solid support in the studio and easy transportation to locations shoots.



YOUR PROAIM LOW NINJA BABY DOUBLE RISER STAND ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.