


Certified	Version
Model	Model
Q7	7-Riders



৭ www.ejeas.com

## **Product Details**




## **SafeRiding APP**

The SafeRiding App allows you to set up your group and stay connected with your friends. Save time and enjoy your adventure even more! You can also see more product operations precautions and multiple language operations! Download the EJEAS SafeRiding App for Android and Apple operating systems from ejeas.com/support.




# **Product Installation**



# **Product Operations**

## **Operation Diagram**



## **Basic Operations**


Power ON/OFF Please charge it before using.




## **Battery Level**




## Low Battery Indication



## **Charging Indication**



Volume Control FM and intercom can be used at the same time.



## **Factory Reset**




Long press the <Volume +>, <Volume ->, <Phone Button> for 5s at the same time.

- Red light quick flashes three time, blue light flashes once
- ? "Restore Default Setting"

### **Bluetooth Intercom**

### Two-Intercom Pairing



- 1 Long-press <A Button> for
  - Red and blue lights flash fast alternately
  - Intercom A Pairing

Searching and paring.

Paring successfully.


▼ Blue light flashes simultaneously
② "Intercom Pairing Successful"


Connected, start communication.

? "Intercom A Connected"

### Multi-Intercom Pairing (3-7 models)


All the following voice prompts refer to the host.






(Recommend marking all the intercom for easy switching)


## Intercom Switching Only the Host allows to switch.




#### Intercom Disconnection



#### Compatible with Old Intercom Pairing



- 1 Long press < A Button> for 5s, while V4/V6 enter the pairing mode.
  - Red and blue lights flash fast alternately
  - Intercom A Pairing



- (2) Click < A Button> enter Bluetooth search mode.
  - Red and blue lights flash twice alternatively
    - Intercom A Searching

### - Paring successfully.


- Blue light flash fast
- Intercom Pairing Successful

## Connected, start communication.

? "Intercom A Connected"

## **Bluetooth Pairing**

### **Phone Pairing**



Bluetooth Q7

- Long press the <Phone Button> for 5s to enter the pairing mode. (If no phone connected, it will exit pairing mode after 2 mins)
  - Red & blue lights flash fast alternately Phone Pairing"
- Open your phone's Bluetooth, search and pair with the device.




- Blue light twice flashes slowlyPairing Successful, Connected
- \*

Current power will be shown on your phone.

(Phone must support HFP)

#### **Phone Reconnection**


Automatically connect back to the last paired.



### **Mobile Phone**

#### Answer a Call

Auto answering within 8s if no any operation.



#### Reject a Call



## Last Call Replay



## End a Call




TEL Priority When listening to music/FM/intercom, and receiving a phone call.



#### Voice Assistant

Phone must support & open the voice assistant (Google assistant & Siri).



## **Music Control**

# Music Play/Pause



# Music Switching





#### **FM Radio**

#### FM ON/OFF 76~108MHz

Auto search and radio, intercom and radio could working at the same time.



#### Long press <FM Button> for 1s to open the FM.

- → Blue light is always on for 4s
  - Red light double flashes quickly

? "FM Radio"

Long press <FM Button> for 1s to close the FM.

9 "FM Radio Off"


### Frequency Switching





#### Music Share


Share the music played by Bluetooth on your phone to another device, and this function cannot be used during Bluetooth intercom. This function cannot be used when two phones are connected simultaneously.



Take an intercom as the host. connect it to the phone, and the other one is the slave.


After the connection is successful, play the phone music of the host, and the music can also be played from the speaker.

3 "Music Share Connected"



Press the <Phone/Power Button>+<Volume -> at the same time between the host and slave to enter the music sharing search connection

state. ? "Music Share"



Press the <Phone/Power Button>+<Volume -> again to exit music sharing. ? "Music Share Disconnected"

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equi pment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does caus harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliancecould void the user's authority to operate the equipment. This device complies with Part15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

Pairing operation with EUC handle, please scan the code to view the corresponding manual.

