


# Sunco

Lighting made better.

User Manual

## Lux Solar Garden Light

SKU: GD\_MD\_SR-BK-2740K




support@sunco.com  
(844) 334-9938




# What's in the Box?

## Solar Sidewalk Light




Let there be light!  
(literally)



**A**

**x1**


Light



**B**

**x2**

Light Pole



**C**

**x1**

Ground Stake

# Before You Start

## Safety Information

To reduce the risk of fire or physical injury:

- Suitable for outdoor environments ranging from -4°F to 104°F.
- Do not cover the fixture with thermally insulating material.
- Not intended for use with emergency fixtures.
- Not compatible with occupancy sensors.
- Not compatible with dimmers or timing devices.
- Not compatible with third party sensors.
- All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards.
- Please review installation manual carefully before proceeding. Consult a qualified electrician if you are unfamiliar with proper installation.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference that may cause undesired operation. Please review all instructions carefully prior to installation.

### WARNING:


Cancer & Reproductive Harm-  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

## Quickstart Guide



### Step 1

Connect light poles and ground stake.




### Step 2

Connect the light pole to the light. Press Power button to toggle CCT and brightness.



### Step 3

Allow light to charge in sunlight before operation.




### Step 4

Battery can be removed by unscrewing the cap from the light.


# Installation Guide

## STEP 1



- Remove accessories from packaging.
- Connect the light poles (B) and the ground stake (C).


## STEP 2



- Connect the light pole (B) to the light (A).
- Press the Power button to turn the light on. Continue pressing the Power button to toggle between color temperatures and its selectable brightness.


## Installation Guide (Cont.)

### STEP 3




- Once fully assembled, place the light into desired location.
- This location should have clear access to sunlight and kept away from other sources of light that could interfere with the sensor.

### STEP 4



**Note:** To replace the rechargeable battery, unscrew the cap from the light and replace the battery.

## Product Details



## Specifications

<b>Voltage</b>	3.7V	<b>Lifetime</b>	25,000 Hours
<b>Wattage</b>	2W	<b>Lumens</b>	120 lm
<b>Battery</b>	500mAh 3.7V	<b>CRI</b>	70+
<b>CCT</b>	2700K , 3000K , 4000K	<b>Usage</b>	Outdoor
<b>Material</b>	ABS	<b>Warranty</b>	1 Year
<b>Beam Angle</b>	120°	<b>Battery Included</b>	Yes
<b>Dimmable</b>	Selectable Brightness	<b>Efficacy</b>	130 lm/W

# Common Troubleshooting

We've got you covered! Our troubleshooting section is here to shed some light and provide you with easy-to-follow solutions for any problem.

If you still need some assistance, feel free to contact us. Our team of lighting experts are happy to help brighten your day.

## Installation

Light isn't turning on.

Allow the light to fully charge in sunlight before operation.

## Turned On

Light doesn't turn on when Power button is pressed.

Allow the light to fully charge in sunlight before operation.

## Clean Panel

Light doesn't turn on when power button is pressed.

Verify the solar panels are free of dust, dirt, or debris. Debris on solar panels can reduce their efficiency.

## Location

Light isn't turning on in certain locations.

Check for any obstructions or damage on the light.

# Sunco

Lighting made better.

support @sunco.com  
(844) 334-9938

REV 20