




10 TRUE WIRELESS
STEREO

Quick Guide

1

Bluetooth pairing and wearing



Bluetooth pairing

1. Pick up two earbuds from charging case, and they will power and pair to each other automatically within 10 seconds.
2. One of the earbuds red and blue light blinking alternately.
3. Selecting the [TOZO T10] from device list in your bluetooth manual.



Select your fit

Wearing

1. Ensure the eartip facing downwards, then place the earbuds into your ears.
2. Rotate the earbuds back to the auricleside to fit snugly.

*Eartip facing upwards is the incorrect way to wear the earbuds.



Insert



Twist to lock



Wrong demo



Correct Wearing



- 1 Ensure the eartip facing downwards.
- 2 Rotate the earbuds back to the auricleside to fit snugly.



Wrong Wearing



- * Eartip facing upwards is the incorrect way to wear the earbuds.



Smart touch control

EN | JP | DE | FR | IT | ES | NL | SE

X1: Press once **X2:** Press twice **X3:** Press three times **Hold:** Press and hold for 2 seconds

X2 



Previous song | 前の曲 |

Vorheriges lied | Chanson Irécédente |
Canzone precedente | Canción anterior |
Vorig nummer | Föregående låt

X2 



Next song | 次の曲 |

Nächstes lied | Chanson prochaine |
Canzone prossima | Canción siguiente |
Vorgende nummer | Nästa låt

Hold 



Volume down | 音量を下げる |

Lautstärke runter | Baisser le volume |
Volume basso | Bajar volumen |
Volume verminderen | Sänk volymen

Hold 



Volume up | 音量を上げる |

Lauter | Monter le son |
Alza il volume | Sube el volumen |
Volume omhoog | Høj volymen

X1 



Play/Pause | 再生/一時停止 |

Spielen/Pause | Jouer/Pause |
Giocare a/Pausa | Tocar/Pausa |
Toneelstuk/Pauze | Spela/Paus

X1 



Answer | 答え |

Antworten | Réponse |
Rispondere | Responder |
Antwoorden | Svar

Hold 



Hang up | 電話を切る |

Auflegen | Raccrocher |
Appendere | Colgar |
Ophangen | Lägga på

Hold 



Reject | 拒絶 |

Ablehnen | Rejeter |
Rifiutare | Rechazar |
Afwijzen | Afvija

X3 



Activate the voice assistant | 音声アシスタントをアクティブにする |

Aktivieren Sie den Sprachassistenten | Activer l'assistant vocal | Attiva l'assistente vocale |
Activar el asistente de voz | Activeer de stemassistent | Aktivera röstassistenten



3

Power on/off

EN Power on :

Take out the earbuds from the charging case;
or press and hold 3 seconds.

Power off :

Place the earbuds back into the charging case;
or press and hold 5 seconds.

DE Ein :

Nehmen Sie die Ohrhörer aus dem Ladekoffer;
oder 3 Sekunden gedrückt halten.

Ausschalten :

Legen Sie die Ohrhörer wieder in das Ladeetui;
oder 5 Sekunden gedrückt halten.

IT Accensione :

Estrarre gli auricolari dalla custodia di ricarica;
oppure tieni premuto per 3 secondi.

Spegni :

Rimetti gli auricolari nella custodia di ricarica;
oppure tieni premuto per 5 secondi.

NL Aanzetten:

Haal de oordopjes uit de oplaadcassette;
of houd 3 seconden ingedrukt.

Uitschakelen:

Plaats de oordopjes terug in de oplaadcassette;
of houd 5 seconden ingedrukt.

JP 電源オン :

充電ケースからイヤフォンを取り出します。
または、3秒間押し続けます。

電源を切る :

イヤフォンを充電ケースに戻します。または、
5つのセンコンドを押し続けます。

FR Allumer :

Sortez les écouteurs de l'étui de chargement;
ou appuyez et maintenez 3 secondes.

Éteindre :

Remettez les écouteurs dans l'étui de chargement;
ou appuyez et maintenez 5 secondes.

ES Encendido :

Saque los auriculares del estuche de carga;
o mantenga presionado 3 segundos.

Apagado :

Vuelva a colocar los auriculares en el estuche de
carga; o mantenga presionado 5 segundos.

SE Ström på :


Ta ut öronsnäckorna från laddningsfodralet;
eller tryck och håll ned 3 sekunder.

Stäng av :

Sätt tillbaka öronsnäckorna i laddningsfodralet;
eller tryck och håll ned 5 sekunder.

4


Reset



If you Accidentally get only one earbud work, or fail to pair each other, please reset it:

1. Delete all [TOZO T10] Bluetooth records on the phone, then turn off the Bluetooth.
2. Pick up two earbuds from charging case, then clicking the both earbuds twice quickly.
3. The reset will be done when the blue light flashes rapidly, and then one of the earbuds red and blue light blinking alternately.

NOTE: In case there is connection unsuccessful in your devices; please delete all historical records of [TOZO T10] and try the paring process again.



5

Charging



Place the case upright on the wireless charger.
(Wireless charging pad not included)

Or charge the case via USB-C connector.
(USB-C cable included)

* * * * 0~25%

* * * * 25%~50%

* * * * 50%~75%

* * * * 75%~100%



Don't put wet earbuds into the
charging case, fully dry off the
earbuds before charging.



Don't place the case face up
or face down.

Thank you for purchasing the TOZO authentic product.
For more latest products, parts and accessories,
please visit: **www.tozostore.com**
For any assistance please contact Email: **info@tozostore.com**

