



Original	Recharge	Original	Recharge
	Power		Power
	Sleep		Sleep / Timer
	Program		TV/Radio /
	Cancel		Exit / Cancel / Clear
	1		1
	2		2
	3		3
	Disc		Shift + 2
	4		4
	5		5
	6		6
	+10/-/-		Guide / EPG / -/-
	7		7
	8		8
	9		9
	0		0
	EQ		Subtitle / EQ
	Up		Up
	Left		Left
	3D AI		Picture / Format
	Right		Right
	CH Select		Smart / List
	Down		Down
	AV Effect		AV / Input / RDS
	Test		Text / Goto
	Pro Logic		Audio / Lang I/II
	Super Surround		Eject / Surround
	Simulated Stereo		Sound / Title
	VCR/AUX/6CH		Shift + 7
	Tape/Deck 1/2		Shift + 5
	CD		Shift + 3
	Tuner/Band		Shift + 6
	Pause / Step / Freeze		Pause / Step / Freeze
	Stop		Stop / Hold



