

Wireless Audio Receiver & Transmitter BT 5.0

Gebruikershandleiding 



Bedankt dat je gekozen hebt voor Brightside
Lees altijd voor gebruik de handleiding
aandachtig door voor een correcte en
veilige werking van het product.

Nederlands


SPECIFICATIES

Bluetooth versie	V5.0
Speeltijd	4h
Bluetooth bereik	Tot 10M in openruimte
Batterij capaciteit	140mA
Oplaadtijd	1h
Product afmeting	59,5 (L) x 22 (B) x 12 (H) mm

INHOUD VERPAKKING

- 1x Brightside C28 Wireless Audio Ontvanger & Zender
- 1x USB-A naar micro-USB oplaadkabel
- 1x 3,5 mm jack (m) - 3,5 mm jack (m) stereo koppelstuk
4. Gebruikershandleiding

PRODUCT DIAGRAM




Bediening met één knop

Schakel eenvoudig tussen zender- (TX) & ontvanger (RX) modus.

INTERFACEDIAGRAM

1. Multifunctionele knop (aan/uit/afspelen/pauze)
2. Aux-ingang/-uitgang
3. Zender en ontvanger schakelaar
4. Microfoon
5. Indicatielampje
6. 5V/1A micro-USB-oplaad-poort



HOE TE GEBRUIKEN

Ontvanger modus

1. Gebruik de micro-USB-kabel om de C28 op te laden voor gebruik. Tijdens het opladen gaat het indicatielampje (5) rood branden;
2. Sluit de C28 aan op je audioapparaat via de AUX-poort (2);
3. Zet de schakelknop (3) in de RX-stand;
4. Zet de C28 aan door de multifunctionele knop (1) ingedrukt te houden. Het blauwe lampje zal snel knipperen om aan te geven dat de C28 gereed is om te koppelen.
5. Zoek de C28 in de draadloze zoekfunctie van uw apparaat en kies om te koppelen. Als de verbinding tot stand is gebracht, zal het indicatielampje (5) blauw branden.

Zender modus

1. Gebruik de micro-USB-kabel om op te laden voor gebruik. Tijdens het opladen gaat het indicatielampje (6) rood branden;
2. Sluit de C28 aan op uw audioapparaat via de AUX-poort (2);
3. Zet de schakelknop (3) in de TX-stand;
4. Zet de C28 aan door de multifunctionele knop (1) ingedrukt te houden, waarna het rode lampje snel knippert om aan te geven dat de C28 gereed is om te koppelen;
5. Zet het apparaat aan waarmee je verbinding wilt maken en de C28 zal automatisch verbinding maken. Als de verbinding tot stand is gebracht, zal het indicatielampje (5) rood branden.

Ontervind je problemen met de installatie of heb je andere vragen, neem dan gerust contact met ons op. Dit kan direct via onze contactpagina: www.brightsideonline.nl



krijg 10% korting!
Met de code: BSO-BTA-10

Engels

Wireless Audio Receiver & Transmitter BT 5.0

User manual 



Thankyou for choosing Brightside

Always read the manual carefully before
using, for correct and safe operation of the
product.

English

SPECIFICATIONS

Bluetooth version	V5.0
Playtime	4h
Bluetooth Range	Up to 10m in a open area
Battery capacity	140mA
Charging time	1h
Products size	59,5 (L) x 22 (W) x 12 (H) mm

PACKAGE CONTENTS

1. 1x Brightside C28 Wireless Audio Receiver & Transmitter
2. 1x USB-A to micro-USB charging cable
3. 1x 3,5 mm jack (m) - 3,5 mm jack (m) stereo plug
4. User manual

PRODUCT DIAGRAM




One button control

Switch easily between transmitter- (TX) & receiver (RX) mode.

INTERFACE DIAGRAM

1. Multifunction button (power/play/pause)
2. Aux input/ output
3. Transmitter and receiver switch
4. Microphone
5. Indicator light
6. 5V/1A micro USB charging port



How to use

Receiver mode

1. Use the micro USB cable to charge before use. When charging the indicator light (6) will illuminate red;
2. Connect the C28 to your audio device using the AUX port (2);
3. Change the switch button (3) to the RX position;
4. Turn on the device (Long press on the multifunction button (1)) then the blue light will flash quickly indication that it is ready for pairing.
5. Find the C28 in the wireless search of your device and chose to pair. When the connection is successful the indicator light (5) will illuminate blue.

Transmitter mode

1. Use the micro USB cable to charge before use. When charging the indicator light (6) will illuminate red;
2. Connect the C28 to your audio device using the AUX port (2);
3. Change the switch button (3) to the TX position;
4. Turn on the device (Long press on the multifunction button (1)) then the red light will flash quickly indicating that it is ready to pair;
5. Turn on the device you want to connect and the C28 will automatically connect. When the connection is successful the indicator light (5) will illuminate red.

If you encounter any problems with the installation or if you have any other questions, please feel free to contact us. You can do this directly via our contact page: www.brightsideonline.nl



Get 10% off!
With the code: BSO-BTA-10

Engels

60x90mm