

CARSON[®] SPLITHANDLE[™]


HF-11

2x / 3.5x LED LIGHTED MAGNIFIER

Instructions for use:

Installing Batteries


Pull apart handle into split position to reveal battery compartment (Fig. 1). Slide down to remove battery cover located on inside of right handle (Fig. 2). Insert 2 AAA batteries into battery compartment according to polarity indicators marked inside it (Fig. 3). Replace battery door when done (Fig. 4).



Warning: Use only alkaline batteries. Mixing old and new, different brands or types within brands may cause batteries to leak, overheat or explode. Keep away from fire or excessive heat. Inspect batteries for corrosion or leakage. Insert in direction indicated. Rechargeable batteries not recommended.


To Activate LED Light

To turn light on, slide switch located on top of handle up (Fig. 5). Turn light off when not in use.






Attaching Neck Strap

Neck strap is stored inside left handle (Fig. 6). Slide down and remove cover located on inside of left handle (Fig. 7). Remove strap (Fig. 8) and replace cover. Unravel neck strap and locate C clamps on each side of strap (Fig. 9).




Snap clamps into place on each side of the magnifier lens frame (Fig. 10-11). Note: Circular bumps on inside of clamps should line up with indents on sides of lens frame (Fig. 12).




To Use Hands Free

With neck strap attached and handles in split position (Fig. 13), place strap around neck and rest ends of handles on chest (Fig. 14). Rubber tips on ends of handles will keep magnifier from slipping. Adjust length of neck strap as desired.



To Use Hand Held

Remove neck strap and push sides of handles together to form one large handle (Fig. 15).



Cleaning Your Magnifier

Clean lens with a soft, clean microfiber cloth by rubbing gently in a circular motion. Moisten the lens cloth with water if needed. Do not use harsh chemicals, solvents or abrasives as they may damage the lens.

Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.

In the U.S.A.

Phone: 1-631-963-5000

Email: info@carson.com

In the U.K.

Phone: +44 (0) 1938 557440

Email: uksupport@carson.com

In the E.U.

Phone: +44 (0) 1938 557440

Email: eusupport@carson.com

For warranty information, visit www.carson.com/warranty