





SILVERSTONE


IceMyst Series

liquid cooling
user's manual



Contents

A




FAN SCREW x8 (240/280)
x12 (360/420)

B




CASE SCREW x8 (240/280)
x12 (360/420)

C



SPRING SCREW x4

D



LGA115x SCREW x4

E




LGA1700 SCREW x4

F



LGA2011 SCREW x4

G




AMD BUCKLE x2

H




THERMAL GREASE x1

I



Intel CLIP x1

J



AMD CLIP x1

K



LGA115x BACK PLATE x1

L




LGA1700 BACK PLATE x1

M




4PIN PERIPHERAL
ADAPTER CABLE x1

N



2 IN 1 FAN CABLE x1
(240/280)

O




3 IN 1 FAN CABLE x1
(360/420)

P




ARGB SYNC CABLE x1

Q



MB SYNC CABLE x1

R




ARGB CONTROL BOX x1

S






SATA POWER ADAPTER x1


T







2 IN 1 ARGB CABLE x1




240/280




240/280










360/420



360/420



INTEL




Intel LGA 115x / 1200



Intel LGA 1700

Intel LGA 2011 / 2066


AMD




AMD Socket AM4/AM5



MOTHERBOARD SYNC



ARGB CONTROL BOX



PLEASE CONFIRM THE CONNECTOR, THE DEFINITION AND DIRECTION OF YOUR PIN HEADER WHEN CONNECTING CABLES.

ENSURE ARGB CONTROLLER / MOTHERBOARD HAS SAME +5V PIN DEFINITION AS ICEMYST SERIES.

SilverStone Technology Co., Ltd.

www.silverstonetek.com

support@silverstonetek.com

NO.G11248520