


Note on making connections


Do not connect both the DVD&VCR outputs (LINE OUT VIDEO/AUDIO L/R) and S-video output (S-VIDEO OUT) to the same TV input.

You can enjoy higher quality DVD images by connecting the S-video output (S-VIDEO OUT) and the audio output for DVDs (LINE OUT AUDIO L/R) to a different set of TV inputs such as LINE 2 on your TV.

CORRECT



INCORRECT



This file has been downloaded from:

www.UsersManualGuide.com

User Manual and User Guide for many equipments like mobile phones, photo cameras, mother board, monitors, software, tv, dvd, and others..

Manual users, user manuals, user guide manual, owners manual, instruction manual, manual owner, manual owner's, manual guide, manual operation, operating manual, user's manual, operating instructions, manual operators, manual operator, manual product, documentation manual, user maintenance, brochure, user reference, pdf manual