## QUICK SETUP GUIDE:



IMPORTANT: It is recommended to BENCH TEST this unit by performing the Quick setup procedures below, adding a new user(s) and testing communications. In this manner, if there are any communication concerns experienced after the installation, troubleshooting efforts can be focused towards evironmental variables.





## **IMPORTANT!**

STANDARD GOOSENECK PEDESTAL INSTALLATION RECOMMENDED.

IF ALTERNATE MOUNTING IS REQUIRED, ALLOW SPACE FOR ANTENNA.

WITHOUT PROPER SPACING, SIGNAL MAY BE INTERRUPTED.




### **IMPORTANT!**

ELIKA 460 **REQUIRES ACTIVATION** BEFORE USE.

SEE THE ACTIVATION CARD
FOLLOW THE PROMPTED
INSTRUCTIONS AT:

www.elikacloud.com



2. REMOVE THE MAIN BOARD



RE-INSTALL THE MAIN BOARD

#### **WARNING**

AUTOMATIC GATES CAN CAUSE SERIOUS INJURY OR DEATH!

THE GATE PATH MUST BE CLEAR BEFORE OPERATING!


SAFETY DEVICES SHOULD BE INSTALLED TO ENSURE PROPER USE.

1. REMOVE THE SECURITY SCREWS

## QUICK SETUP GUIDE:



IMPORTANT: It is recommended to BENCH TEST this unit by performing the Quick setup procedures below, adding a new user(s) and testing communications. In this manner, if there are any communication concerns experienced after the installation, troubleshooting efforts can be focused towards evironmental variables.





# ENSURE THAT ALL COMPONENTS ARE PROPERLY CONNECTED AND MOUNTED TO THE UNIT.

FOR ADDITIONAL INFORMATION REGARDING INSTALLATION REFER TO THE MANUAL.



#### STOP!

CONFIRM THAT THE UNIT HAS THE PROPER POWER BEFORE TRYING TO OPERATE.

FOR ADDITIONAL INFORMATION ON POWER OPTIONS REFER TO THE INSTALLATION MANUAL.





## 1. REGISTER DEVICE AT: www.elikacloud.com

- a. FOLLOW ONLINE PROMPT
- 2. INPUT CODES:
  - a. SERIAL NUMBER
  - b. REGISTRATION CODE
  - c. FOLLOW ONLINE PROMPT
  - d. ACTIVATE AND PICK PLAN

FOR MORE INFORMATION REFER TO THE MANUAL

