



BBQ Grill Gazebo
OP3672

USA office: Fontana

GBR office: Ipswich

AUS office: Truganina

If you're having difficulty, our friendly
customer team is always here to help.




USA: cs.us@costway.com
AUS: cs.au@costway.com
GBR: cs.uk@costway.com

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.



BBQ Grill Gazebo



PARTS LIST

READ AND SAVE THESE INSTRUCTIONS

Please read instruction carefully and identify all the parts before assembly.

※ Caution : Small parts like nuts and bolts, may pose a choking hazard to young children.
Keep out of reach of small children.

No.	Picture	Description	Qty
A		Pillar	2
B		Pillar	1
B1		Pillar	1
C		Long Top Beam	2
D		Short Top Beam	2
E		U-shaped Connector	6
F		Top Tube	4
F1		Top Tube	2
G		Connector Hub	1
H		Side Shelf	2
I		Hook	1
J		Shelf Support Frame	4

No.	Picture	Description	Qty
K		Large Canopy Fabric	1
L		Small Canopy Fabric	1
M		Bolt (M6x15mm)	27
N		Bolt (M6x20mm)	8
O		Bolt (M6x30mm)	14
Q		Nut	6
R		Ground Stake	8
S		Hex Wrench	1
T		Driver	1
U		Bolt Cap	37
V		Nut Cap	6
W		Leg Cap	4
Y			1

ASSEMBLY INSTRUCTIONS

1

Slide the four Leg Caps (W) onto each Pillar (A/B/B1). Attach the U-Shaped Connector (E) to the top end of each Pillar (A/B/B1), using Bolt (M). Repeat this step 4 times as shown in Figure 1.




Figure 1

2

Attach Top Beams (C/D) to each of Pillars (A/B/B1) with Bolt (M) and Bolt Cap (U) as shown in Figure 2. Repeat this step with remaining Long and Short Beams (C/D) until all have been attached.




Figure 2

3

Insert Top Tubes (F/F1) into the Connector Hub (G). Repeat this step 4 times as shown in Figure 3.




Figure 3

4

Attach the Large Canopy Fabric (K) to the Top Frame assembled in Step 3.




Figure 4

5

Attach the Small Canopy Fabric (L) to the Top Frame assembled in Step 3.
 Note: There are four tube receivers in the four corners of the small and Large Canopy Fabric (L, K). **You may need to enlist “team work” by using ladders and two or more people to complete this step.**
 Then Connect the Top Tube (F) of the Canopy Frame assembled in Step 3 with the U-shaped Connector (E) to the Pillars (A/B/B1) in four corners with the Bolt (O), Nut (Q) and Nut Cap (V) as shown in Figure 5.




Figure 5

6

Connect the Shelf Support Frame (J) with the Pillars (A/B), using Bolt (O) and Bolt Cap (U). Repeat this step 4 times to assembly each of the Pillars (A/B) as shown in Figure 6.




Figure 6

7

Attach the Hook (I) to the Glass Side Shelf (H) with Bolt (M) and Bolt Cap (U) as shown in Figure 7.




Figure 7

8

Attach the Side Shelf (H) to the Shelf Support Frame (J) with Bolt (N) and Bolt Cap (U) as shown in Figure 8.





Figure 8

Fixed the bottom hole of each of four Pillars (A/B/B1) to a solid surface, ground, patio, deck etc. by using the Ground Stake (R). Repeat this step to attach the shelves at each of the four corners as shown in Figure 9.



NOTE: The side tables are adjustable to two heights, 24 in. and 30 in. There is a cap pre-inserted in the lowest hole on each Pillar. Please remove the cap for the hole first if you want to adjust the table height to 24 in. for the first time. And then use included bolt & cap in unused hole in pillar once attached.

Now please enjoy your new grill gazebo.



Return / Damage Claim Instructions

- ⚠ **DO NOT discard the box / original packaging.**
In case a return is required, the item must be returned in original box. Without this your return will not be accepted.
- ⚠ **Take a photo of the box markings.**
A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.
- ⚠ **Take a photo of the damaged part (if applicable).**
A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.
- ⚠ **Send us an email with the images requested.**
Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.