T14 Gen 2, T15 Gen 2, P14s Gen 2, and P15s Gen 2
User Guide





Read this first

Before using this documentation and the product it supports, ensure that you read and understand the following:

- Safety and Warranty Guide
- Setup Guide
- Generic Safety and Compliance Notices

First Edition (February 2021)

© Copyright Lenovo 2021.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Contents

Discover your Lenovo notebook iii	Lock the computer
	Log in with your fingerprint (for selected models) 31
Chapter 1. Meet your computer 1	Log in with your face ID (for selected models) 31
Front view	Protect your privacy (for selected models) 32
Side view	Protect data against power loss (for selected
Bottom view 6	models)
Rear view	UEFI BIOS passwords
Specifications	Password types
USB specifications	Set, change, and remove a password 34
0	Associate your fingerprints with passwords
Chapter 2. Get started with your	(for selected models)
computer9	Chapter 5. Configure advanced
Access networks	settings
Connect to Wi-Fi networks 9	_
Connect to the wired Ethernet 9	UEFI BIOS
Connect to a cellular network (for selected	Enter the UEFI BIOS menu
models)	Navigate in the UEFI BIOS interface
Turn on the Airplane mode	
Interact with your computer	Change the startup sequence
Use the keyboard shortcuts	Update UEFI BIOS
Use the TrackPoint pointing device 12	Recovery
Use the trackpad	Restore system files and settings to an earlier
Use the touch screen (for selected models) 14	point
Connect to an external display 16	Restore your files from a backup
Observan	Reset your computer
Chapter 3. Explore your computer 19	Use advanced options
Lenovo apps	Windows automatic recovery
Smart features (for selected models)	Create and use a recovery USB device 39
Color calibration (for selected models)	Install Windows 10 and drivers
Intelligent Cooling	Chapter 6 CPU replacement 41
Manage power	Chapter 6. CRU replacement 41
Check the battery status	CRU list
Charge the computer	Disable Fast Startup and the built-in battery 41
Change the power settings 25	Replace a CRU
Transfer data	Base cover assembly (T14 Gen 2 and P14s
Set up a Bluetooth connection 25	Gen 2)
Set up an NFC connection (for selected models)	Base cover assembly (T15 Gen 2 and P15s Gen 2)
Use a microSD card or smart card (for	Memory module (for selected models) 46
selected models)	M.2 solid-state drive 47
Use the RFID feature (for selected Intel	Coin-cell battery 49
models)	Wireless WAN card (for selected models) 49
Accessories	Speaker assembly 51
Purchase accessories 27	Always On USB 3.2 connector Gen 1 board
Docking station 27	
	Keyboard 52
Chapter 4. Secure your computer	Chantar 7 Halp and account 50
and information 31	Chapter 7. Help and support 59

© Copyright Lenovo 2021 i

Frequently asked questions	59 Appendix A. Accessibility and ergonomic
Error messages	60 information
Beep errors	61
Self-help resources	Appendix B. Compliance
Windows label	information
Call Lenovo	63 Appendix C. Notices and
Before you contact Lenovo	63 trademarks
Lenovo Customer Support Center	64
Purchase additional services	65

Discover your Lenovo notebook

Thank you for choosing a Lenovo notebook! We are dedicated to delivering the best solution to you.

Before starting your tour, please read the following information:

- Illustrations in this documentation might look different from your product.
- Depending on the model, some optional accessories, features, software programs, and user interface instructions might not be applicable to your computer.
- Documentation content is subject to change without notice. To get the latest documentation, go to https://pcsupport.lenovo.com.

© Copyright Lenovo 2021