



QUICK START GUIDE




QUICK START GUIDE


GESTURES



Tap
Play/Pause



Swipe
Next/Previous



Swipe
Volume (Up/Down)

