

Retail mode removal / Factory reset instructions.

CAT S62

1. Go To Settings > Display > Advanced > Retail Demo Mode
2. Select "Exit Retail Demo Mode" and when prompted enter 24682468 to exit retail mode.

REVV L6 + 6Pro

Access the app drawer and find "REVV L 6 TMUSdemo"

Press and hold that icon

Drag the icon to "Uninstall"

Confirm uninstallation by clicking "OK." The demo will be uninstalled.

Samsung

Access the app drawer and find "Samsung Retail Mode"

Select 'store settings'

Enter the password (see passwords >)

Select Display Mode Setting

Toggle 'Deactivate Retail Mode'

Select 'ok'

Hard reset the device to complete removal

A03 5444

A13 uncarr1er

S21 magenta

S22 uncarr1er or uncarri3r

Z series uncarr1er or uncarri3r

A52 magenta

A53 uncarr1er or uncarri3r

TCL30XE

1. Access the app drawer and find "TCL 30 XE TMUSdemo."
2. Press and hold that icon.
3. Select App info.
4. Click Uninstall.
5. Confirm uninstallation by clicking "OK." The demo will be uninstalled.

Motorola

1. Access settings
2. Search and select factory reset
3. Enter Password: demo3948

OnePlus

1. Open up Demo Mode
2. Click on setting icon in top right corner
3. Type 0110 into prompt
4. Click on "Exit demo mode"
5. For CPH2417 passcode 652511/ For CPH2419 type 661307



TCL Stylus 5G

1. Click on “Demo Mode” icon
2. Click the 
3. Input 852618
4. Click “Exit” to exit app
5. Factory reset