

尺寸: 105x148.5mm 材质: 128g双铜 工艺: 彩色双面印刷 折页方式: 骑马钉

SEENDA

User Manual

Full Size Bluetooth Keyboard Mouse Combo

3-channel Multi-OS Connectivity

Type-C Rechargeable

Full Size and Slim

COSS500

EN

Product Warranty

All Seenda products come with a 24-month warranty policy, please do not hesitate to contact us if you have any questions. Our support team will try our best to provide you with a pleasant shopping experience.

Our email: support@seenda.com

Our website: www.seenda.com

Phone: +1 844-968-2543

Mon-Fri 10AM - 2PM; 3PM - 7PM ET

*Closed during holidays.

Product Features

Left Button

Scroll Wheel

Type-C Charging Port

Bluetooth 3 Indicator

Bluetooth 1 Indicator

Power Switch

Right Button

Charging / Low Battery Indicator

Bluetooth 2 Indicator

Bluetooth 1 Indicator

Channel Switch Button

DPI Button

Charging: Red Light

Fully Charged: Green Light

Low Battery: Red Light Flashing

Multimedia Function Keys

Multimedia Function Keys

Power Switch

Type-C Charging Port

Charging Indicator

Bluetooth 1/ Low Battery Indicator

Bluetooth 2/ Low Battery Indicator

Bluetooth 1 Channel

Bluetooth 2 Channel

Bluetooth 3 Channel

Mouse Bluetooth Connection

1. Turn the power switch to "ON".

2. Press the channel switch button until the 01/02/03 channel indicator light is on, and the mouse enters the Bluetooth channel. Long press the channel switch button for 3-5 seconds until the indicator light flashes quickly, and the mouse enters Bluetooth pairing mode.

3. Turn on the Bluetooth settings on your device, search or select "Seenda COSS500", and start Bluetooth pairing until the connection is completed.

Keyboard Bluetooth Connection

1. Turn the power switch to "ON".

2. Press the 01/02/03 channel button, and the channel indicator light is on, the keyboard enters the Bluetooth channel. Long Press this selected channel button for 3-5 seconds until the indicator light flashes quickly, and the keyboard enters Bluetooth pairing mode.

3. Turn on the Bluetooth settings on your device, search or select "Seenda COSS500", and start Bluetooth pairing until the connection is completed.

Mouse Channel Switching

1. 2. 3.

After 01/02/03 are connected, short press the channel switch button on the bottom of the mouse, easily switch between multiple devices.

Keyboard Channel Switching

1. 2. 3.

After 01/02/03 are connected, short press the channel button on the keyboard, easily switch between multiple devices.

Charging Guide

1. When the battery is low, the low battery indicator light on the keyboard or mouse will rapidly flash to indicate low power.

2. Insert the Type-C port into the mouse or keyboard and the USB-A port into the computer to charge, the red light stays on while charging.

3. A full charging cycle typically takes 2 to 3 hours. Once the keyboard and mouse are fully charged, the charging indicator light turns green.

Multimedia Function Keys

Button	MAC OS System	iOS System
Brightness -	Brightness -	Brightness -
Brightness +	Brightness +	Brightness +
Mission Center	N/A	
Search	Search	
Previous track	Previous track	
Play & Pause	Play & Pause	
Next track	Next track	
Mute	Mute	
Volume -	Volume -	
Volume +	Volume +	
Long press to turn off	Short press to lock screen	
Lock screen	Lock screen	
Language switch	Language switch	
Fn + Esc/Fn lock button to turn on or turn off the FN function		

Note: The FN function is a cyclic mode (F1-F12 and multimedia functions are cyclically used).

Product Specifications

Keyboard Specifications:

Battery Capacity	280mAh
Battery Life	1000 charge and discharge cycles
Keystroke Life	3 million keystroke test
Standby Time	200 hours
Continuous Working Hours	50 hours
Wake-up Mode	Press any key to wake up
Effective Distance	Within 8 meters
Working Current	≤5.5mA
Keyboard Size	427.8*142*15.8mm/16.8*4.5*0.6in

Mouse Specifications:

Battery Capacity	300mAh
Battery Life	1000 charge and discharge cycles
Keystroke Life	More than 3 million
Standby Time	200 hours
Continuous Working Hours	50 hours
Engine	Optical
Mouse DPI	1000/600/2400 DPI
Mouse Size	107*58*23.2mm/4.2*2.3*0.9in

Bluetooth Transmission Specifications:

Transmission Distance	10m
Working Voltage	3.7V
Working Current	<5mA
Return Rate	125Hz
System Requirements	Mac OS: Mac OS 10.0 and Above iPad OS: iPad OS 13.4.1 and Above iPhone OS: iPhone OS 13.4.1 and above

Sleep Mode

1. When the keyboard/mouse stops working for 60 minutes, it will automatically enter the sleep mode for energy saving.

2. When use the keyboard/mouse again, you only need to press any key, and the keyboard/mouse will wake up within 3-5 seconds.

3. The channel indicator lights up and start working.

Memory Function

The keyboard/mouse has a memory function. When a channel is connected normally, the keyboard/mouse defaults to this channel after turning off the device and turn back on, and the channel indicator lights up.

Package Content

► 1* Wireless Bluetooth Keyboard

► 1* Wireless Bluetooth Mouse

► 1* User Manual

► 1* Type-C Charging Cable

Frequently Asked Questions

How to deal with cracked keyboard edges or dropped keys?

► If this happens and it cannot be recovered, please do not hesitate to contact our customer service for assistance.

How to deal with disconnection issues, keys repeating or typing & clicking delay?

► Please ensure that the keyboard/mouse is fully charged. A low battery can affect the performance of the keyboard/mouse.

► Delete the Bluetooth name from your device's Bluetooth connection list, and restart your device and repair the keyboard/mouse by following the steps in the user manual.

► If the issues persist, try to connect the keyboard/mouse to other devices to check if the same issues occur and don't hesitate to contact our customer service for assistance.

How to deal with keyboard/mouse won't turn on or stops working?

► The rated charging voltage for the keyboard and mouse is 5V. It is recommended to use the computer's USB port for charging.

► Try to change another Type-C cable to confirm whether it is a cable issue or a fault with the keyboard and mouse.

► If the power indicator of the keyboard/mouse does not light up at all, please do not hesitate to contact our customer service for assistance.

How to deal with keys/mouse buttons stop working or feel sticky?

► Please note the keyboard/mouse is not waterproof. Avoid water/drinks/coffee and other liquids from entering. If this happens, please turn it upside down and clean the liquid.

► Also, avoid eating near the keyboard/mouse as crumbs are also the primary cause of this issue. If this happens, first try to clean the debris with compressed air blower, then wipe it clean with a cotton swab dipped in ethanol or isopropyl alcohol.

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

⚠ Charging Safely: Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.

⚠ Battery Handling: Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.

⚠ Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.

⚠ Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until thoroughly dried.

⚠ Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.

⚠ Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.

⚠ Radio Frequency Interference: This device may cause interference with other electronics. Keep a safe distance from sensitive devices.

⚠ Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.