

USER PRODUCT GUIDE


Product parameter



Product model: X1
Waterproof level: IPX6
Wireless version: V5.4
Transmission distance: ≤10m
Music format support: MP3, WMA, WAV, APE, FLAC

Battery: 200mAh
Charging: About 2 hours
Play: 10H@65% volume
Protocol: HFP A2DP AVRCP

Multiple use key




Start: Long press the power button for 3 seconds, Blue light flashes for 2 seconds
Shutdown: Long press the power button for 3 seconds, red light on for 1 second.
Wireless /MP3: Double click the power button.
To answer a call: Press the power button once.
End of call: Press the power button once.
Volume increase: Press the volume+ key once.
Volume Down: Press the volume- key once.
Previous song: Long press the Volume- key for 1 seconds.
Next song: Long press the Volume+ key for 1 seconds.
Music play/Pause: Press the power button once.

Pairing/Pilot lamp



Enter the pairing state: After the device is powered on, enter pairing mode. When paired, the red and blue lights flash alternately.
Pairing: After entering the pairing state, open the Wireless on the device, search the device name "POLVCDG X1", click the device "POLVCDG X1" to pair and connect, you can use the connection successfully.
USB data transfer mode: The blue indicator is blinking.
When charging: The red light is long on
When fully charged: The Blue light is long on
Low battery warning: When the battery is low, the red light blinks and an alert tone plays every 3 minutes.

Dual mode switching (Applicable 32g)



Mode switching: Double-click the power button to enter MP3 mode.
Reminder: Boot automatically default Wireless mode.
MP3(TF card) mode: Default sequential play, with memory function.
Computer side file transfer(Song download): Use the magnetic data cable to connect the headset to the computer, you can read the headset U disk, in the folder, open the drive disk named "POLVCDG X16", the computer side for file transfer.

Charging

1. The headset uses a built-in rechargeable battery, which must be fully charged when using the headset for the first time. In use, if the voice "drop" indicates that the battery is low, it means that the battery is low, and you need to charge the headset at this time.
2. Connect the charging cable to the magnetic charging port of the headset, and it will be fully charged in about 2 hours. Charging status indicator Blinking Breathing indicator, fully charged blue indicator.

Warn!!!

1. Magnetic charging has a positive and negative electrode corresponding, which can be charged normally by adsorption of each other, and can not be charged by mutual exclusion
Even cause a short circuit.
2. Rechargeable batteries of this product must be disposed of properly for recycling. Do not put the battery in the fire to avoid an explosion.

Matters needing attention

1. Do not soak the earphone in seawater/salt water. If there is rain after use, please dry the charging magnetic part with a paper towel.
2. If you do not use it for a long time, please charge it at least once a month.
3. Please do not disassemble any part of the product without permission. If the product is found defective, stop using the product immediately.
Contact the seller for after-sales treatment.
4. After each exercise, please wipe the sweat on the surface of the headset, especially the position of the charging magnetic suction port.
It should be cleaned in time to prevent sweat and salt water from corroding the charging port and affecting the service life of the product.
5. Keep the product away from fire, heat source, freezing source and chemicals, and prohibit violent impact, disassembly and extrusion of the product.
6. Please use the charging head with output 5V1A or less. If the charge is greater than 5V, it will cause the earphone to heat up, which may cause damage to the battery and motherboard.