

Bluetooth®
Travel Pillow
Headphones




User Manual




K: 43-559-763 | T: 71-038-872
MODEL: EBA2-240057A

- Includes:
- ▶ Bluetooth® Travel Pillow Headphones
 - ▶ USB-A to USB-C Charging Cable
 - ▶ User Manual



Function overview:



- | | |
|---|------------------------------|
| 1. Volume Up/Next Song | 5. Volume Down/Previous Song |
| 2. Power ON/OFF
Play/Pause
Answer/End/Reject Call | 6. AUX-IN Port |
| 3. Indicator Light | 7. USB-C Charging Port |
| 4. MIC | 8. Adjustable Buckle |

How to use this speaker

- Function Operation**
- Power ON/OFF** Long press button 3 seconds **Play/Pause** Short press button
- Previous Song** Short press button for 2 times to skip the track **Next Song** Short press button for 2 times to skip the track
- Volume Down** Short press button to decrease the volume **Volume Up** Short press key to increase the volume

Specifications:

- | | |
|---|---|
| Model no:
EBA2-240057A | Charging voltage:
DC =5V |
| Version:
Bluetooth V5.3 | Battery capacity:
3.7V 500mAh |
| Working distance:
10 Meters | Charge time:
Approx 2 hours |
| Output:
RMS 30-50MW (THD≤10%) | Music time:
Approx 30 hours(80% volume) |

Power ON Button Function

▶ Press and hold button for 3 seconds to turn on the device. The indicator light will first stay on in blue for 2 seconds, and then will flash alternately between red and blue, a prompt tone can be heard at the same time. At this point, the device enters Bluetooth pairing mode. If no Bluetooth device is connected within 5 minutes, the machine will automatically shut down.

Short press	Play/pause music while playing music.
Short press	Answer/end the call when a call comes in.
Long press	Reject the call during a call.

Bluetooth Mode

- ▶ Once the device is powered on, it will automatically enter Bluetooth mode in several seconds and the indicator light will flash alternately in red and blue.
- ▶ Search for "anko43559763" (Bluetooth name) and connect from the Bluetooth menu on the source device that has Bluetooth turned on.
- ▶ Once the device is successfully paired and connected, the indicator light will stay on in blue, and a prompt tone can be heard at the same time.
- ▶ When the device is turned on again, it will automatically reconnect to your media device via Bluetooth as it did last time.

AUX Function

- ▶ Use a 3.5mm audio cable (not included) to connect your device through the AUX-IN port. Choose the music from your media device and play.

Adjustable Buckle

- ▶ This Bluetooth travel pillow headphones is comfortable for long-term wear, adjustable via a tension buckle, and fits most ear and head shapes.

Charging

- ▶ This device is powered by rechargeable Lithium battery. Please use provided USB-C cable for charging (Plug the USB-C end into the device's charging port and the other USB-A end into a charger with a minimum output of 5V/1A). The indicator light will turn red while charging and will turn off when fully charged.
- ▶ Please note that the device will shut down during charging.

Operating Environment & Storage Environment

- ▶ Operating environment
Temperature: -5 °C ~ 45 °C
- ▶ Storage environment
Temperature: -20 °C ~ 60 °C

12 month warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Statement

- This product shall not be connected to power supply source exceeding PS1 (5V d.c. 1A).
- Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- The apparatus is only suitable for mounting at height < 2m.
- The marking located on the bottom of the apparatus.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic. 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.

