


ILLUSTRATED PARTS MANUAL



Self-Propelled Mowers

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019


Model E18J



Ref No.	Part Number	Description
1	787-01629	19" Deck
2	687-02415	Transmission Support Bearing
3	710-1241	Screw, 1/4-15 x 1.000
4	710-04744	Screw, HL, #12-16 x 1.00
5	749-04556	Lower Handle
6	931-04462	Engine Shroud
7	710-0654A	Screw, 3/8-16 x 1.00
8	687-02555	Blade Adapter
9	942-0739	Mulching Blade
10	736-0524B	Blade Bell Support
11	710-1044	Screw, 3/8-24 x 1.50
12	731-05639A	Trailing Shield
13	731-05746	Rear Mulch Plug
14	731-04177	Side Discharge Chute
15	987-02055	Mulch Plug (Incl. 16-18)
16	732-1014	Torsion Spring
17	747-0710	Hinge Pin
18	17032A	Chute Deflector Adapter
19	736-0270	Belleville Washer
20	710-0599	Screw
21	931-05686	Rear Door
22	931-05634	Front Cover
23	687-02323-0637	Handle Bracket - RH
	687-02322-0637	Handle Bracket - LH
24	964-04134	Grass Bag
25	647-04082-0637	Grass Bag Frame
26	687-02225-0637	Front Bracket Assembly
27	936-0369	Washer, Flat, .508 x 1.00 x .020
28	687-02304-0637	Self Propelled Bracket Ass'y
29	710-3025	Hhcs, 5/16-18 x .625
30	710-1242	Screw, 5/16-14 x .750
31	712-04063	Nut, Flange Lock, 5/16-18
32	712-04065	Nut, Flange Lock, 3/8-16
33	734-1988	Front Wheel
34	634-04363	Rear Wheel
35	720-04096	Knob
36	732-04650	Wave Spring
37	749-04550	Upper Handle
38	736-0242	Washer, Bell, .340 x .872 x .060
39	720-0279	Knob
40	725-0157	Cable Tie

Ref No.	Part Number	Description
41	710-1205	Rope Guide
42	710-0779A	Screw, #10-16 x .500
43	746-04523	Control Cable
44	747-04995	Blade Control
45	710-1174	Bolt Carriage, 5/16-18 x 2.0
46	720-04072A	Star Knob
47	731-06190	Rear Baffle
48	732-04534	Door Torsion Spring - RH
	732-04535	Door Torsion Spring - LH
49	732-04338C	Spring Lever
50	726-0101	Nut, Spd
51	736-04413	Wshr, Wave, .385 ID x .598 OD
52	954-04158	V-Belt
53	741-0492A	Bushing, Lock, .505 Dia. X .62
54	747-04589	Rear Door Pivot Rod
55	749-04307-0637	Cross Bracket
56	738-04278	Scr., Shldr., 1/4-20 x .50
57	731-06974	Wheel Dust Cover
58	946-04519B	Drive Cable
59	735-04059	Grommet
60	747-04994A	Drive Control
61	918-04463A	Transmission
62	710-04531	Screw, 1/4-20 x .390
63	915-0221	Dowel Pin
64	716-0198	Retainer Ring
65	917-04192C	Spur Gear - RH
	917-04184C	Spur Gear - LH
66	731-05872	Spacer, Clip
67	731-06164	Engine Baffle
68	932-04262	Exten. Spring, .429OD x 2.515
69	748-0390	Bearing Support Spacer
70	750-04870	Sleeve Spacer, .550ID x .340 Lg.
71	750-04853	Sleeve Spacer, .550ID x 7.97 Lg.
72	725-04329	Battery Charger
73	925-04072	Electric Start Harness Assembly
74	925-04347	Key Switch
75	710-1667A	Screw, #10-16 x .750
76	925-0201	Key
77	925-04323	Battery
78	728-0199	Rivet


Model 18M



Ref No.	Part Number	Description
1	787-01629	19" Deck
2	687-02415	Transmission Support Bearing
3	710-1241	Screw, 1/4-15 x 1.000
4	710-04744	Screw, HL, #12-16 x 1.00
5	749-04556	Lower Handle
6	931-04462	Engine Shroud
7	710-0654A	Screw, 3/8-16 x 1.00
8	687-02555	Blade Adapter
9	942-0739	Mulching Blade
10	736-0524B	Blade Bell Support
11	710-1044	Screw, 3/8-24 x 1.50
12	731-05639A	Trailing Shield
13	731-05746	Rear Mulch Plug
14	731-04177	Side Discharge Chute
15	987-02055	Mulch Plug (Incl. 16-18)
16	732-1014	Torsion Spring
17	747-0710	Hinge Pin
18	17032A	Chute Deflector Adapter
19	736-0270	Belleville Washer
20	710-0599	Screw
21	931-05686	Rear Door
22	931-05634	Front Cover
23	687-02323-0637	Handle Bracket - RH
	687-02322-0637	Handle Bracket - LH
24	964-04134	Grass Bag
25	647-04082-0637	Grass Bag Frame
26	687-02225-0637	Front Bracket Assembly
27	936-0369	Washer, Flat, .508 x 1.00 x .020
28	687-02304-0637	Self Propelled Bracket Ass'y
29	710-3025	Hhcs, 5/16-18 x .625
30	710-1242	Screw, 5/16-14 x .750
31	712-04063	Nut, Flange Lock, 5/16-18
32	712-04065	Nut, Flange Lock, 3/8-16
33	734-1988	Front Wheel
34	634-04363	Rear Wheel
35	720-04096	Knob
36	732-04650	Wave Spring

Ref No.	Part Number	Description
37	749-04550	Upper Handle
38	736-0242	Washer, Bell, .340 x .872 x .060
39	720-0279	Knob
40	725-0157	Cable Tie
41	710-1205	Rope Guide
42	710-0779A	Screw, #10-16 x .500
43	946-04637	Control Cable
44	747-04995	Blade Control
45	710-1174	Bolt Carriage, 5/16-18 x 2.0
46	720-04072A	Star Knob
47	731-06190	Rear Baffle
48	732-04534	Door Torsion Spring - RH
	732-04535	Door Torsion Spring - LH
49	732-04338C	Spring Lever
50	726-0101	Nut, Spd
51	736-04413	Wshr, Wave, .385 ID x .598 OD
52	954-04158	V-Belt
53	741-0492A	Bushing, Lock, .505 Dia. X .62
54	747-04589	Rear Door Pivot Rod
55	749-04307-0637	Cross Bracket
56	738-04278	Scr., Shldr., 1/4-20 x .50
57	731-06974	Wheel Dust Cover
58	946-04519B	Drive Cable
59	735-04059	Grommet
60	747-04994A	Drive Control
61	918-04463A	Transmission
62	710-04531	Screw, 1/4-20 x .390
63	915-0221	Dowel Pin
64	716-0198	Retainer Ring
65	917-04192C	Spur Gear - RH
	917-04184C	Spur Gear - LH
66	731-05872	Spacer, Clip
67	731-06164	Engine Baffle
68	932-04262	Exten. Spring, .429OD x 2.515
69	748-0390	Bearing Support Spacer
70	750-04870	Sleeve Spacer, .550ID x .340 Lg.
71	750-04853	Sleeve Spacer, .550ID x 7.97 Lg.

Model Series 260




Ref No.	Part Number	Description
1.	747-1214	Drive Control
2.	747-1161A-0637	Blade Control
3.	746-1113	Control Cable - 37.75"
	746-1114	Control Cable - 50.56"
4.	946-04204	Drive Control Cable
5.	749-1092A-0637	Upper Handle
6.	710-1205	Eye Bolt
7.	720-0279	Wing Nut, 1/4-20
8.	748-0390	Bearing Support Spacer
9.	732-1026	Spring Lever
10.	710-1174	Carriage Bolt, 5/16-18 x 2.0
11.	631-04045	Mulching Baffle
12.	720-04072A	Star Knob
13.	749-04037	Lower Handle
14.	725-0157	Cable Tie
15.	732-04631	Hinge Clip
16.	731-06952	Trail Shield
17.	710-0599	Hex Screw, 1/4-20 x.500
18.	682-3064-0637	Handle Bracket Assy - RH
19.	736-0741	Bell Washer, .760 x 1.25 x.041
20.	712-04065	Lock Nut, 3/8-16
21.	682-3065-0637	Handle Bracket Assembly - LH
22.	687-02046	22" Deck Assembly
23.	710-0654A	Hex Washer Scr., 3/8-16 x 1.0
24.	954-04100	V-Belt, 3L x 32.90
25.	782-0585A-0637	Forward Height Adj. Plate - LH
26.	728-0199	Rivet
27.	750-04407	Sleeve Spacer, .550 ID x 2.22
28.	716-0198	Retainer Ring
29.	918-04375B	Transmission Assy. Comp.
30.	750-04406A	Sleeve Spacer, .550 ID x 8.51
31.	731-0073	Transmission Cover

Ref No.	Part Number	Description
	931-04636	Transmission Cover (Yellow)
32.	687-02555	Blade Adapter
33.	942-0742A	22" Mulching Blade
34.	736-0524B	Blade Bell Support
35.	710-1044	Hex Cap Screw, 3/8-24 x 1.5
36.	782-0584-0637	Forward Hght. Adj. Plate - RH
37.	710-04531	Screw, 1/4-20 x .390
38.	710-0216	Hex Cap Screw, 3/8-16 x.75
39.	720-0426	Adjustment Knob
40.	734-1987	Rear Wheel, 8 x 1.8, Bar
	734-04087	Rear Wheel, 8 x 1.8, Bar, Yellow
41.	731-04643	Wheel Dust Cover
42.	915-0221	Pin
43.	717-1762	Spur Gear 14T - RH
	717-1761	Spur Gear 14T - LH
44.	732-04049	Ext. Spring, .47 OD x 2.50
45.	634-0190	Front Wheel, 8 x 1.8, Bar
	634-04100	Front Wheel, 8 x 1.8, Bar, Yellow
46.	747-0710	Hinge Pin
47.	732-1014	Torsion Spring
48.	931-1034B	Side Discharge Assembly
49.	736-0270	Bell Washer, .265 ID x.75 OD
50.	17032A	Deflector Chute Adapter
51.	741-04242	Height Adjustment Bearing
52.	987-02051	Rear Hgt. Adj. Lever Assembly
53.	987-02140A	Front Lever Assembly - RH
	987-02141A	Front Lever Assembly - LH
54.	687-02342	Rear Pivot Arm Assembly
55.	738-1173	Shoulder Screw, 3/8-16
56.	731-0981C†	Hub Cap
57.	731-2626†	Deluxe Bail Cover
58.	936-0504†	Washer, Wave, .510 x .750 x .017

† If Equipped


Model 26J



Ref No.	Part Number	Description
1.	747-1214	Drive Control
2.	747-1161A-0637	Blade Control
3.	746-04300	Blade Control Cable
4.	746-04304	Drive Control Cable
5.	749-1092A-0637	Upper Handle
6.	710-1205	Eye Bolt
7.	720-0279	Wing Nut, 1/4-20
8.	710-0606	Hex Screw, 1/4-20 x 1.50
9.	731-06749	Cable Mount
10.	710-1174	Carriage Bolt, 5/16-18 x 2.0
11.	712-04064	Flange Lock Nut, 1/4-20
12.	720-04072A	Star Knob
13.	749-04037	Lower Handle
14.	725-0157	Cable Tie
15.	732-04631	Hinge Clip
16.	731-06952	Trail Shield
17.	710-0599	Hex Screw, 1/4-20 x.500
18.	682-3064-0637	Handle Bracket Assy - RH
19.	736-0741	Bell Washer, .760 x 1.25 x.041
20.	712-04065	Lock Nut, 3/8-16
21.	682-3065-0637	Handle Bracket Assembly - LH
22.	687-02046	22" Deck Assembly
23.	710-0654A	Hex Washer Scr., 3/8-16 x 1.0
24.	954-04100	V-Belt, 3L x 32.90
25.	782-0585A-0637	Forward Height Adj. Plate - LH
26.	728-0199	Rivet
27.	750-04407	Sleeve Spacer, .550 ID x 2.22
28.	716-0198	Retainer Ring
29.	918-04375B	Transmission Assy. Comp.
30.	750-04406A	Sleeve Spacer, .550 ID x 8.51

Ref No.	Part Number	Description
31.	731-0073	Transmission Cover
32.	687-02555	Blade Adapter
33.	942-0742A	22" Mulching Blade
34.	732-1026	Spring Lever
35.	710-1044	Screw, 3/8-24 x 1.5
36.	782-0584-0637	Forward Hght. Adj. Plate - RH
37.	736-0524B	Blade Bell Support
38.	710-0216	Hex Cap Screw, 3/8-16 x.75
39.	720-0426	Adjustment Knob
40.	631-04045	Mulch Plug
41.	731-04643	Wheel Dust Cover
42.	915-0221	Pin
43.	717-1762	Spur Gear 14T - RH
	717-1761	Spur Gear 14T - LH
44.	732-04049	Ext. Spring, .47 OD x 2.50
45.	634-0190	Front Wheel
46.	747-0710	Hinge Pin
47.	732-1014	Torsion Spring
48.	931-1034B	Side Discharge Assembly
49.	736-0270	Bell Washer, .265 ID x.75 OD
50.	17032A	Deflector Chute Adapter
51.	741-04242	Height Adjustment Bearing
52.	987-02051	Rear Hgt. Adj. Lever Assembly
53.	987-02140A	Front Lever Assembly - RH
	987-02141A	Front Lever Assembly - LH
54.	687-02342	Rear Pivot Arm Assembly
55.	738-1173	Shoulder Screw, 3/8-16
56.	710-04531	Screw, 1/4-20 x .390
57.	734-1987	Rear Wheel
58.	748-0390	Bearing Support Spacer


Model 26M



Ref No.	Part Number	Description
1.	747-1214	Drive Control
2.	747-1161A-0637	Blade Control
3.	746-04300	Blade Control Cable
4.	746-04304	Drive Control Cable
5.	749-1092A-0637	Upper Handle
6.	710-1205	Eye Bolt
7.	720-0279	Wing Nut, 1/4-20
8.	710-0606	Hex Screw, 1/4-20 x 1.50
9.	946-04295A	Choke Cable
10.	710-1174	Carriage Bolt, 5/16-18 x 2.0
11.	712-04064	Flange Lock Nut, 1/4-20
12.	720-04072A	Star Knob
13.	749-04037	Lower Handle
14.	725-0157	Cable Tie
15.	732-04631	Hinge Clip
16.	731-06952	Trail Shield
17.	710-0599	Hex Screw, 1/4-20 x.500
18.	682-3064-0637	Handle Bracket Assy - RH
19.	736-0741	Bell Washer, .760 x 1.25 x.041
20.	712-04065	Lock Nut, 3/8-16
21.	682-3065-0637	Handle Bracket Assembly - LH
22.	687-02046	22" Deck Assembly
23.	710-0654A	Hex Washer Scr., 3/8-16 x 1.0
24.	954-04100	V-Belt, 3L x 32.90
25.	782-0585A-0637	Forward Height Adj. Plate - LH
26.	728-0199	Rivet
27.	750-04407	Sleeve Spacer, .550 ID x 2.22
28.	716-0198	Retainer Ring
29.	918-04375B	Transmission Assy. Comp.
30.	750-04406A	Sleeve Spacer, .550 ID x 8.51
31.	731-0073	Transmission Cover

Ref No.	Part Number	Description
32.	687-02555	Blade Adapter
33.	942-0742A	22" Mulching Blade
34.	732-1026	Spring Lever
35.	710-1044	Screw, 3/8-24 x 1.5
36.	782-0584-0637	Forward Hght. Adj. Plate - RH
37.	736-0524B	Blade Bell Support
38.	710-0216	Hex Cap Screw, 3/8-16 x.75
39.	720-0426	Adjustment Knob
40.	631-04045	Mulch Plug
41.	731-04643	Wheel Dust Cover
42.	915-0221	Pin
43.	717-1762	Spur Gear 14T - RH
	717-1761	Spur Gear 14T - LH
44.	732-04049	Ext. Spring, .47 OD x 2.50
45.	634-0190	Front Wheel
46.	747-0710	Hinge Pin
47.	732-1014	Torsion Spring
48.	931-1034B	Side Discharge Assembly
49.	736-0270	Bell Washer, .265 ID x.75 OD
50.	17032A	Deflector Chute Adapter
51.	741-04242	Height Adjustment Bearing
52.	987-02051	Rear Hgt. Adj. Lever Assembly
53.	987-02140A	Front Lever Assembly - RH
	987-02141A	Front Lever Assembly - LH
54.	687-02342	Rear Pivot Arm Assembly
55.	738-1173	Shoulder Screw, 3/8-16
56.	710-04531	Screw, 1/4-20 x .390
57.	734-1987	Rear Wheel
58.	748-0390	Bearing Support Spacer
59.	710-04744	Screw, #12-16 x 1.00
60.	631-04437	Engine Shroud


Model Series 460



Ref No.	Part Number	Description
1	747-1214	Drive Control
2	710-0599	TT Screw 1/4-20 x 0.5
3	736-0270	Bell Washer.265 x 0.75
4	17032A	Deflector Chute Adapter
5	732-1014	Torsion Spring
6	918-04376B	Transmission Assembly
7	747-1161A-0637	Blade Control
8	749-1092A-0637	Upper Handle
9	731-04177	Chute Deflector
10	987-02055	Mulch Plug Complete
11	747-0710	Hinge Pin
12	782-7551A	Wheel Dust Cap
13	720-0279	Handle Knob
14	720-04072A	Star Knob
15	710-1205	Eye Bolt
16	746-1132	Control Cable - 40.75"
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	787-01593	Engine Baffle Bracket
19	926-0240	Cable Tie
20	731-05642A	Rear Trailing Shield
21	710-0654A	Self-Tapping Sems Screw
22	946-04203	Drive Cable
23	964-04007A	Grass Bag
24	710-1650	Shoulder Screw # 12 -24
25	987-02347	Front Bearing Assembly
26	710-1241	Screw, 1/4-15 x 1.000
27	987-02194A	Height Adjustment Ass'y - RH
	987-02193A	Height Adjustment Ass'y - LH
28	787-01278	21" Deck
29	731-04150C	Rear Baffle
30	912-0397	Wing Nut
31	750-04595	Slev. Spacer 1.4" Lg.
32	710-0216	Hex Screw, 3/8-16 x.75
33	732-04090A	Torsion Spring - RH
34	712-04065	Flange Lock Nut, 3/8-16

Ref No.	Part Number	Description
35	931-05013A	Transmission Cover
36	782-5002B	Front Baffle
37	954-0637A	V-Belt
38	936-0447	Wave Washer
39	750-04594	Sleeve Spacer 8.985" Lg.
40	987-02221	Blade Adapter, 25mm
41	942-0741A	21" Mulching Blade
42	736-0524B	Blade Bell Support
43	987-02334	Pivot Plate Assembly
44	710-1257	Hex Screw 3/8-24 x 2.50
45	749-0928A-0637	Lower Handle
46	732-1043	Belt Tension Spring
47	720-0426	Adjustment Knob
48	731-06847	Rear Discharge Door
49	634-0190	Front Wheel
50	710-04531	Screw, 1/4-20 x .390
51	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
52	747-04080A-0637	Grass Bag Frame
53	710-0703	Carriage Bolt 1/4-20
54	916-0102	Snap Ring
55	710-1652	TT Scr. w/Washer 1/4-20 x.625
56	987-02271A	Handle Bracket Assembly - RH
	987-02270A	Handle Bracket Assembly - LH
57	915-0221	Dowel Pin
58	736-0474	Washer
59	987-02333	Pivot Arm Assembly - RH
	987-02332	Pivot Arm Assembly - LH
60	732-04175	Rear Spring Lever
61	738-04266	Shoulder Scr.500 Dia. x.434
62	734-1987	Rear Wheel
63	753-06116	Engine Baffle
64	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
65	747-04587	Pivot Rod

Model E46J




Ref No.	Part Number	Description
1	747-1214	Drive Control
2	710-0599	TT Screw 1/4-20 x 0.5
3	736-0270	Bell Washer.265 x 0.75
4	17032A	Deflector Chute Adapter
5	732-1014	Torsion Spring
6	918-04376B	Transmission Assembly
7	747-1161A-0637	Blade Control
8	749-1233D-0637	Upper Handle
9	731-04177	Chute Deflector
10	987-02055	Mulch Plug Complete
11	747-0710	Hinge Pin
12	782-7551A	Wheel Dust Cap
13	720-0279	Handle Knob
14	720-04072A	Star Knob
15	710-1205	Eye Bolt
16	946-04589	Control Cable
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	731-06749	Control Cable Mount
19	926-0240	Cable Tie
20	710-04744	Screw, HL, #12-16 x 1.00
21	710-0654A	Self-Tapping Sems Screw
22	946-04303	Drive Cable
23	964-04128	Grass Bag
24	710-1650	Shoulder Screw # 12 -24
25	987-02347	Front Bearing Assembly
26	710-1241	Screw, 1/4-15 x 1.000
27	987-02194A	Height Adjustment Ass'y - RH
	987-02193A	Height Adjustment Ass'y - LH
28	787-01278	21" Deck
29	731-04150C	Rear Baffle
30	912-0397	Wing Nut
31	750-04595	Slev. Spacer 1.4" Lg.
32	710-0216	Hex Screw, 3/8-16 x.75
33	732-04090A	Torsion Spring - RH
34	712-04065	Flange Lock Nut, 3/8-16
35	931-05013A	Transmission Cover
36	782-5002B	Front Baffle
37	954-0637A	V-Belt
38	936-0447	Wave Washer
39	750-04594	Sleeve Spacer 8.985" Lg.
40	687-02195A	One Piece Blade Adapter
41	942-0741A	21" Mulching Blade

Ref No.	Part Number	Description
42	736-0524B	Blade Bell Support
43	987-02334	Pivot Plate Assembly
44	710-1257	Hex Screw 3/8-24 x 2.50
45	749-0928A-0637	Lower Handle
46	732-1043	Belt Tension Spring
47	720-0426	Adjustment Knob
48	731-06847	Rear Discharge Door
49	634-0190	Front Wheel
50	710-04531	Screw, 1/4-20 x .390
51	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
52	747-04080A-0637	Grass Bag Frame
53	710-0703	Carriage Bolt 1/4-20
54	916-0102	Snap Ring
55	710-1652	TT Scr. w/Washer 1/4-20 x.625
56	987-02271A	Handle Bracket Assembly - RH
	987-02270A	Handle Bracket Assembly - LH
57	915-0221	Dowel Pin
58	736-0474	Washer
59	987-02333	Pivot Arm Assembly - RH
	987-02332	Pivot Arm Assembly - LH
60	732-04175	Rear Spring Lever
61	738-04266	Shoulder Scr.500 Dia. x.434
62	734-1987	Rear Wheel
63	712-04064	Nut, FlgIk, 1/4-20
64	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
65	747-04587	Pivot Rod
66	731-05642A	Rear Trailing Shield
67	753-06116	Engine Baffle
68	787-01593	Engine Baffle Bracket
69	631-04440	Engine Shroud
70	725-04329	Battery Charger
	791-182534†	Battery Charger (w/LED Light)
71	925-04072	Electric Start Harness Ass'y.
72	925-04347	Key Switch
73	710-1667A	Screw, #10-16 x .750
74	925-0201	Key
75	925-04323	Battery
76	728-0199	Rivet
77	710-0606	Screw, 1/4-20 x 1.50

† If Equipped


Model Series 560



Ref No.	Part Number	Description
1	747-1214	Drive Control
2	710-0599	TT Screw 1/4-20 x 0.5
3	736-0270	Bell Washer.265 x 0.75
4	17032A	Deflector Chute Adapter
5	732-1014	Torsion Spring
6	918-04376B	Transmission Assembly
7	747-1161A-0637	Blade Control
8	749-1092A-0637	Upper Handle
9	731-04177	Chute Deflector
10	987-02055	Mulch Plug Complete
11	747-0710	Hinge Pin
12	782-7551A	Wheel Dust Cap
13	720-0279	Handle Knob
14	720-04072A	Star Knob
15	710-1205	Eye Bolt
16	746-1132	Control Cable - 40.75"
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	936-0447	Wave Washer, 1.5 x 1.0 x .029
19	926-0240	Cable Tie
20	914-0104	Cotter Pin
21	710-0654A	Self-Tapping Sems Screw
22	946-04203	Drive Cable
23	964-04007A	Grass Bag
24	710-1650	Shoulder Screw # 12 -24
25	987-02347	Front Bearing Assembly
26	710-1241	Screw, 1/4-15 x 1.000
27	987-02194A	Height Adjustment Ass'y - RH
	987-02193A	Height Adjustment Ass'y - LH
28	787-01278	21" Deck
29	731-04150C	Rear Baffle
30	912-0397	Wing Nut
31	750-04595	Slev. Spacer 1.4" Lg.
32	710-0216	Hex Screw, 3/8-16 x.75
33	732-04090A	Torsion Spring - RH
34	712-04065	Flange Lock Nut, 3/8-16
35	931-05013A	Transmission Cover

Ref No.	Part Number	Description
36	782-5002B	Front Baffle
37	954-0637A	V-Belt
38	753-06116	Engine Baffle
39	750-04594	Sleeve Spacer 8.985" Lg.
40	987-02221	Blade Adapter Assembly
41	942-0741A	21" Mulching Blade
42	736-0524B	Blade Bell Support
43	987-02334	Pivot Plate Assembly
44	710-1257	Hex Screw 3/8-24 x 2.50
45	749-0928A-0637	Lower Handle
46	732-1043	Belt Tension Spring
47	720-0426	Adjustment Knob
48	731-06847	Rear Discharge Door
49	634-0190	Front Wheel
50	710-04531	Screw, 1/4-20 x .390
51	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
52	747-04080A-0637	Grass Bag Frame
53	710-0703	Carriage Bolt 1/4-20
54	916-0102	Snap Ring
55	710-1652	TT Scr. w/Washer 1/4-20 x.625
56	987-02280A	Handle Bracket Assembly - LH
	987-02279A	Handle Bracket Assembly - RH
57	915-0221	Dowel Pin
58	736-0474	Washer, Flat, 1.01 x 1.50 x .035
59	987-02335	Pivot Arm Assembly - RH
	987-02336	Pivot Arm Assembly - LH
60	732-0866	Rear Spring Lever
61	720-0312	Foam Grip
62	738-04266	Shoulder Scr.500 Dia. x.434
63	734-04082	Rear Wheel
64	787-01593	Engine Baffle Bracket
65	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
66	747-04588	Pivot Rod
67	731-05642A	Rear Trailing Shield

Model Series V560




Ref No.	Part Number	Description
1	946-04206A	Variable Speed Cable
2	731-04150C	Rear Baffle 21" Rd.
3	710-1241	Screw, 1/4-15 x 1.000
4	732-04317	Extension Spring
5	747-1161A-0637	Blade Control
6	749-04206B-0637	Upper Handle
7	787-01258A-0637	Cable Mount Bracket
8	753-06060	Control Lever Assembly
9	720-0279	Handle Knob
10	720-04072A	Star Knob
11	710-1205	Eye Bolt
12	946-1130	Control Cable - 40"
	946-04589	Control Cable - 37.25" (Kohler)
13	710-1174	Carriage Bolt, 5/16-18 x 2.0
14	926-0240	Cable Tie
15	914-0104	Cotter Pin
16	912-0397	Wing Nut
17	964-04007A	Grass Bag
18	747-04080A-0637	Grass Bag Frame
19	736-0524B	Blade Bell Support
20	731-05642A	Rear Trailing Shield

Ref No.	Part Number	Description
21	731-06847	Rear Discharge Door
22	710-0703	Carriage Bolt, 1/4-20
23	732-04090A	Torsion Spring - RH
24	747-04588	Pivot Rod
25	931-05013A	Transmission Cover
26	710-1650	Shoulder Screw, # 12 -24
27	753-06116	Engine Baffle
28	749-0928A-0637	Lower Handle
29	954-04082A	V-Belt
30	731-04177	Side Discharge Chute
31	710-04329	Torx Screw
32	787-01593	Baffle Bracket
33	687-02195A	Blade Adapter Assembly
34	942-0741A	21" Mulching Blade
35	732-04294	Belt Keeper Wire
36	710-0896	Scr., 1/4-14 x.625
37	710-1257	Hex Screw, 3/8-24 x 2.50
38	710-0106†	Hhcs, 1/4-20 x 1.50
39	712-04064†	Nut, Flglk, 1/4-20
40	731-06749†	Mount, Cable
41	731-04859†	Bail Cover

† If Equipped

Model Series V560



Ref No.	Part Number	Description
1	750-04405	Slev. Spacer, 1.8" Lg.
2	750-04404	Slev. Spacer, 9.10" Lg.
3	710-0654A	TT Screw
4	787-01278	21" Deck
5	710-0599	TT Screw, 1/4-20 x 0.5
6	736-0270	Bell Washer
7	987-02055	Hinged Mulch Plug Assembly
8	17032A	Chute Deflector Adapter
9	732-1014	Torsion Spring
10	747-0710	Hinge Pin
11	918-04377B	Transmission Assembly
12	987-02193A	Height Adj. Assembly - LH
	987-02194A	Height Adj. Assembly - RH
13	987-02280A	Handle Bracket Assembly - LH
	987-02279A	Handle Bracket Assembly - RH
14	987-02334	Pivot Plate Assembly
15	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
16	782-5002B	Front Baffle
17	712-04065	Flange Lock Nut, 3/8-16
18	734-2042A	Front Wheel, 8 x 2.125

Ref No.	Part Number	Description
19	734-04093	Rear Wheel, 12 x 2.125, Gray
	734-04046	Rear Wheel, 12 x 2.125, Yellow
20	710-04531	Screw, 1/4-20 x .390
21	717-1762	Gear 14T FWD - RH
	717-1761	Gear 14T FWD - LH
22	915-0221	Dowel Pin
23	782-7551A	Wheel Dust Cap
24	916-0102	Snap Ring
25	736-0474	Flat Washer
26	710-0216	Hex Screw, 3/8-16 x .75
27	936-0447	Wave Washer
28	987-02347	Bearing Assembly
29	720-0426	Adjustment Knob
30	710-1652	TT Screw w/washer, 1/4-20 x .625
31	738-04266	Shoulder Screw, .500 Dia. x .385
32	987-02335	Pivot Arm Assembly - RH
	987-02336	Pivot Arm Assembly - LH
33	732-0866	Rear Spring Lever
34	720-0312	Foam Grip
35	736-0182	Washer, Spring, .500 x 1.00 x .022
36	731-07001†	Hubcap

† If Equipped


This exploded view diagram illustrates the assembly of a car door. The main components are labeled with numbers 1 through 49. Key parts include the door panel (35), the door frame (3), the door handle (49), the door latch (46), the door hinge (18), the door lock (31), the door trim (27), the door weatherstripping (13), the door seal (16), the door hinge (15), the door hinge (12), the door hinge (10), the door hinge (11), the door hinge (14), the door hinge (17), the door hinge (19), the door hinge (20), the door hinge (21), the door hinge (22), the door hinge (23), the door hinge (24), the door hinge (25), the door hinge (26), the door hinge (28), the door hinge (30), the door hinge (32), the door hinge (33), the door hinge (34), the door hinge (36), the door hinge (37), the door hinge (38), the door hinge (39), the door hinge (40), the door hinge (41), the door hinge (42), the door hinge (43), the door hinge (44), the door hinge (45), the door hinge (47), the door hinge (48).

Callout A points to the door hinge (15) and the door hinge (30). Callout B points to the door hinge (12) and the door hinge (10).

Ref No.	Part Number	Description
1	946-04440	Drive Cable
2	735-04059	Rubber Grommet
3	747-04994A	Drive Control
4	732-04516	Shift Spring
5	747-04995	Blade Control
6	746-04438	Control Cable
7	749-04555	Lower Handle
8	725-0157	Cable Tie
9	732-04535	Torsion Spring, LH
10	710-0599	TT Screw, 1/4-20 x .500
11	787-01618	21-inch Deck
12	710-0654A	TT Screw, 3/8-16 x 1.00
13	787-01790	Front Deck Baffle
14	731-06304	Variable Spd. Cont. Panel Cover
15	726-0201	Speed Nut
16	710-0779A	Screw, #10-16 x .500
17	710-0895	Screw, 1/4-15 x .750
18	736-3000	Washer, Flat, .250 x .750 x .119
19	936-0275	Washer, Flat, .344 x .688 x .065
20	715-04073	Dowel Pin
21	631-04323	Variable Speed Control Panel
22	710-0642	Screw, TT, 1/4-20 x .750
23	946-04439A	Variable Speed Cable
24	731-06173	Rear Baffle
25	710-3025	Screw, 5/16-18 x .625

Ref No.	Part Number	Description
26	712-04063	Flange Lock Nut, 5/16-18
27	731-05462A	Trail Shield
28	731-05157	Rear Mulching Baffle
29	731-05702A	Rear Door
30	710-1241	Screw, 1/4-15 x 1.00
31	720-04072A	Star Knob
32	732-04534	Torsion Spring, RH
33	747-05034	Door Pivot Rod
34	647-04051B-0637	Grass Catcher Frame
35	964-04101	Grass Catcher
36	710-1174	Carriage Bolt, 5/16-18 x 2.00
37	720-0279	Wing Nut
38	710-1205	Eye Bolt
39	749-04607-0637	Upper Handle
40	736-0270	Bell Washer, .265 x .75 x .062
41	732-1014	Torsion Spring
42	17032A	Chute Deflector Adapter
43	747-0710	Hinge Pin
44	987-02055	Mulch Plug Assembly
45	731-04177	Side Discharge Chute
46	710-04373A	Screw, #12-16 x .75
47	710-0896	Screw, AB, 1/4-14 x .625
48	731-06189	4 Speed Actuator
49	731-06193A	Speed Selector Lever


Model Series 830



Ref No.	Part Number	Description
1	954-04176A	V-Belt
2	732-04338C	Spring Lever
3	720-04113	Height Adjuster Knob - Red
	720-04092	Height Adjuster Knob - Blue
4	917-04540B	Spur Gear, 14T - LH
5	738-04278	Shldr. Screw, 1/4-20 x 0.50
6	710-0895	Screw, HL, 1/4-15 x .750
7	749-04267A-0637	Cross Bracket
8	687-02204B-0637	Front Bracket Assembly
9	731-05470	Clip Spacer
10	741-04136B	Split Hex Flange Bearing
11	734-04014B	Front Wheel
12	712-04065	Flange Lock Nut, 3/8-16
13	934-04430	Rear Wheel
14	710-04531	Screw, 1/4-20 x .39
15	917-04539B	Spur Gear, 14T - RH
16	731-06284	Baffle
17	731-06974	Wheel Dust Cover
18	687-02415	Transmission Bearing Support
19	731-05872	Clip Spacer
20	716-0198	Retaining Ring .875
21	687-02314A-0637	Rear Bracket Assembly
22	732-04630	Compression Spring
23	756-04316A	Upper Pulley

Ref No.	Part Number	Description
24	936-0406	Flat Washer, .442 x 1.38 x .060
25	756-04317A	Lower Pulley
26	687-02322-0637	Handle Bracket Assembly LH
27	915-0221	Dowel Pin
28	918-04826A	Transmission Assembly
29	687-02323-0637	Handle Bracket Assembly RH
30	748-0390	Bearing Support Spacer
31	732-04313	Extension Spring
32	748-04096	Blade Adapter
33	710-1044	Screw, 3/8-24 x 1.50
34	736-0524B	Blade Bell Support
35	942-0741A	21" Mulching Blade
36	936-0447	Washer, Wave, 1.5 x 1.0 x .029
37	710-0599	TT Screw, 1/4-20 x .500
38	731-06112A	Engine Baffle
39	956-04046	Lower Pulley Assembly
40	756-04311A	Pulley, Half
41	736-04413	Wash., Wave, .385 ID x .598 OD
42	710-04774	Screw, 1/4-15 x 1.250
43	736-0242	Washer, Bell, .340 x .872 x .080
44	936-0369	Washer, Flat, .508 x 1.00 x .020
45	732-04650	Spr, Wave
46	750-05007	Spcr., 25mm x 1.375


Model Series 860



Ref No.	Part Number	Description
1	946-04440	Drive Cable
2	735-04059	Rubber Grommet
3	747-04994A	Drive Control
4	732-04516	Shift Spring
5	747-04995	Blade Control
6	746-04438	Control Cable
7	749-04557-0637	Lower Handle
8	725-0157	Cable Tie
9	732-04535	Torsion Spring, LH
10	710-0599	TT Screw, 1/4-20 x .500
11	787-01618	21-inch Deck
12	710-0654A	TT Screw, 3/8-16 x 1.00
13	787-01790	Front Deck Baffle
14	731-06304	Variable Spd. Cont. Panel Cover
15	710-0642	Screw, TT, 1/4-20 x .750
16	710-0779A	Screw, #10-16 x .500
17	726-0201	Nut, Speed
18	710-0895	Screw, 1/4-15 x .750
19	710-0703	Carriage Bolt, 1/4-20
20	912-0397	Wing Nut
21	631-04323	Variable Speed Control Panel
22	914-0104	Cotter Pin
23	946-04439A	Variable Speed Cable
24	731-06173	Rear Baffle
25	710-3025	Screw, 5/16-18 x .625
26	712-04063	Flange Lock Nut, 5/16-18

Ref No.	Part Number	Description
27	731-05462A	Trail shield
28	731-05157	Mulch Plug
29	731-05702A	Rear Door
30	710-1241	Screw, 1/4-15 x 1.00
31	720-04072A	Star Knob
32	732-04534	Torsion Spring, RH
33	747-05034	Door Rod
34	647-04051B-0637	Grass Catcher Frame
35	964-04101	Grass Catcher
36	710-1174	Carriage Bolt, 5/16-18 x 2.00
37	720-0279	Wing Nut
38	710-1205	Eye Bolt
39	749-04607-0637	Upper Handle
40	736-0270	Bell Washer, .265 x .75 x .062
41	732-1014	Torsion Spring
42	17032A	Chute Deflector Adapter
43	747-0710	Hinge Pin
44	987-02055	Mulch Plug Assembly
45	731-04177	Side Discharge Chute
46	710-04373A	Screw, #12-16 x .75
47	710-0896	Screw, AB, 1/4-14 x .625
48	731-06189	4 Speed Actuator
49	731-06193A	Speed Selector Level
50	715-04073	Dowel Pin
51	936-0275	Washer, Flat, .344 x .688 x .065
52	736-3000	Washer, Flat, .250 x .750 x .119


Model Series 860



Ref No.	Part Number	Description
1	954-04176A	V-Belt
2	732-04480A	Spring Lever
3	720-04097	Height Adjuster Knob - Red
	720-04092	Height Adjuster Knob - Blue
4	917-04577A	Spur Gear, 16T - LH
5	738-04278	Shldr. Screw, 1/4-20 x 0.50
6	710-0895	Screw, 1/4-15 x .750
7	749-04414A-0637	Cross Bracket
8	687-02367B-0637	Front Bracket Assembly
9	731-05470	Clip Spacer
10	741-04136B	Split Hex Flange Bearing
11	734-04014B	Front Wheel
12	712-04065	Flange Lock Nut, 3/8-16
13	934-04404	Rear Wheel
14	710-04531	Screw, 1/4-20 x .39
15	917-04578A	Spur Gear, 16T - RH
16	917-04678	Gear, Spur, 23T
17	731-06145C	Wheel Dust Cover
18	741-0604A	Bearing Sleeve
19	787-01645A	Dust Cover Seal Plate
20	731-06146	Hub Cap
21	687-02390-0637	Rear Bracket Assembly
22	732-04630	Compression Spring
23	756-04316A	Upper Pulley
24	936-0406	Flat Washer, .442 x 1.38 x .060
25	756-04317A	Lower Pulley
26	987-02503	Handle Bracket Assembly LH (Includes Ref. #'s 18, 46, & 47)
27	915-0221	Dowel Pin

Ref No.	Part Number	Description
28	918-04826A	Transmission Assembly
29	987-02537	Handle Bracket Assembly RH (Includes Ref. #'s 18, 46, & 47)
30	756-04311A	Pulley, Half
31	732-04313	Extension Spring
32	748-04096	Blade Adapter
33	710-1044	Screw, 3/8-24 x 1.50
34	736-0524B	Blade Bell Support
35	942-0741A	21" Mulching Blade
36	936-0447	Washer, Wave, 1.5 x 1.0 x .029
37	710-0599	TT Screw, 1/4-20 x .500
38	731-06112A	Engine Baffle
39	956-04046	Lower Pulley Assembly
40	710-0653	Screw, TT, 1/4-20 x .375
41	710-04774	Screw, 1/4-15 x 1.25
42	736-0182	Washer, Sprg, .500 x 1.00 x .022
43	936-0272	Washer, Flat, .510 x 1.00 x .060
44	711-05040	Shf., .500 Dia.
45	731-06284	Baffle
46	748-04177	Bearing Support
47	732-0708	Bearing Retainer
48	736-04413	Wshr, Wave, .385 ID x .598 OD
49	732-04557	Sprg, Comp., .63 OD x 1.00 Lg.
50	750-05061	Spacer, .690 x .870 x .150
51	750-05008	Spcr., 25mm x 1.375
52	750-05250	Spcr., Flg., .51 ID x .58 OD
53	936-0369	Washer, Flat, .508 x 1.00 x .020
54	732-04650	Spr, Wave


Model TB210



Ref No.	Part Number	Description
1	747-05214	Blade Control
2	749-04681-0637	Upper Handle
3	747-05226-0637	Grass Catcher Frame
4	749-04608A-0637	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-04998	Carriage Screw ,5/16-18
8	964-04117	Grass Bag
9	720-04124	Wing Knob
10	731-07131	Side Chute
11	725-0157	Cable Tie
12	712-04222	Nut, Sq., 1/4-20
13	631-04369	Rear Discharge Door Assembly
	631-04371	Rear Discharge Door Assembly - (Lowes)
14	747-0710	Hinge Pin
15	787-01779	Chute Deflector Bracket
16	732-04673	Torsion Spring - RH
17	734-04018A	Front Wheel
18	787-01800	Engine Baffle Bracket
19	710-05073	Screw, 1/4-20 x .500
20	787-01802	Deck , 21"
21	987-02516	Hinged Mulch Plug Assembly
22	732-04674	Torsion Spring - LH
23	687-02538	Blade Adapter Assembly
24	942-0741A	Mulching Blade
25	710-1044	Screw , 3/8-24 x 1.50
26	747-05210A	Drive Control
27	738-04419A	Sldr. Screw, .375 x .126 x 1/4-20
28	712-04217	Flange Lock Nut, 3/8-16
29	720-04131	Adjustment Lever Knob
30	720-04127	Wing Nut
31	736-0524B	Blade Bell Support
32	712-04064	Nut, Flange Lock, 1/4-20
33	734-04014B	Rear Wheel

Ref No.	Part Number	Description
34	946-04674	Control Cable
35	710-0654A	TT Sems Screw, 3/8-16 x 1.0
36	731-07203	Trail Shield
37	731-07208	Front Cover
38	732-1014	Torsion Spring
39	946-04675	Drive Cable
40	911-04149	Rear Axle Assembly
41	911-04160	Front Axle Assembly
42	710-04995	Screw, 5/16-14 x .750
43	731-07240	Wheel Dust Cover
44	912-0641	Nut, Hex
45	736-0225	Washer, Lock, 5/8"
46	936-0570	Wash., Flat, .865 x 1.145 x .030
47	737-04003D	Water Nozzle
48	921-04041	Water Nozzle Adapter
49	918-04881	Transmission Assembly
50	631-04444	Engine Baffle
51	641-00014	Bearing Assembly
52	710-04531	Screw, 1/4-20 x .390
53	710-0599	Screw, 1/4-20 x .500
54	710-0895	Screw, 1/4-15 x .750
55	915-0221	Dowel Pin
56	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
57	731-07184A	Lower Tray
58	731-07355	Spring Body
59	732-04675A	Transmission Wire
60	732-04704	Compression Spring
61	936-0369	Wash., Flat, .508 x 1.00 x .020
62	736-04202	Wash., Flat, .504 x .700 x .010
63	736-04495	Wash., Saddle, .505 x .740 x .125
64	738-04436A	Scr., Sldr., 1/4-20 x .70
65	954-04259A	V-Belt
66	787-01793	Front Axle Clip


Model TB270 ES



Ref No.	Part Number	Description
1	747-05214	Blade Control
2	749-04681-0637	Upper Handle
3	747-05226-0637	Grass Catcher Frame
4	749-04608A-0637	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-04998	Carriage Screw ,5/16-18
8	964-04117	Grass Bag
9	720-04124	Wing Knob
10	731-07131	Side Chute
11	725-0157	Cable Tie
12	712-04222	Nut, Sq., 1/4-20
13	631-04369	Rear Discharge Door Assembly
	631-04371	Rear Discharge Door Assembly - (Lowes)
14	747-0710	Hinge Pin
15	787-01779	Chute Deflector Bracket
16	732-04673	Torsion Spring - RH
17	734-04018A	Front Wheel
18	787-01800	Engine Baffle Bracket
19	710-05073	Screw, 1/4-20 x .500
20	787-01806	Deck , 21"
21	987-02516	Hinged Mulch Plug Assembly
22	732-04674	Torsion Spring - LH
23	687-02538	Blade Adapter Assembly
24	942-0741A	Mulching Blade
25	710-1044	Screw , 3/8-24 x 1.50
26	747-05210A	Drive Control
27	738-04419A	Sldr. Screw, .375 x .126 x 1/4-20
28	712-04217	Flange Lock Nut, 3/8-16
29	720-04131	Adjustment Lever Knob
30	720-04127	Wing Nut
31	736-0524B	Blade Bell Support
32	712-04064	Nut, Flange Lock, 1/4-20
33	734-04014B	Rear Wheel
34	946-04674	Control Cable
35	710-0654A	TT Sems Screw, 3/8-16 x 1.0
36	731-07203	Trail Shield
37	731-07208	Front Cover
38	732-1014	Torsion Spring
39	946-04675	Drive Cable
40	911-04149	Rear Axle Assembly

Ref No.	Part Number	Description
41	911-04160	Front Axle Assembly
42	710-04995	Screw, 5/16-14 x .750
43	731-07240	Wheel Dust Cover
44	912-0641	Nut, Hex
45	736-0225	Washer, Lock, 5/8"
46	936-0570	Wash., Flat, .865 x 1.145 x .030
47	737-04003D	Water Nozzle
48	921-04041	Water Nozzle Adapter
49	918-04881	Transmission Assembly
50	631-04444	Engine Baffle
51	641-00014	Bearing Assembly
52	710-04531	Screw, 1/4-20 x .390
53	710-0599	Screw, 1/4-20 x .500
54	710-0895	Screw, 1/4-15 x .750
55	915-0221	Dowel Pin
56	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
57	731-07184A	Lower Tray
58	731-07355	Spring Body
59	732-04675A	Transmission Wire
60	732-04704	Compression Spring
61	936-0369	Wash., Flat, .508 x 1.00 x .020
62	736-04202	Wash., Flat, .504 x .700 x .010
63	736-04495	Wash., Saddle, .505 x .740 x .125
64	738-04436A	Scr., Sldr., 1/4-20 x .70
65	954-04259A	V-Belt
66	787-01793	Front Axle Clip
67	725-04329	Battery Charger
68	710-0136	Screw, 1/4-20 x 1.75
69	710-3105	Bolt, Carr., 5/16-18 x .875
70	712-04063	Nut, Flglk., 5/16-18 x
71	925-0201	Key
72	725-04903	Battery
73	738-04431	Scr., Sldr., 5/16-14 x .972
74	725-05112	Key Switch
75	726-0201	Speed Nut
76	731-07135	Battery Housing
77	731-07154	Battery Housing Top
78	731-07155	Electric Start Housing
79	735-04213A	Lid Seal
—	725-05015	Wire Harness (Not Shown)


Model TB230



Ref No.	Part Number	Description
1	747-05267	Blade Control
2	749-04679-0637	Upper Handle
3	747-05226-0637	Grass Catcher Frame
4	749-04608A-0637	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-04998	Carriage Screw ,5/16-18
8	964-04117	Grass Bag
9	720-04124	Wing Knob
10	731-07131	Side Chute
11	725-0157	Cable Tie
12	712-04222	Nut, Sq., 1/4-20
13	631-04369	Rear Discharge Door Assembly
	631-04371	Rear Discharge Door Assembly - (Lowes)
14	747-0710	Hinge Pin
15	787-01779	Chute Deflector Bracket
16	732-04673	Torsion Spring - RH
17	734-04018A	Front Wheel
18	731-07199	Hubcap
19	710-05073	Screw, 1/4-20 x .500
20	787-01802	Deck , 21"
21	987-02516	Hinged Mulch Plug Assembly
22	732-04674	Torsion Spring - LH
23	687-02528	Blade Adapter Assembly
24	942-0741A	Mulching Blade
25	710-1044	Screw , 3/8-24 x 1.50
26	753-06060	Control Lever Assembly
27	738-04419A	Slidr. Screw, .375 x .126 x 1/4-20
28	712-04217	Flange Lock Nut, 3/8-16
29	720-04131	Adjustment Lever Knob
30	720-04127	Wing Nut
31	736-0524B	Blade Bell Support
32	712-04064	Nut, Flange Lock, 1/4-20
33	634-04626	Rear Wheel

Ref No.	Part Number	Description
34	946-04661	Control Cable
35	710-0654A	TT Sems Screw, 3/8-16 x 1.0
36	731-07203	Trail Shield
37	731-07208	Front Cover
38	732-1014	Torsion Spring
39	946-04655	Variable Speed Cable
40	911-04144	Rear Axle Assembly
41	911-04160	Front Axle Assembly
42	710-04995	Screw, 5/16-14 x .750
43	731-07240	Wheel Dust Cover
44	912-0641	Nut, Hex
45	736-0225	Washer, Lock, 5/8"
46	936-0570	Wash., Flat, .865 x 1.145 x .030
47	737-04003D	Water Nozzle
48	921-04041	Water Nozzle Adapter
49	918-04881	Transmission Assembly
50	631-04444	Engine Baffle
51	641-00014	Bearing Assembly
52	710-04531	Screw, 1/4-20 x .390
53	710-0599	Screw, 1/4-20 x .500
54	710-0895	Screw, 1/4-15 x .750
55	915-0221	Dowel Pin
56	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
57	731-07184A	Lower Tray
58	731-07355	Spring Body
59	732-04675A	Transmission Wire
60	732-04704	Compression Spring
61	936-0369	Wash., Flat, .508 x 1.00 x .020
62	736-04202	Wash., Flat, .504 x .700 x .010
63	736-04495	Wash., Saddle, .505 x .740 x .125
64	787-01800	Engine Baffle Bracket
65	954-04260	V-Belt
66	787-01793	Front Axle Clip


Model TB250



Ref No.	Part Number	Description
1	747-05267	Blade Control
2	749-04679-0637	Upper Handle
3	747-05226-0637	Grass Catcher Frame
4	749-04608A-0637	Lower Handle
5	720-0279	Wing Nut
6	710-1205	Rope Guide
7	710-04998	Carriage Screw ,5/16-18
8	964-04117	Grass Bag
9	720-04124	Wing Knob
10	731-07131	Side Chute
11	725-0157	Cable Tie
12	712-04222	Nut, Sq., 1/4-20
13	631-04369	Rear Discharge Door Assembly
	631-04371	Rear Discharge Door Assembly - (Lowes)
14	747-0710	Hinge Pin
15	787-01779	Chute Deflector Bracket
16	732-04673	Torsion Spring - RH
17	734-04018A	Front Wheel
18	787-01793	Front Axle Clip
19	710-05073	Screw, 1/4-20 x .500
20	787-01802	Deck , 21"
21	987-02516	Hinged Mulch Plug Assembly
22	732-04674	Torsion Spring - LH
23	687-02528	Blade Adapter Assembly
24	942-0741A	Mulching Blade
25	710-1044	Screw , 3/8-24 x 1.50
26	753-06060	Control Lever Assembly
27	738-04419A	Slidr. Screw, .375 x .126 x 1/4-20
28	712-04217	Flange Lock Nut, 3/8-16
29	720-04131	Adjustment Lever Knob
30	720-04127	Wing Nut
31	736-0524B	Blade Bell Support
32	712-04064	Nut, Flange Lock, 1/4-20

Ref No.	Part Number	Description
33	734-04014B	Rear Wheel
34	946-04670	Control Cable
35	710-0654A	TT Sems Screw, 3/8-16 x 1.0
36	731-07203	Trail Shield
37	731-07208	Front Cover
38	732-1014	Torsion Spring
39	946-04655	Variable Speed Cable
40	911-04149	Rear Axle Assembly
41	911-04160	Front Axle Assembly
42	710-04995	Screw, 5/16-14 x .750
43	731-07240	Wheel Dust Cover
44	912-0641	Nut, Hex
45	736-0225	Washer, Lock, 5/8"
46	936-0570	Wash., Flat, .865 x 1.145 x .030
47	737-04003D	Water Nozzle
48	921-04041	Water Nozzle Adapter
49	918-04881	Transmission Assembly
50	631-04444	Engine Baffle
51	641-00014	Bearing Assembly
52	710-04531	Screw, 1/4-20 x .390
53	710-0599	Screw, 1/4-20 x .500
54	710-0895	Screw, 1/4-15 x .750
55	915-0221	Dowel Pin
56	917-04801	Spur Gear, 14T - RH
	917-04802	Spur Gear, 14T - LH
57	731-07184A	Lower Tray
58	731-07355	Spring Body
59	732-04675A	Transmission Wire
60	732-04704	Compression Spring
61	936-0369	Wash., Flat, .508 x 1.00 x .020
62	736-04202	Wash., Flat, .504 x .700 x .010
63	736-04495	Wash., Saddle, .505 x .740 x .125
64	787-01800	Engine Baffle Bracket
65	954-04260	V-Belt


Engine Model 1P70MC



Ref No.	Part Number	Description
1.	951-10438	Fuel Tank
2.	951-10369	Flywheel Shroud
3.	951-10840	Reed Valve Assembly
4.	951-10334	Oil Filler Tube Assembly
5.	951-10863	Dipstick Assembly
6.	951-10413	Cylinder Head Complete
7.	951-10867	Short Block Assembly
8.	951-10321	Stop Switch and Brake Assembly
9.	951-10319	Recoil Spring and Pulley Assembly
10.	951-10344	Push Rod Kit
11.	951-10345	Valve Kit
12.	951-10370	Oil Drain Plug and Washer Assembly
13.	951-10366	Ignition Coil
14.	951-10862	Carburetor Assembly
15.	951-10307	Flywheel Key
16.	951-10865	Air Cleaner Housing Assembly Complete
17.	951-10342	Muffler Stud Assembly
18.	951-10364	Fuel Line Kit – Inc. hoses, clamps & filter
19.	951-10358	Fuel Filter
20.	951-10440	Fuel Cap
21.	951-10299	Recoil Starter Assembly
22.	951-10298	Air Cleaner Kit
23.	951-10297	Air Cleaner Thumb Screw
24.	951-10411	Muffler Guard
25.	951-10775	Muffler
26.	951-10402	Muffler Gasket /Heat Shield
27.	951-10387	Governor Return Spring
28.	951-10292	Spark Plug
29.	951-10869	Roll Over Valve Assembly
30.	951-10443	Carbon Canister
31.	951-10773	Spark Arrestor
–	952Z1P70MC	Engine – Complete
–	951-10868	Carburetor Kit – Major
–	951-10870	Cylinder Head Service Kit
–	951-10416	Gasket Kit – Complete
–	951-10417	Gasket Kit – External

NOTE: Illustrated parts without a numeric call-out are not servicable components.

Engine Model - 2P70MOB




Ref No.	Part Number	Description
1.	951-10368	Fuel Tank
2.	951-10855	Flywheel Shroud
3.	951-10335	Rubber Fuel Tank Mntg. Washer
4.	951-10334	Oil Filler Tube Assembly
5.	951-10852	Dipstick Assembly
6.	951-10413A	Cylinder Head Complete
7.	951-10857A	Short Block Assembly
8.	951-10858	Stop Switch and Brake Assembly
9.	951-10319	Recoil Spring and Pulley Ass'y.
10.	951-10344	Push Rod Kit
11.	951-10345	Valve Kit
12.	951-10370	Oil Drain Plug and Washer Ass'y.
13.	951-10854	Ignition Coil
14.	951-10881	Carburetor Assembly
15.	951-10307	Flywheel Key
16.	951-10412A	Air Cleaner Housing Complete
17.	951-10342	Muffler Stud Assembly
18.	951-10364	Fuel Line Kit – Inc. hoses, clamps & filter
19.	951-10358	Fuel Filter
20.	951-10300	Fuel Cap Assembly

Ref No.	Part Number	Description
21.	951-10299A	Recoil Starter Assembly
22.	951-10298	Air Cleaner Kit
23.	951-10297	Air Cleaner Thumb Screw
24.	951-10411	Muffler Guard
25.	951-10403	Muffler
26.	951-11179	Muffler Gasket /Heat Shield
27.	951-11178	Governor Return Spring
28.	951-10292	Spark Plug
29.	951-10351	Spark Arrestor
30.	951-10880A	Electric Starter
31.	951-10823	Relay Assembly
32.	951-10824	Relay Harness Connector
33.	951-10888	Primer Assembly
–	952Z2P70MOB	Engine – Complete
–	712-04221	Flywheel Nut
–	951-11045	Flywheel
–	951-11238	Governor Arm Bracket
–	951-10890	Carburetor Kit – Major
–	951-10859	Cylinder Head Service Kit
–	951-10416	Gasket Kit – Complete
–	951-10417	Gasket Kit – External

NOTE: Illustrated parts without a numeric call-out are not servicable components.

Model Series G460



Model Series G460

Ref No.	Part Number	Description
1	753-06060	Drive Control Assembly
2	749-0928A-0637	Lower Handle
3	710-0703	Carriage Bolt 1/4-20
4	918-04377B	Transmission Assembly
5	731-06847	Rear Discharge Door
6	954-04082A	V-Belt
7	747-1161A-0637	Blade Control
8	749-1092A	Upper Handle
9	731-04177	Chute Deflector
10	987-02055	Mulch Plug Complete
11	732-04090A	Torsion Spring - RH
12	747-04080A	Grass Bag Frame
13	720-0279	Handle Knob
14	720-04072A	Handle Knob
15	710-1205	Eye Bolt
16	746-1130	Control Cable
17	710-1174	Carriage Bolt 5/16-18 x 2.0
18	731-07049	Hub Cap
19	926-0240	Cable Tie
20	732-0706	Front Lever - RH
	732-0707	Front Lever - LH
21	710-0654A	Self-Tapping Sems Screw
22	746-04206A	Drive Cable
23	964-04007A	Grass bag
24	710-1650	Shoulder Screw # 12 -24
25	747-04587	Pivot Rod
26	710-1241	Screw, 1/4-15 x 1.00
27	732-04317	Extension Spring
28	731-05642A	Rear Trailing Shield
29	731-04150C	Rear Baffle
30	936-0504	Washer, Wave, .510 x .750 x .017
31	912-0397	Wing Nut
32	931-05013A	Transmission Cover
33	687-02221	Blade Adapter
34	942-0741A	21" Mulching Blade
35	736-0524B	Blade Bell Support
36	710-1257	Hex Screw 3/8-24 x 2.50
37	782-7551A	Wheel Dust Cap
38	916-0102	Snap Ring
39	787-01258A-0637	Cable Mount Bracket
40	710-0896	Screw, 1/4-14 x .625
41	710-04329	Screw, .159 OD x .610

Ref No.	Part Number	Description
42	787-01593	Engine Baffle Bracket
43	936-0447	Washer, Wave, 1.5 x 1.0 x .029
44	931-06029	Engine Baffle
45	710-0599	TT Screw 1/4-20 x 0.5
46	736-0270	Bell Washer.265 x 0.75
47	17032A	Deflector Chute Adapter
48	732-1014	Torsion Spring
49	747-0710	Hinge Pin
50	987-02347	Bearing Assembly
51	787-01278-0691	21" Deck
52	987-02194A	Height Adjustment Ass'y - RH
	987-02193A	Height Adjustment Ass'y - LH
53	750-04405	Sleeve Spacer, 1.8" Lg.
54	710-0216	Hex Screw, 3/8-16 x.75
55	712-04065	Flange Lock Nut, 3/8-16
56	782-5002B	Front Baffle
57	732-04294	Belt Keeper Wire
58	750-04404	Sleeve Spacer, 9.10" Lg.
59	987-02334	Pivot Plate Assembly
60	720-0426	Adjustment Knob
61	734-2042A	Front Wheel
62	710-04531	Screw, 1/4-20 x .390
63	717-1762	Gear 14T RH FWD
	717-1761	Gear 14T LH FWD
64	710-1652	TT Scr. w/Washer 1/4-20 x.625
65	987-02271A	Handle Bracket Assembly - RH
	987-02270A	Handle Bracket Assembly - LH
66	915-0221	Dowel Pin
67	736-0474	Washer
68	987-02333	Pivot Arm Assembly - RH
	987-02332	Pivot Arm Assembly - LH
69	732-04175	Rear Spring Lever
70	738-04266	Shoulder Scr., 500 Dia. x. 385
71	734-2004B	Rear Wheel
72	725-04329	Battery Charger
73	925-04072	Electric Start Harness Assembly
74	925-04347	Key Switch
75	710-1667A	Screw, #10-16 x .750
76	925-0201	Key
77	925-04323	Battery
78	728-0199	Rivet