


LEVEL 1/2 PORTABLE ELECTRIC VEHICLE CHARGER

MODEL: EV-ACS1601U/K3







MODEL: EV-ACS1601U/K3



This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.



Warning-To reduce the risk of injury, user must read instructions manual carefully.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

INSTRUCTIONS


▲ WARNINGS

- ▲ Do not connect the EV charger into a power outlet that is not properly grounded.
- ♠ Please use the EV charger only within the specified operating parameters.
- ⚠ The charger is designed only for vehicles that are compatible with the SAE J1772 AC Level 1/2 charging standard.
- ▲ Do not use the EV charger if it is defective, appears cracked, frayed, broken or otherwise damaged, or fails to operate.
- ▲ Do not use the EV charger's plug or adapter in any outlet for which they are not designed.
- ▲ Do not attempt to open, disassemble, repair, tamper with, or modify the EV charger. The EV charger is not user-serviceable.
- ▲ Do not disconnect the EV charger from the wall outlet when the vehicle is charging.
- ⚠ Do not use the EV charger when either you, the vehicle or the EV charger is exposed to severe rain, snow, electrical storm or other inclement weather.
- ♠ Protect the EV charger from moisture, water and foreign objects at all times. If any exist or appear to have corroded or damaged the EV charger, do not use the EV charger.
- ▲ Do not plug the EV charger into an electrical outlet that is submerged in water or covered in snow. If in this situation, the EV charger is already plugged in and needs to be unplugged, turn off the breaker before unplugging the EV charger.
- ▲ Do not touch the EV charger's end terminals with sharp metallic objects, such as wire, tools or needles. Do not forcefully fold any part of the EV charger or damage it with sharp objects. Do not insert foreign objects into any part of the EV charger.
- ⚠ The EV charger is not a toy and should be kept away from children. If the EV charger is operating, children nearby should be supervised at all times.

PRODUCT SPECIFICATIONS

Voltage	110-240V AC Single-phase		
Current	16A Max		
Power	3.84 kW Max		
Plug	6-20 Plug + 5-15 Adapter		
Innut / Output	240V/AC 16A		
Input / Output	120V/AC 12A		
Circuit Breaker Requirements	20A Circuit Breaker for 6-20 Plug 15A Circuit Breaker for 5-15 Adapter		
Standard	SAE J1772 (IEC 62196 Type 1)		
Operating Temperature	-22°F to 122°F (-30°C to 50°C)		
Storage Temperature	-40°F to 185°F (-40°C to 85°C)		
IP Rating	IP66		
Total Length	25 Feet		

PRODUCT OVERVIEW



- ① NEMA 6-20 Plug
- 2 Control Box
- ③ LED Light
- Charging Cable
- ⑤ SAE J1772 Connector
- ⑥ Protective Cap


CAUTIONS BEFORE START CHARGING


- **1.** Make sure that the power outlet is properly grounded before plug the EV charger into it.
- 2. Do not use the EV charger if it is defective, appears cracked, frayed, broken or otherwise damaged, or fails to operate. Do not start using if the plug is dirty or wet.
- 3. The plug should be inserted completely into the power outlet.






HOW TO START CHARGING









- **1.** Turn off the vehicle and completely insert the EV charger's plug into the power outlet.
- 2. Take off the protective cap.
- 3. Plug the charger connector into your vehicle and start charging.

HOW TO STOP CHARGING







- **1.** Unlock the vehicle and press the button above the handle to pull the charger connector out of the charge port.
- 2. Disconnect the charger's plug from the power outlet.
- **3.** Put on the protective cap then put the charger into the storage bag, and store it in an appropriate location.

LED LIGHT STATUS DESCRIPTION

Color	Status	Description	Color	Status	Description
	Flashing	Charging		Flashing	EV Connected
	Solid on	Fully charged		Solid on	Ground fault
	Solid on	Standing by		Flashing	Ground fault

TROUBLESHOOTING

Diagnostic Problem		Solution		
The red light is solid on	Leakage Over voltage Over current	1.Check whether the charger is broken or damaged. 2.Re-plug the charger. 3.Try a different outlet. If the error persists, please contact our support service.		
The red light is flashing	The power outlet is not properly grounded.	The charger must be plugged into a power outlet that is properly grounded, though the charging is allowed when connected to the vehicle.		
The blue light is flashing, but the charging is not in progress.	Something stops the charging progress.	Re-plug the charger connector and it will start charging again.		
The blue light is solid on but the charging is not in progress.	The charger is not connected to the vehicle.	Make sure that the charger connector is plugged completely into the charge port.		
The charging speed is not fast as advertised, or the charging current can't reach the maximum ampere. A. The charger or the vehicle is overheating. B. The vehicle charging setting is set a limited ampere.		A. Stop the charging progress, wait for the charger or vehicle cooling down and start charging again. B. Cancel the ampere limited setting in your vehicle.		

Sanven Technology Ltd. Address: Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730

