



Step 4



Instruction Manual


FULL-MOTION TV WALL MOUNT

TEXONIC 




CAUTION: DO NOT EXCEED MAXIMUM LISTED WEIGHT CAPACITY. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

Parts List



www.texonic.ca


Step 1-a For Wood Stud Wall Mounting





Find and mark the exact location of mounting holes





Drill pilot holes




Step 1-b For Solid Brick and Concrete Mounting



Drill pilot holes



Step 2 Installing the Display



Step 3 Installing the Display

