

Installation Instructions
SKU# 260432, 260433, 260434
[LD-WLT749-1, LD-WLT712-1RO, LD-WLT719-1RO]
Rated Voltage 220-240V~ 50Hz

THANK YOU FOR PURCHASING THIS QUALITY LUCCI PRODUCT. TO ENSURE CORRECT FUNCTION AND SAFETY, PLEASE READ AND FOLLOW ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT. PLEASE KEEP THE INSTRUCTIONS FOR FUTURE REFERENCE.

WARRANTY:







- This light fitting is covered by a 12 month warranty; please retain proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the fitting.

INSTALLATION REQUIREMENTS:

- This product is suitable for indoor use only.
- Do not exceed the maximum wattage rating.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling.
- Check whether the fitting has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Ensure power connection is off for your own safety.
- Select a suitable location for the fitting;
 - Ensure the fitting is not next to any air vents and is not in any moist or damp areas.
 - Do not place flammable material near or over the fitting.
 - Ensure it is on a flat and stable surface

INSTALLATION DIRECTIONS:

1. Remove all packaging material from the lamp and shade (A).
2. Unscrew and remove the lamp holder skirt (C) from the lamp holder (B).
3. Place the shade (A) onto the lamp holder (B) and secure by using the lamp holder skirt (C).
4. Install a globe (D - not included) into the lamp holder (B). Do not exceed the maximum wattage rating.
5. Insert the plug into the socket outlet and ensure it is fully plugged in.
6. Turn power on at the socket outlet.
7. Use the cord line switch to turn the lamp on/off.



SAFETY TIPS:

1. Always ensure the power is OFF and the fitting has cooled down before performing any maintenance, cleaning, changing the globe or adjustment to the fitting.
2. Do not touch the globe with bare hands. Use a clean cloth, gloves or a tissue.
3. To avoid injury or damage to the fitting, ensure the power cord is fully plugged in before using.
4. Handle the fitting and shade with care to avoid any damage or breakage.
5. Select a suitable location away from liquids, hazards or flammable material.
6. Ensure that the fitting does not come in contact with any corrosive solvents or chemicals etc.
7. To clean, wipe with a damp clean cloth. Never soak the fitting in water.

SPECIFICATIONS:

SKU #	260432	260433	260434
MODEL #	LD-WLT749-1	LD-WLT712-1RO	LD-WLT710-1RO
RATED VOLTAGE	220-240V~ 50Hz		
RATED WATTAGE	MAX. 60W		
LAMP HOLDER	ES		
WEIGHT	1.73kg	1.56kg	1.3kg
DIMENSIONS	245 x 475mm (Dia x H)	245 x 470mm (Dia x H)	245 x 465mm (Dia x H)

