


hama


XX
173057

Keyboard



WK-300






A



B Pairing mode 2.4 GHz



C Pairing mode Bluetooth





+

**Android**

+

**Windows**

+

**MacOS, iOS,
iPadOS**

E

The diagram illustrates the connection sequence for BT 1, 2.4 GHz, and BT 2 devices. A central keyboard shows a finger pressing the **Fn** key. Arrows indicate the flow: 2.4 GHz (1) to BT 1 (2) to BT 2 (3). Each device has a status bar with icons for connection, audio, and power.




2



1





3



F

Assist = AI assistant

Fn +




G


STANDBY



zzz



1x



ON



hama

Service & Support



support.hama.com/00173057

☎ +49 9091 502-0

D

GB



www.hama.com/nep

Hama GmbH & Co KG
86652 Monheim / Germany
www.hama.com

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.



xx173057/10.24