


UX150 ARGB Sync














Intel Installation Guide







Fan & MB SYNC Installation Guide

ACAUTION

Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

