

MONSTER®

BLUETOOTH® 2-IN-1 WIRELESS AUDIO ADAPTER



SCAN QR CODE
TO EXTEND YOUR
PRODUCT'S WARRANTY

Operation Manual

MBA9-1011-BLK
V2.1 0824

Introduction

The Bluetooth® 2-in-1 wireless audio adapter is a Bluetooth Audio Transceiver (Transmitter and Receiver) that allows you to both conveniently receive and transmit audio to and from other audio devices up to 33 feet away. In Transmitter mode you can stream audio from any TV, gaming system, or other audio device that can connect to the Transceiver's inputs, to two Bluetooth headphones, soundbars, or speakers. In Receiver mode, you can stream audio from your phone or other Bluetooth device to any non-Bluetooth audio device that has can be connected to the Transceiver's outputs.


Features

- Transmitter and receiver with analog and digital audio inputs and outputs
- Transmit/stream audio from non-Bluetooth enabled TVs or audio devices to up to two Bluetooth headsets or other Bluetooth devices at the same time.
- Receive Bluetooth audio from mobile phones or other devices and output to headphones, speakers or other wired audio devices with 3.5mm or optical audio
- Easy one-touch pairing and multi-device memory
- Easily connect Bluetooth and non-Bluetooth devices without cables and cords within a wireless range up to 33ft/10m
- Conveniently powered from your TV's USB port or other USB power source (not included)
- Perfectly sync stereo sound

What's Included

- Bluetooth 2-in-1 Wireless Audio Adapter
- Optical Audio Cable 3.3ft/100cm
- 3.5mm Audio Cable 2ft/60cm
- Type-C Power Cable 2.6ft/80cm
- Optional Mounting Adhesive

Controls, at a Glance




①	POWER ON/OFF
②	BLUETOOTH® PAIRING/RE-PAIRING
③	MODE (TX/RX/BYPASS)
④	SEARCH AND PAIR BLUETOOTH® DEVICES (TX MODE)
⑤	MULTI-FUNCTION BUTTON AND VOLUME/SCROLL KNOB
⑥	TYPE-C POWER PORT
⑦	OUTPUT JACKS (RX MODE)
⑧	INPUT JACKS (TX MODE)

Note: For power saving, the display may go dark for approx. 3 seconds when you change modes (TX, RX and Bypass). It may also darken when not being adjusted, and can be illuminated again by pressing the multifunction button.

Power on the Transceiver

Using the included USB Type-C power cable, connect the Bluetooth 2-in-1 Wireless Audio Adapter to a 5V USB power adapter or the USB port on your TV or other USB power source. Press and hold the power button for 3 seconds to power on the device.

Transmitter Mode (TX)



- 1 Press the mode button to switch the Bluetooth® transceiver to transmitter mode, "TX" will appear on the screen and the transceiver will go into "Searching / Connecting".
- 2 Connect the Bluetooth Transceiver output of your TV, game system, or other audio source to the input of the Bluetooth Transceiver with either the included 3.5mm audio cable or optical audio cable.
- 3 Power on Bluetooth headphone/speaker and set them in pairing mode. Follow the pairing instructions for your Bluetooth device.

- 4 Keep the devices close to each other while pairing to Bluetooth. The Transceiver will pair/connect to your Bluetooth audio device. Once connected, the name of the Bluetooth audio device will be shown on the transceiver's screen.
- 5 You should now hear output on your headphones or speaker when you play audio from your TV, game system, or other audio source. **Ensure sound levels are adjusted correctly on the adapter, AND all devices connected for optimal sound quality.**

Troubleshooting: If the Transceiver is not successfully pairing, turn the Transceiver off and then on again by pressing the power button. Then then start the pairing process again.

How to connect the second headphone/speaker:

- 1 Enter the second headphone into pairing mode
- 2 Press the Search and pair button (4)
- 3 Press the multi-function button to confirm

How to choose the paired Bluetooth® headphones/speakers:

- 1 Press the Bluetooth button to disconnect current two paired devices
- 2 The transceiver will automatically enter searching mode and the names of the paired devices will appear on the screen. (One page can show four devices).
- 3 Rotate the multi-function button to choose the desired device then press to confirm.

How to automatically connect two Bluetooth® headphones/speakers:

- 1 Press the search button to disconnect current two paired devices and automatically enter searching and connecting mode. Once connected, two devices name will appear on the screen.


Note: The device will automatically reconnect to the recently connected two headphones/speakers once they are in pairing mode.



Operation Manual

MBA9-1011-BLK
V2.1 0824

Receiver Mode (RX)




- 1 Press the mode button to switch Bluetooth Transceiver to receiver mode, "RX" will be shown on the screen.
- 2 Connect the Bluetooth transceiver to a speaker/soundbar with either the included 3.5mm Audio Cable or Optical Audio Cable
- 3 Turn on the Bluetooth on your phone or other device then search for "Monster MBA9-1011-BLK" then tap to connect. Once connected, the name of mobile phone or Bluetooth device will be shown on the screen. You should now hear output on your speakers when you playback audio from your Bluetooth device.
- 4 Press the multi-function button to play/pause the music or rotate clockwise/anti-clockwise to increase/decrease the volume.

5

Audio Bypass Mode

Use the Bluetooth Transceiver to connect a sound system directly to your TV



- 1 Press the mode button to switch the Bluetooth® transceiver to Bypass mode, "BYPASS" will appear on the screen.
- 2 Connect the TV to the input jack of the transceiver and connect the sound system to the output jack

NOTE: The input/output should be the same. If you are using the OPTICAL cable with the TV, please use OPTICAL cable to connect to the sound system. If you are using the AUX cable to connect to the TV, please use AUX cable to connect to the sound system.

If the transceiver is connected with both AUX and OPTICAL cables in Audio bypass mode, the bypass mode will default to AUX Mode. Disconnect the AUX cables if you intend to use OPTICAL bypass mode.

6

Safety Instructions

Please read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, this warranty is null and void.

- Keep these instructions.
- Do not drop, puncture, or disassemble this product.
- Do not expose this product to dripping or splashing of drinks or liquids of any kind.
- Avoid long exposure to direct sunlight, which may cause damage.
- Do not expose this product to open flames.
- Do not use the product in a strong magnetic field.
- Use a clean, soft cloth to clean. Do not use any corrosive cleaners/oils to clean.
- Do not attempt to repair the device or open the unit as this will void the warranty.

7

Customer Service

1 Year Limited Warranty
Scan QR code for warranty information

866-246-2008

customerservice@monsterilluminescence.com

In the event this product becomes defective, call Customer Service. Do not return this product to the retailer.

Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty or authority to operate the equipment.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed or mobile condition. The minimum separation distance is 20cm.

The illustrated products and specifications may differ slightly from those supplied. The M Monster logo is a registered trademark of Monster, Inc. or its subsidiaries in the U.S. and other countries and are used under license. All other brand names are trademarks of their respective owners. Neither Jem Accessories, Inc. nor Monster, Inc. is affiliated with the respective owners of their trademarks. Licensed and Manufactured by Jem Accessories, Inc. Edison, NJ 08817.

8