



SMÅSTAD



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.



NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.





1



114929

6x



116637

6x



110837

4x




102533

8x




102509

2x




100215

4x




130449

14x




159945

6x




152529

6x




109546

4x



151599

4x




100001

1x


2




2x




4x




2x




2x




2x




9x




2x





2x




1x







1




2




3




4




5




6




7





8




9





2x




17




1




2




3




4




5




6




7




8




9





10






11








12






13







15



16








www.IKEA.com/secure-it






www.IKEA.cn/secure-it





18

English



The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.




19




20




21





22




23







⇕
24




25





26










24












1





2

