






Original	Recharge	Original	Recharge
	Power		Power
	Input		AV / Input / RDS
	Netflix		Shift + Red / Netflix /
	YouTube		Shift + Yellow / YouTube /
	Subtitles		Subtitle / EQ
	Stop		Stop / Hold
	Mute		Mute / Dimmer
	<<		<< / Tune-
	Play / Pause		Play / Slow
	Play / Pause		Pause / Step / Freeze
	>>		>> / Tune+
	Text		Text / Got o
	Gui de		Gui de / EPG / - / -
	Aspect		Picture / Format
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Back		Back / Return
	Home		Menu / Home
	Home		Shift + Menu /
	Options		Shift + Set up / OPT / Tools
	Options		Set up / OPT /
	Vol +		Vol +
	Vol -		Vol -
	Google Assist		Smart / List
	CH+		CH+ / Page+
	CH-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5





Original	Recharge
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info / Angle
 Recall	 Fav / Marker / PC
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random

Original Recharge

