

## Uputstvo za upotrebu (EN)

DENVER bluetooth zvučnik BTV-150B



Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

<https://tehnoteka.rs/p/denver-bluetooth-zvucnik-btv-150b-akcija-cena/>



## Instruction manual

### BLUETOOTH SPEAKER BTV-150

BLUETOOTH  
CONNECTION

MP3 PLAYER

USB/MICRO SD  
CARD READER

AUX IN



<https://facebook.com/Denver.eu>



**FR**  
Cet appareil et  
ses accessoires  
sont recyclables

A DÉPOSER  
EN MAGASIN



OU

A DÉPOSER  
EN DÉCHÈTRE



Points de collecte sur [www.quefaire-demidechets.fr](http://www.quefaire-demidechets.fr)  
Privilégiez la réparation ou le don de votre appareil !


## **Safety information**

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Warning: This product includes lithium polymer batteries.
3. Keep product out of the reach of children and pets to avoid chewing and swallowing.
4. Product operating and storage temperature is from 0 degree Celsius to 40 degree Celsius. Under and over this temperature might affect the function.
5. Never open the product. Touching the inside electrics can cause electric shock. Repairs or service should only be performed by qualified personnel.
6. Do not expose to heat, water, moisture, direct sunlight!
7. Please protect your ears against loud volume. Loud volume can damage your ears and risk in hearing loss.
8. Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
9. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
10. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.
11. Only charge with supplied USB cable.
12. Do not use non original accessories together with the product as this can make the product functionality abnormal.

## **Denver A/S reserve the rights for print errors**

Denver A/S cannot be held responsible for any technical or typographical errors and reserves the right to make changes to the product and manuals without prior notice. If you detect any inaccuracies or omissions, please inform us at the address on the back cover.



## **CONTROLS**

1. Type-C charging port with LED indicator: Red LED when charging; turns off when charging is completed.
2. MicroSD memory input
3. USB input
4. AUX IN input
5. Volume-/Previous Track button
6. Volume +/Next track button
7. Power On/Off/Play/Pause button
8. MODE button

## **CHARGING**

The speaker must be recharged when switched off.

1. Using the supplied USB cable, connect the end with the type-C jack to the type-C connector (1) of the speaker and the other end to the USB port of a PC or USB charger (5V, 1A, not included).
2. The LED indicator will light up red to indicate the charging status of the speaker; when fully charged, the LED indicator will turn off.

## **BASIC OPERATION**

To turn on the speaker, press and hold the power button (7). Press the MODE button (8) to choose from:

1. Bluetooth mode.
2. MicroSD mode: If a microSD memory card is inserted into the microSD port (2), the speaker will start playing music automatically.
3. USB Mode: If a USB stick is inserted into the USB port (3), the speaker will start playing songs automatically.

## **VOLUME ADJUSTMENT**

Press and hold the Volume -(5) or Volume + (6) to decrease or increase the volume.

## **AUX IN**

1. Turn on the speaker.
2. Connect the aux-in cable to the AUX IN jack (4) of the speaker and the other end to the external device.
3. Start playing the contents from the external device.

## **USING A MICROSD CARD/USB STICK**

1. Turn on the speaker.
2. Insert a MicroSD card into the microSD port (2) with the contacts facing the USB port (3) or insert a USB stick into the USB port.
3. The contents will start playing automatically.
4. Press once the Volume-/Previous Track button (5) button to skip to the previous track; press the Volume +/Next track button (6) to move to the next track.
5. Press the button (7) to pause or resume the playback.

## **Bluetooth OPERATION PAIRING DEVICES**

1. Place the speaker next to the Bluetooth device to be paired.
2. Turn on the speaker and press the MODE button (8) to enter the Bluetooth mode.
3. Follow the instructions of your device to search the speaker.
4. The speaker name is "Denver BTV-150" and will be displayed on your Bluetooth device list, select it and enter the password "0000" if required.
5. When paired successfully, you can stream music from your Bluetooth device to the speaker.

### **Notes:**

- The Bluetooth speaker only can connect to one Bluetooth device at a time, and the connection cannot be interrupted during operation.
- When the Bluetooth pairing fails, turn off Bluetooth on your Bluetooth device that you don't want to connect, restart the Bluetooth speaker and search for the Bluetooth device to be connected again.

## **COMMANDS IN Bluetooth MODE**

1. Press once the Volume-/Previous Track button (5) button to skip to the previous track; press the Volume +/Next track button (6) to move to the next track.
2. Press the power button (7) to pause or resume the playback.
3. If you receive a call, press the power button (7) to answer the call and activate the speaker's phone feature. To end the call, press the power button.

## **TRUE WIRELESS STEREO Bluetooth CONNECTION(TWS FUNCTION FOR TWO SPEAKERS)**

1. Power on two speakers and the default setting is the Bluetooth mode, the LED light flashes (a sound is heard confirming the speaker is set into Bluetooth pairing mode);
2. Turn off the Bluetooth function on your phone or other Bluetooth device, press and hold the M button of either speaker (a sound is heard confirming the TWS function is activated), after a few seconds both Bluetooth speakers will give a voice prompt. When you see both speakers' LED lights are flashing, two speakers' Bluetooth are connected;
3. Turn on your mobile phone's Bluetooth, search for the "Denver BTV-150";
4. Find the name "Denver BTV-150" and select it to connect;
5. Bluetooth speaker gives a voice prompt, it says "Bluetooth connected", then you can enjoy the music from two speakers;
6. Press and hold the M button again to quit the TWS function to hear music from one speaker.

Note: If some equipment prompts for a password, enter the default password 0000.

## **VOICE ASSISTANT FUNCTION**

Press the MODE button (8) twice to turn on the voice assistant function.

## **TECHNICAL FEATURES**

|                                 |                                 |
|---------------------------------|---------------------------------|
| Rechargeable Battery:.....      | Built-in lithium: 3.7V, 1200mAh |
| Output power:.....              | 5V 1A                           |
| Bluetooth Frequency Range:..... | 2402MHz~2480MHz                 |
| Operating Frequency Range:..... | 20Hz~20KHz                      |
| Max Output Power:.....          | 40dBm                           |
| Dimensions:.....                | 65 x 65 x 170 mm                |
| Weight:.....                    | 405 g                           |

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT DENVER A/S



denver.eu



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Denver A/S declares that the radio equipment type BTV-150 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: [denver.eu](http://denver.eu) and then click the search ICON on topline of website. Write model number: BTV-150. Now enter product page, and RED directive is found under downloads/other downloads.

Operating Frequency Range: 20Hz-20KHz

Max Output Power:40dBm

DENVER A/S

Omega 5A, Soefften

DK-8382 Hinnerup

Denmark

[www.facebook.com/denver.eu](http://www.facebook.com/denver.eu)

# Contact

## Nordics

**Headquarter**  
Denver A/S  
Omega SA, Soeften  
DK-8382 Hinnerup  
Denmark

Phone: **+45 86 22 61 00**  
(Push "T" for support)

E-Mail  
For technical questions, please write to:  
**support.hq@denver.eu**

For all other questions please write to:  
**contact.hq@denver.eu**

---

## Benelux

**DENVER BENELUX B.V.**  
Barwoutswaarder 13C+D  
3449 HE Woerden  
The Netherlands

Phone: **0900-3437623**

E-Mail: **support.nl@denver.eu**

---

## Spain/Portugal

**DENVER SPAIN S.A**  
Ronda Augustes y Louis Lumiere, nº 23 – nave 16  
Parque Tecnológico  
46900 PATERNA  
Valencia (Spain)

### Spain

Phone: **+34 960 046 883**  
Mail: **support.es@denver.eu**

### Portugal:

Phone: **+35 1255 240 294**  
E-Mail: **denver.service@satfiel.com**

## Germany

**Denver Germany GmbH Service**  
Max-Emanuel-Str. 4  
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail  
**support.de@denver.eu**

**Fairfixx GmbH**  
Repair and service  
Rudolf-Diesel-Str. 3 TOR 2  
53859 Niederkassel

(for TV, E-Mobility/Hoverboards/Balanceboards,  
Smartphones & Tablets)

Tel: **+49 851 379 369 69**  
E-Mail: **denver@fairfixx.de**

---

## Austria

**Lurf Premium Service GmbH**  
Deutschstrasse 1  
1230 Wien

Phone: **+43 1 904 3085**  
E-Mail: **denver@lurfservice.at**

---

If your country is not listed above,  
please write an email to  
**support@denver.eu**



DENVER A/S  
Omega SA, Soeften  
DK-8382 Hinnerup  
Denmark

denver.eu  
facebook.com/denver.eu

Version 1.1

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda Denver, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanесenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

<https://tehnoteka.rs/p/denver-bluetooth-zvucnik-btv-150b-akcija-cena/>