


■ Control Key Description





Touch bar



Button Control	Function Description	Remote Control
MODE	Mode Select	MODE
	Frame Select	
A	AI Function on / off	A
 Touch bar Anticlockwise	Left	
 Touch bar Clockwise	Right	
	Zoom In	
	Zoom Out	
N/A	Save and load setting	S/L
Long press "MODE" button	Mirror the screen	
	microphone on/off	
	Increase volume	
	Decrease volume	
	Downloads the Webcam Companion App for Windows®	N/A
	Downloads the Webcam Companion App for macOS®	N/A

■ Basic Operation

- (1) Press the (MODE) button to select the desired screen mode.
- (2) AI detection is on by default, which will track participants or frame the screen automatically.
- (3) Press () to enter advanced operation and switch frames. Refer to the next chapter "Advanced Operations" for more on screen operations and settings.



■ Advanced Operation

MODE 1

Full Screen 360°

Recommended Scene

Fully display the on-site participants




Introduction

AI detection - on ※Smart tracking mode

Press (A) to turn AI on or off

AI Detection ON OFF




Press (Left ◀) or (Right ▶) to select participant

AI detection - off

Press (A) to turn AI on or off

AI Detection ON OFF




Press (Left ◀) or (Right ▶) to move the screen .

MODE 2

Host Mode

Recommended Scene

Focus on the presenter or the object




Introduction

AI detection - on ※Smart tracking mode

Press (A) to turn AI on or off

AI Detection ON OFF




Press (Left ◀) or (Right ▶) to select participant

AI detection - off

Press (A) to turn AI on or off

AI Detection ON OFF




Press (Left ◀) or (Right ▶) to move the screen .

MODE 3

Dual Host Mode

Recommended Scene


Display two speakers or objects simultaneously



Introduction

Press (**A**) to turn AI on or off

Press (**□**) to enter advanced operation and switch frames



The status of the AI mode in this frame


Press (Left ◀) or (Right ▶) to select participant

Press (**+**) or (**-**) to move the screen to the left or right

AI detection - off

Press (**A**) to turn AI on or off

Press (**□**) to enter advanced operation and switch frames




Press (Left ◀) or (Right ▶) to move the screen .

MODE 4

Three Speakers Mode

Recommended Scene


Display three speakers or objects simultaneously



Introduction

Press (**A**) to turn AI on or off

Press (**□**) to enter advanced operation and switch frames



The status of the AI mode in this frame

Press (Left ◀) or (Right ▶) to select participant

Press (**+**) or (**-**) to move the screen to the left or right

AI detection - off

Press (**A**) to turn AI on or off

Press (**□**) to enter advanced operation and switch frames




Press (Left ◀) or (Right ▶) to move the screen .

MODE 5

360° All Around View (Zoom in/Out)


Recommended Scene

In addition to displaying the entire conference scene in 360 degrees, it can also zoom in to focus on specific participants or objects



Introduction


Press (**A**) to turn AI on or off



Press (**A**) to turn AI on or off

Press (Left ◀) or (Right ▶) to move the screen .

Press (**+**) or (**-**) to zoom in or zoom out the screen




MODE 6

Single View Mode (Vertical 90° Rotation)


Recommended Scene

Suitable for personal video conferences and can adjust the screen to focus on specific objects



Introduction

Press (**A**) to turn AI on or off



Press (**A**) to turn AI on or off

Press (Left ◀) or (Right ▶) to move the screen .

Press (**+**) or (**-**) to zoom in or zoom out the screen

