



Original	Replacement	Original	Replacement
	Power		Power
	CBL/SAT		Setup / OPT /
	Media Player		Audio / Lang I/II
	Blu-ray		Subtitle / EQ
	Game		TV/Radio /
	Aux 1		Text / Goto
	Aux 2		AV / Input / RDS
	TV Audio		Picture / Format
	CD		Shift + 3
	Tuner		Shift + 6
	USB		8
	Phono		Sound / Title
	Bluetooth		9
	Micro		5
	Internet/Radio		6
	CH/Page+		CH+ / Page+
	ECO		Smart / List
	Volume+		Vol+
	CH/Page-		CH- / Page-
	Mute		Mute / Dimmer
	Volume-		Vol-
	Info		Info / Angle
	Option		Shift + Setup / OPT / Tools
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Back		Back / Return
	Down		Down
	Setup		D.Menu / Top
	I<</Tune-		I<< / Preset-
	Play/Pause		Play / Slow
	>>I/Tune+		>>I / Preset+
	HDMI/Out		Guide / EPG / -/-







Original	Replacement	Original	Replacement
	Power		Power
	CBL/SAT		Setup / OPT /
	Media Player		Audio / Lang I/II
	Blu-ray		Subtitle / EQ
	Game		TV/Radio /
	Aux 1		Text / Goto
	Aux 2		AV / Input / RDS
	TV Audio		Picture / Format
	CD		Shift + 3
	Tuner		Shift + 6
	USB		8
	Phono		Sound / Title
	Bluetooth		9
	Micro		5
	Internet/Radio		6
	CH/Page+		CH+ / Page+
	Volume+		Vol+
	CH/Page-		CH- / Page-
	Mute		Mute / Dimmer
	Volume-		Vol-
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Back		Back / Return
	Down		Down
	I<</Tune-		I<< / Preset-
	Play/Pause		Play / Slow
	>>I/Tune+		>>I / Preset+
	Sleep		Sleep / Timer
	Quick Select 1		1
	Quick Select 2		2
	Quick Select 3		3
	Quick Select 4		4

