


BLENDER

FABER

BLENDER
FBG BLENDY P1021



VOLTAGE : 220-240V FREQUENCY : 50-60Hz , 300-350W

INSTRUCTIONS MANUAL

PLEASE READ THIS INSTRUCTIONS MANUAL CAREFULLY BEFORE USING THIS PRODUCT

CONTENT

1. IMPORTANT SAFETY INSTRUCTIONS
2. TECHNICAL SPECIFICATIONS
3. OPERATING INSTRUCTION
4. CLEANING AND MAINTENANCE

IMPORTANT SAFETY INSTRUCTIONS

When using this electrical appliance, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Before using, check that the voltage indicated on the product corresponds with the voltage of your electrical outlet.
3. Do not let cord hang on hot surface or over edge of table or counter.
4. Do not operate any appliance with a damaged cord or plug or after the appliance malfunction or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
5. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
6. Close supervision is necessary when any appliance is used by or near children.
7. Avoid contacting the moving parts.
8. Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender.
9. The use of attachments not recommended or sold by manufacturer may cause fire, electric shock or injury.
10. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning. To disconnect, turn any control to "0", then remove plug from wall outlet by grasping the plug, not the cord.
11. To reduce the risk of injury, never place blade assembly on motor unit without the jar properly attached.
12. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
13. Children should be supervised to ensure that they do not play with the appliance.
14. Do not leave the machine on unattended.
15. When removing the blender from the motor unit, wait until the blades have completely stopped

IMPORTANT SAFETY INSTRUCTIONS

16. Always operate blender with cover in place.
17. Always use the appliance on a secure, dry level surface.
18. Never place this appliance on or near a hot gas or an electric burner or where it could touch a heated appliance.
19. Do not use outdoors.
20. Do not use appliance for other than its intended use.
21. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
22. Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
23. Children shall not play with the appliance.
24. Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.
25. This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
26. WARNING: Potential injury from misuse. Care shall be taken when handling the sharp cutting blades, emptying the bowl and during cleaning.
27. Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.
28. CAUTION: Ensure that the blender is switched off before removing it from the stand.
29. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
30. Be careful if hot liquid is poured into the blender as it can be ejected out of the appliance due to a sudden steaming.
31. Save these instructions.

TECHNICAL SPECIFICATIONS

THIS PRODUCT IS FOR HOUSEHOLD USE ONLY : -

MODEL	FBG BLENDY P1021
POWER SUPPLY	220-240V 50-60Hz
POWER CONSUMPTION	300-350W
PRODUCT SIZE	156 X 125 X 350mm

PARTS : -





Fig.1 : Speed level "0", Item in OFF status ;
Fig.2 : Speed level "1", Item in low speed status ;
Fig.3 : Speed level "2", Item in high speed status ;
Fig.4 : Speed level "P", Item in Puls status.



OPERATING INSTRUCTION

1. Put the 1000ml jar on the motor unit:

The handle of the 1000ml jar aim at the "open lock" symbol on the main unit, then put the jar downward as the below photo then lock it at the right position. (see Fig.5)

2. Take off the 1000ml jar from the motor unit:

Turning the handle of the 1000ml jar to the "open lock" symbol at the main unit, then take off the jar as the below photo. (see Fig.6)




Fig.5




Fig.6

IMPORTANT NOTE :-

- 1) For each use, the consecutive operation time should not exceed 1 minutes, The operation is carried out 5 times with a rest period of 30 mins during which the mixture is replaced. Please let the unit cool to room temperature before performing next operation cycle.
- 2) If you want to stop the machine during operation, just push the knob to 0 position anytime.

OPERATING INSTRUCTION

3. Put the grinder on the main unit:

First, the "arrow" symbol on the grinder aim at the "lock open" symbol on the main unit, then put the jar downward into the main unit as the Fig.9, then screw on the main unit as Fig.10. If you want to take off the grinder, use the opposite steps.




Fig.9




Fig.10

IMPORTANT NOTE :-

- 1) For each use, the consecutive operation time should not exceed 30 seconds, The operation is carried out 5 times with a rest period of 30 mins during which the mixture is replaced. Please let the unit cool to room temperature before performing next operation cycle.
- 2) If you want to stop the machine during operation, just push the knob to 0 position anytime

4. How to use :-

- 4.1 Peeled or cored the fruit or vegetables and then cut them into small dices.
- 4.2 Place the food to be blended into the jar (See Fig.11) . Usually, certain amount of purified water has to be added to facilitate the smooth running of appliance. The proportion of the food and water is 1:1.5. The amount of mixture should not exceed the max level as indicated on the jar.

OPERATING INSTRUCTION

4.3 Recipe :-

INGREDIENT	REMARK	WEIGHT	SPEED
Carrot/Apple	Cut into 15mm*15mm*15mm	400g & water 800g	High Speed

5. Note :-

- 5.1 never add boiling liquids into jar, or run the appliance empty!
- 5.2 Put the lid on the jar and be sure the measuring cup is in place. ;
- 5.3 Plug the power cord into a standard wall outlet. ;
- 5.4 Push the speed knob to the appropriate speed setting for your task. ;
- 5.5 For quick or delicate blending tasks, push the speed knob to P position and hold for a few seconds and then release, the knob will be reset to level "0" then the item will be stop automatically. Operate several times until get the effect you want. If you want to add ingredients while the blender is working, just open the measuring cup and lid (see Fig.12)
- 5.6 When the effect you desire is obtained, push the knob to "0" position ;

IMPORTANT NOTE :-

- 1) For each use, the consecutive operation time should not exceed 1 minutes, The operation is carried out 5 times with a rest period of 30 mins during which the mixture is replaced. Please let the unit cool to room temperature before performing next operation cycle.
- 2) If you want to stop the machine during operation, just push the knob to 0 position anytime.




Fig.11




Fig.12

OPERATING INSTRUCTION

Important operating tips :-

- 1) For best circulation of food that is to be blended with some liquid. pouring the liquid into the jar first, then add solid food.
- 2) Some of the tasks that cannot be performed efficiently with a blender are: beating egg whites, whipping cream, mashing potatoes, grinding meat, mixing dough, extracting juice from fruit and Vegetables, etc.
- 3) The following items should never be placed in the unit as they may cause damage: bones, large pieces of hard things, frozen food, or tough foods.

6. The using of grinding cup :-

- 6.1 Rotate open the grinding cup from grinding cutter head components and place on the table with open side up ;
- 6.2 Put bean food into grinding cup (About $\leq 50g$) and turn-lock clasp well the grinding cutter head components (its seal ring inside), then lock it on the motor unit ;
- 6.3 Plug the power cord into a standard wall outlet ;
- 6.4 Push the speed knob to the 2 speed for your task.(generally need about 30 seconds) When achieved the effect you want, push the knob to 0 position.

CARE & CLEANING

This product contains no user serviceable parts. Refer service to qualified service personnel.

- 7.1 Before cleaning, unplug the blender ;
- 7.2 For easier cleaning, please always wash immediately after using. Don't let food dry on the jar assembly as this will make cleaning difficult. ;
- 7.3 Pour a little warm soapy water into the jar and push the knob to P position for a few seconds. And then empty the jar ;
- 7.4 Rinse the measure cup, lid, seal ring and blade assembly by hands or in a dishwasher and then dry them. They are dishwasher safe components, but the temperature setting shall not exceed 70°C. ; 7.5 Brush the blade clean with warm soapy water, then rinse thoroughly under the tap water. Don't touch the sharp blades, handle carefully. Don't immerse the blade assembly, grinder blade assembly. Please inversion to dry and put in the place where children can't touch.
- 7.6 Wipe the motor unit surface with a damp cloth and dry thoroughly. Remove the stubborn spots by rubbing with non-abrasive cleaner. If liquids spill into the motor unit, please unplug the unit first, then wipe with a dry cloth and dry thoroughly.

CAUTION :

- 7.7 Do not immerse the motor unit into liquids to prevent the risk of electric shock ;**
- 7.8 Do not use rough scouring pads or cleansers to clean the product ;**
- 7.9 Do not place engine base into dishwasher for cleaning. This unit is not available for dishwasher**



Dibuat untuk dan diedarkan oleh :
 FIMACO SDN BHD
 8-2, WISMA FIAMMA,
 No.20, Jalan 7A/62A,
 Bandar Manjalara, 52200 Kuala Lumpur, Malaysia.
 CUSTOMER CARE CENTRE : +603 6279 8888

