

manual

PS2 HDMI adapter

EN

Start

Use the adapter with the original composite cable

Connect the original composite cable to the PS2.

Change the video settings from RGB to YPbPr.

Use the adapter without the original composite cable

Start the PS2 without a game inside.

Wait 20 seconds.

Press "Down".

Press "X".

Wait 5 seconds.

Press "Down" three times.

Press "X".

Press "Left".

Press "X".

Troubleshooting

Remove any games left in the console's tray.

Try to change controller.

Change USB-port on console.

Power must be connected to the HDMI-adapter at all times or else only audio will be outputted.