

Controls

The simple Cricut EasyPress controls are the secret to your iron-on success. You'll love the results.



Tip: To find the correct time and temperature settings for your specific iron-on project with original Cricut EasyPress and Cricut EasyPress 2, refer to our [Cricut Heat Guide](#).

Things to remember

- [Cricut EasyPress Mini](#)
- [Cricut EasyPress](#)
- Always use Cricut EasyPress at room temperature.
- Before using Cricut EasyPress, ensure that fabrics and other base materials are completely dry.
- Always return Cricut EasyPress to its Safety Base when not in use.
- Before using Cricut EasyPress, ensure there is no tape or protective film over its control panel.

Instructions for iron-on

- [Cricut EasyPress Mini](#)
- [Cricut EasyPress](#)

1. **Power Cricut EasyPress ON.**

- Find a firm, flat, heat-resistant surface, around waist high.
- Be sure to avoid flimsy ironing boards.

2. **Set timer and temperature.**

- Use the [Cricut Heat Guide](#) or Cricut Heat app (for Cricut EasyPress 3) to determine project settings.
- Press timer, then use +/- buttons to set recommended time.
 - Cricut Heat app can send settings directly to Cricut EasyPress 3.
- Press temperature, then use +/- buttons to set recommended temperature.
 - Cricut Heat app can send settings directly to Cricut EasyPress 3.
- Orange light means it's heating up. Green light means temperature has been reached. Beep sounds when it's ready.
- **Use extreme caution. Machine operates at high temperatures that can caused burns.**

3. **Preheat base material.** Place Cricut EasyPress on fabric for recommended time.



4. **Position design.** Make sure shiny side (clear carrier sheet) is facing up.



5. **Apply heat to both sides.**
- Place Cricut EasyPress on base material, then press Go button to start timer.
 - Hold Cricut EasyPress in place and apply recommended pressure.
 - Flip base material, and heat back side of design for recommended time.



6. Before removing carrier sheet, refer to the [Cricut Heat Guide](#) or Cricut Heat app (for Cricut EasyPress 3) for peel temperature instructions.



Instructions for Infusible Ink

- [Cricut EasyPress Mini](#)
- [Cricut EasyPress](#)

Infusible Ink projects have special instructions. Carefully follow the instructions for your specific project in these [Infusible Ink How-To articles](#).

Tips to keep in mind:

- Use a Cricut EasyPress Mat or Cricut Pressing Mat rather than a folded towel. Towels hold too much moisture and cause unwanted transfer effects.
- For precise time and temperature settings and recommended pressure for your project, refer to the [Cricut Heat Guide](#) or Cricut Heat app (for Cricut EasyPress 3).
- Avoid seams, buttons, and zippers when positioning Cricut EasyPress on base material. If the heat plate crosses over these things the design will not receive even heat, resulting in unwanted effects. When applying designs to unusual objects, around seams, or in hard-to-reach places, use Cricut EasyPress Mini.
- Do not slide Cricut EasyPress or move hands on the press during transfer. Keep stack as still as possible.
- **Use with extreme caution. Machine operates at high temperatures that can cause burns.** Similarly, base materials will be hot after preheating and transfer. Allow them to cool before handling.