

1/4" MINI AIR REGULATOR

MODEL NO: CAT157

PART NO: 3120171

USER INSTRUCTIONS

ORIGINAL INSTRUCTIONS

GC0122 - Rev 1

INTRODUCTION

Thank you for purchasing this CLARKE product.

Before attempting to use this product, please read this document thoroughly and follow the instructions carefully. In doing so you will ensure the safety of yourself and that of others around you, and you can look forward to your purchase giving you long and satisfactory service.

INSTALLATION


The regulator should ideally be connected to a fixed airline or connected to the outlet of the compressor. An arrow, moulded under the body of the unit, indicates the direction in which the air should flow. Use the mounting bracket supplied whenever possible.

The maximum supply pressure the unit can operate is 145psi (10bar).

IMPORTANT: Remember that the sequence for airline component assembly is: FILTER/REGULATOR/LUBRICATOR.

ADJUSTING THE AIR PRESSURE

To adjust the delivery air pressure, pull the regulator cap upwards and twist clockwise to increase/anti-clockwise to decrease the outlet pressure. The outlet pressure is displayed by the gauge. When the pressure is correct, press the cap back to lock and retain the setting.



The unit can be isolated from the air supply by screwing down the shut off valve on the inlet side of the unit. To restore airflow, unscrew the valve no more than 3 full turns from the fully closed position.



CAUTION: AIRFLOW WILL BE RESTORED AFTER 3 FULL TURNS. NEVER UNSCREW THE VALVE ANY MORE THAN 3 FULL TURNS FROM THE FULLY CLOSED POSITION.

This product has no user serviceable parts.

SPECIFICATION

Weight	0.228 kg
Length x Width x Height	98 x 68 x 80
Maximum supply pressure	143psi (10 bar)
Maximum outlet pressure	115psi (8 bar)
Outlet port size	2 x 1/4" BSP
Gauge range	0-230psi (0-16bar)

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

ENVIRONMENTAL PROTECTION POLICY

Do not dispose of airline products with general household waste at the end of its life. This product contains valuable raw materials and should be disposed of appropriately at a recognized disposal facility.

A SELECTION FROM THE VAST RANGE OF







POWER WASHERS

Hot and cold, electric and engine driven - we have what you need

WELDERS

Mig, Arc, Tig and Spot. From DIY to auto/industrial.

METALWORKING

Drills, grinders and saws for DIY and professional use.

WOODWORKING

Saws, sanders, lathes, mortisers and dust extraction.

HYDRAULICS

Cranes, body repair kits, transmission jacks for all types of workshop use.

WATER PUMPS

Submersible, electric and engine driven for DIY, agriculture and industry.

POWER TOOLS

Angle grinders, cordless drill sets, saws and sanders.

STARTERS/CHARGERS

All sizes for car and commercial use.



PARTS & SERVICE: 0208 988 7400

Parts Enquiries Parts@clarkeinternational.com

Servicing & Technical Enquiries Service@clarkeinternational.com

SALES: UK 01992 565333 or Export 00 44 (0)1992 565335

Clark Content of the International Hernall Street, Epping, Essex CM16 4LG www.clarkeinternational.com