



MacLean MC-164 Tripod Stand with Adjustable Height User Manual

[Home](#) » [MACLEAN](#) » MacLean MC-164 Tripod Stand with Adjustable Height User Manual 



MC-164 Tripod Stand with Adjustable Height User Manual




Contents

- [1 MC-164 Tripod Stand with Adjustable Height](#)
- [2 For your safety](#)
- [3 Package contents](#)
- [4 Specification parameters:](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

MC-164 Tripod Stand with Adjustable Height

Thank you for purchase tripod stand with adjustable height. The tripod was created for users of smartphones, camcorders sports, small video cameras and digital cameras. Thanks to its design it can stand on uneven surfaces. Its small size allows you to take it with you literally anywhere. A 1/4" photographic screw allows you to attach to a tripod camera or camcorder having such a socket. To get the most from your tripod stand, please be sure to read all instructions thoroughly and keep them where they will be ready by all those who use the product.



For your safety

To prevent damage to your Maclean product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them.

1. The manufacturer is not responsible for problems caused by independent modifications. Similarly, in the case of the use of non-original accessories and spare parts.
2. Repair this product only by qualified service manufacturer or an authorized service center. Repair of the device by unqualified service or by an unauthorized service center risks damaging the device and voiding the warranty.
3. The device should not be operated by people (including children) with limited motor or mental predispositions, as well as by people without experience in handling electronic equipment. They may use it only under the supervision of people responsible for their safety.
4. The device should be placed on surfaces or hung in a way that it cannot be damaged and that it does not pose a danger to people, animals and plants. Pay attention to ensure that children and animals do not

have access to the device – they may damage it. Do not expose the device to excessive exposure to harmful factors.

5. After using the tripod, remove the camera / phone / ring light, close the legs and replace the pend handle to the original position. Never carry the tripod with the video / photo camera recorder attached.
6. Clean the tripod with a soft cloth lightly moistened with a mild detergent solution. After using the tripod at a location subject to harmful factor (like sea breezes), be sure to wipe it clean with a dry cloth

Package contents

– Tripod stand – Phone holder – User's manual

Specification parameters:



working height: 1050mm
Min. working height: 350mm
Folded height: 350mm
max. load weight: 2000g
phone holder height: 85mm
Min. phone holder height: 55mm

Documents / Resources



[MacLean MC-164 Tripod Stand with Adjustable Height](#) [pdf] User Manual
MC-164 Tripod Stand with Adjustable Height, MC-164, Tripod Stand with Adjustable Height, M
C-164 Tripod Stand, Tripod Stand, Stand