





MAGICSHINE Monteer 8000S V2.0 MTB Light with Remote Control User Manual


[Home](#) » [MAGICSHINE](#) » MAGICSHINE Monteer 8000S V2.0 MTB Light with Remote Control User Manual 

*MAGICSHINE Monteer 8000S V2.0 MTB Light with
Remote Control User Manual*



MONTEER 8000S V2.0 USER MANUAL


 **WARNING**




Contents

- [1 ACCESSORY/STRUCTURE](#)
- [2 SWITCHING THE LIGHTING MODE](#)
- [3 LUMENS/BURNING TIME](#)
- [4 BATTERY FEATURES](#)
- [5 BATTERY INDICATOR](#)
- [6 HOW TO RECHARGE](#)
- [7 HOW TO INSTALL](#)
- [8 HOW TO INSTALL BATTERY PACK](#)
- [9 OPTIONAL PARTS](#)
- [10 HOW TO PAIR](#)
- [11 HOW TO USE THE M-REMOTE](#)
- [12 SPECIFICATION](#)
- [13 Documents / Resources](#)
- [14 Related Posts](#)


ACCESSORY/STRUCTURE



MONTEER 8000S V2.0




Handlebar mount



Battery pack(电池组)



Nylon strap




USB-C Cable



3mm Hex


Power button

Long press to turn on / off












SWITCHING THE LIGHTING MODE

When you turn the light on, it lights up in the last lighting mode you used. (Mode memory function)
When the light is off, press the power button to display the remaining power.




LUMENS/BURNING TIME

MODE	BRIGHTNESS	ECO	LOW	MID	HIGH	FLASH
	 LUMENS	400	900	1700	3200	0-900
	 h:min	32:00	15:00	09:00	04:00	16:00
	 LUMENS	600	1400	2600	4800	0-1400
	 h:min	22:00	11:00	05:30	02:10	11:30
	 LUMENS	1000	2400	4400	8000	0-2400
	 h:min	12:00	06:30	03:25	01:30	07:00

BATTERY FEATURES

High capacity battery pack with 4*21700 Li-ion battery cells 7.2V 10 Ah.
Multiple circuit protections for safety use.
High quality fireproof PC material for shell.
Type-C charging & discharging integrated interface for 10w/18w fast output.



BATTERY INDICATOR




FLASH RED
0%-10%




RED
11%-30%




GREEN
31%-100%




HOW TO RECHARGE



HOW TO INSTALL



HOW TO INSTALL BATTERY PACK




OPTIONAL PARTS



Helmet mount




M-REMOTE





TTA front mount

HOW TO PAIR



1. Disconnect the light head from the battery.
2. Press the two buttons at the same time until the indicator light flashes.
3. Reconnect the light head to the battery.
4. Pairing is successful: the light head flashes once or the indicator light stops flashing.
5. The M-REMOTE can only be paired with one device. To pair a new device, please repeat the operation steps above .


HOW TO USE THE M-REMOTE



SPECIFICATION

ANSI FL 1 STANDARD





[MAGICSHINE Monteer 8000S V2.0 MTB Light with Remote Control](#) [pdf] User Manual
Monteer 8000S V2.0, MTB Light with Remote Control, Monteer 8000S V2.0 MTB Light with Remote Control, Light with Remote Control, Remote Control