



MAGMA T10-345 Surface Slide Mount Owner's Manual


[Home](#) » [MAGMA](#) » MAGMA T10-345 Surface Slide Mount Owner's Manual 

Contents


- [1 MAGMA T10-345 Surface Slide Mount](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

MAGMA[®]


MAGMA T10-345 Surface Slide Mount




1. Align the bracket with 4 fasteners to the hole pattern on the bottom center of the Firebox or Grill.



2. Secure the fasteners and bracket to the Firebox or Grill.




3. Secure the receiver bracket to desired location



4. Slide the mount arm into the receiver bracket until it locks into place.



5. Place the Firebox or Grill onto the mounting arm.




6. Secure and tighten the bracket to the arm with the quick release lever. To release the grill from the mount, release the lever and pull the grill off the arm.




NOTE: To make any leveling adjustments, loosen the knob, level the grill, and then retighten the knob. |

REMARQUE : Pour effectuer un nivellement réglages, desserrer le bouton, nivelez le gril, puis resserrez le bouton.



NOTE: To remove the arm from the receiver bracket, pull the pin at the top to release the arm and pull the arm up. | REMARQUE : pour retirer le bras de le support du récepteur, tirez sur la goupille en haut pour libérer le bras et tirer le bras vers le haut



Magma Products, LLC 3940 Pixie Avenue, Lakewood, CA 90712 USA | 562-627-0500
mail@magmaproducts.com
magmaproducts.com

Documents / Resources

	MAGMA T10-345 Surface Slide Mount [pdf] Owner's Manual T10-345, Surface Slide Mount, Slide Mount, T10-345, Mount
--	---

References

-  [Magma Products | Boat Grills, Camper Grills, & Accessories](#)