



Mandis Atoll IN50 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis Atoll IN50 Remote Control Instructions 

Contents

- [1 Mandis Atoll IN50 Remote Control](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 OVERVIEW](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Mandis Atoll IN50 Remote Control



Product Information

Specifications

- **Model:** Atoll IN50 (Original), Atoll IN50 (Replacement)
- **Power:** Powered by AC
- **Inputs:** CD, TUNER, TAPE, AUX, DVD, XLR, USB (Original), INPUT CD, INPUT TUNER, INPUT TAPE, INPUT AUX, INPUT DVD (Replacement)
- **Mode:** AV, VCR (Original), AV / Input / RDS (Replacement)
- **Compatibility:** Atoll IN50 ver3

Product Usage Instructions

Original Remote Control

To use the original remote control:

1. Ensure the power is ON.
2. Select the desired input source using the corresponding buttons (CD, TUNER, TAPE, AUX, DVD).
3. Adjust the volume using the VOL+ and VOL- buttons.
4. Mute or unmute the sound using the VOLMUTE button.
5. Configure settings using the CONFIG button.
6. Select the desired channel or bypass mode using the SEL+ and SEL- buttons.
7. View the current channel or input number on the display.

Replacement Remote Control

To use the replacement remote control

1. Ensure the power is ON.
2. Select the desired input source using the corresponding buttons (INPUT CD, INPUT TUNER, INPUT TAPE, INPUT AUX, INPUT DVD).
3. Adjust the volume using the Vol+ and Vol- buttons.
4. Mute or dim the display using the Mute / Dimmer button.
5. Change channels or navigate through pages using the CH+ / Page+ and CH- / Page- buttons.
6. Access additional functions such as Guide, EPG, Display, and Media using the corresponding buttons.
7. Turn the power off using the Power button.

Frequently Asked Questions

- **Q: Where can I find a replacement remote control for Atoll IN50 ver3?**

A: You can find a replacement remote control for Atoll IN50 ver3 at [this link](#).

- **Q: Is the replacement remote control compatible with Atoll IN80SE (AMP ONLY)?**

A: No, the replacement remote control is not compatible with Atoll IN80SE (AMP ONLY). It is specifically designed for Atoll IN50 ver3.

- **Q: How many pages are there in the user manual?**

A: The user manual consists of 2 pages. You can find the second page at [this link](#).

OVERVIEW

	Original	Replacement	Original	Replacement
		Vol+		Vol+
		Config		Menu / Home
		Sel+		CH+ / Page+
		Vol-		Vol-
		Mute		Mute / Dimmer
		Sel-		CH- / Page-
		BY-PASS		4
		NUM		Guide / EPG / -/-
		Disp		Display / Media
		Power		Power
		CD		3
		TUNER		6
		TAPE		5
		AUX		7
		DVD		2
		XLR		1
		USB		8
				Mode
				Smart / List



<https://all-remote-controls.co.uk/en/Atoll/1065651-95968-replacement-remote-control-for-Atoll-IN50-ver3.html>



Original	Replacement	Original	Replacement
	VOL+ Vol+	MODE	Smart / List
	MENU Menu / Home	INPUT AV	AV / Input / RDS
	CH+ / Page+	INPUT VCR	4
	Vol-		
	Mute / Dimmer		
	CH- / Page-		
	1		
	Guide / EPG / -/--		
	Display / Media		
	Power		
	Shift + Power		
	Play / Slow		
	3		
	6		
	5		
	7		
	2		



<https://all-remote-controls.co.uk/en/Atoll/1065651-95968-replacement-remote-control-for-Atoll-IN50-ver3.html>

Documents / Resources

	Mandis Atoll IN50 Remote Control [pdf] Instructions Atoll IN50 Remote Control, Atoll IN50, Remote Control, Control
	Mandis Atoll IN50 Remote Control [pdf] Instructions Atoll IN50 Remote Control, Atoll IN50, Remote Control, Control

References

- [M Replacement remote control for ATOLL IN50 ver3](#)
- [User Manual](#)