



Mandis Atoll IN50 Replacement Remote Control Instruction Manual

[Home](#) » [Mandis](#) » Mandis Atoll IN50 Replacement Remote Control Instruction Manual 



Contents

- [1 Atoll IN50 Replacement Remote Control](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)

Atoll IN50 Replacement Remote Control

[Atoll IN50](#) ()



Original

Replacement

	Vol+		Vol+
	Config		Menu / Home
	Sel+		CH+ / Page+
	Vol-		Vol-
	Mute		Mute / Dimmer

	Sel-		CH- / Page-
	BY-PASS		4
	NUM		Guide / EPG / -/--
	Disp		Display / Media
	Power		Power
	CD		3
	TUNER		6
	TAPE		5
	AUX		7
	DVD		2
	XLR		1
	USB		8
	Mode		Smart / List


	VOL+		Vol+
	CONFIG		Menu / Home
	SEL+		CH+ / Page+
	VOL-		Vol-
	MUTE		Mute / Dimmer
	SEL-		CH- / Page-
	INPUT		1
	NUM		Guide / EPG / -/--
	DISP		Display / Media
	POWER		Power
	POWER OFF	 + 	Shift + Power
	POWER ON		Play / Slow
	INPUT CD		3
	INPUT TUNER		6
	INPUT TAPE		5
	INPUT AUX		7
	INPUT DVD		2

MODE		Smart / List
INPUT AV		AV / Input / RDS
INPUT VCR		4

<https://all-remote-controls.co.uk/en/Atoll/1065651-95968-replacement-remote-control-for-Atoll-IN50-ver3.html>



Documents / Resources



[Mandis Atoll IN50 Replacement Remote Control](#) [pdf] Instruction Manual
Atoll IN50, Atoll IN50 Replacement Remote Control, Replacement Remote Control, Remote Control, Control

References

- [M Replacement remote control for ATOLL IN50 ver3](#)
- [User Manual](#)